

Original operating instructions

Document number: 150001187_03_en-GB Version: 11/04/2022

RP201-21

Round baler

VariPack V 190 XC

From machine number: 1086628





Contact

Maschinenfabrik Bernard Krone GmbH & Co. KG

Heinrich-Krone-Straße 10

48480 Spelle

Germany

Telephone main office	+ 49 (0) 59 77/935-0
Telefax main office	+ 49 (0) 59 77/935-339
Telefax spare parts warehouse na- tional territory	+ 49 (0) 59 77/935-239
Telefax spare parts warehouse export	+ 49 (0) 59 77/935-359
Internet	www.landmaschinen.krone.de
	https://mediathek.krone.de/



For information on your KRONE machines, also refer to <u>mykrone.green</u>. After you have registered, you can generate and manage your machines via the machine number so that you can view the machine data. Via your personal account, you can also access all KRONE services.



Information for enquiries and orders

Model	
Vehicle identification number	
Year of manufacture	

Contact data of your dealer

(Ŭ) KRONE

1	Information on This Document	. 9
1.1	Validity	. 9
1.2	Significance of the document	. 9
1.3	Re-ordering	. 9
1.4	Applicable documents	. 9
1.5	Target group of this document	. 9
1.6	How to use this document	. 9
1.6.1	Directories and references	. 9
1.6.2	Information on direction	10
1.6.3	Term "machine"	10
1.6.4	Figures	10
1.6.5	Scope of the document	10
1.6.6	Means of representation	10
1.6.7	Conversion table	12
2	Safety	14
2.1	Intended use	14
2.2	Reasonably foreseeable misuse	14
2.3	Service life of the machine	15
2.4	Basic safety instructions	15
2.4.1	Importance of operating instructions	15
2.4.2	Personnel qualification of the operating personnel	15
2.4.3	Personnel qualification of the technicians	16
2.4.4	Children in danger	16
2.4.5	Connecting the machine	16
2.4.6	Structural modifications on the machine	16
2.4.7	Additional equipment and spare parts	16
2.4.8	Jobs on the machine	17
2.4.9	Operational safety: Technically sound condition	17
2.4.10	Danger zones	18
2.4.11	Ensuring functionality of safety devices	20
2.4.12	Personal protective equipment	20
2.4.13	Poad safety	21
2.4.14	Parking the machine safely	21
2.4.15	Consumables	22
2 4 17	Dangers arising from environment	23
2.4.18	Sources of danger on the machine	24
2.4.19	Dangers in connection with certain activities: Working on the machine	25
2.4.20	Dangers in connection with certain activities: working on wheels and tyres	26
2.4.21	Behaviour in dangerous situations and in case of accidents	27
2.5	Safety routines	27
2.5.1	Shutting down and safeguarding the machine	27
2.5.2	Securing raised machine and machine parts against lowering	28
2.5.3	Carrying out oil level check and oil and filter element changes safely	28
2.5.4	Running actuator test	29
2.6	Safety labels on the machine	29
2.7	Information labels on the machine	34
2.8	Safety equipment	39
2.8.1	SMV emblem	41
3	Data memory	42
4	Machine description	43
4.1	Machine overview	43
4.2	Overload protections on the machine	44
4.3	Identification plate	44
4.4	Function description net wrapping	46
4.5	Function description of twine tying	47
4.6	Function description cutting unit	48
5	Technical data	49
		-



5.1	Dimensions	49
5.2	Weights	49
5.3	Technically permitted maximum speed (road travel)	49
5.4	Airborne noise emission	49
5.5	Ambient temperature	50
5.6	Tyres	50
5.7	Safety chain	50
5.8	Bale dimensions	50
5.9	Twine wrapping and tying material	50
5.10	Net wrapping and tying material	51
5.11	Requirements for tractor - power	51
5.12	Tractor requirements – hydraulics	51
5.13	Requirements for tractor – electrics	51
5.14	Requirements for tractor – brake system	52
5.15	Consumables	52
5.15.1	OIIs	52
5.15.2	Lubricating greases	53
6	Initial operation	54
6.1	Checklist for initial operation	54
6.2	Scope of delivery	54
6.3	Mounting hose and cable support	55
6.4	Adjusting the drawbar height	56
6.5	Universal shaft	57
6.5.1	Mounting the universal shaft on the machine	57
6.5.2	Adjusting the length of the universal shaft	58
6.5.3	Mounting universal shaft bracket	59
7	Commissioning	60
7 1	Connecting machine to tractor	60
7.1	Mounting the universal shaft on the tractor	61
73	Connecting hydraulic hoses	62
7.0	Connecting hydraulic hoses	63
7.5	Connecting the road lighting	63
7.6	Mounting safety chain	64
77	Connecting the KRONE DS 100 operation unit	65
7.8	Connecting KRONE terminal DS 500	67
7.9	Connecting the KRONE ISOBUS terminal (CCI 800, CCI 1200)	69
7.10	Connecting foreign ISOBUS terminal	71
7.11	Connecting joystick	72
7.12	Connecting the camera to the KRONE ISOBUS terminal CCI 800 or CCI 1200	75
8	Operation	76
0 1	Dreparation before baling	76
0.1	Filipa the hale chamber	70
0.Z 8 3	Completing the baling process, starting typing cycle and electing round bales	70
84	Reducing the pressure on the side walls of the bale chamber	79
85	Operating the support jack	79
8.6	Using the stop cock of the tailgate	80
87	Releasing/applying the parking brake	81
8.8	Using ladders for the tving system	82
8.9	Fifting wheel chocks	83
8.10	Removing/mounting the safety device which prevents unauthorised use	83
8.11	Pick-up	84
8.11.1	Bringing the pick-up to transport/working position	84
8.11.2	Setting the pick-up working height	85
8.11.3	Activating/deactivating the bearing pressure relief for the pick-up	86
8.12	Crop press roller unit	87
8.12.1	Setting the crop press roller unit	87
8.12.2	Removing/mounting the baffle sheet on the crop press roller unit	88
8.13	Cutting unit	89
8.13.1	Lifting/lowering blade cassette	89

(^M) KRONE

8.13.2	Swivelling in/out blades	. 90
8.13.3	Swivelling blade groups in/out	. 92
8.13.4	Storing blades on the blade support	. 93
8.14	Net wrapping	. 94
8.14.1	Inserting the net roll	. 94
8.14.2	Inserting the net	. 96
8.14.3	Cutting the net	. 98
8.14.4	Using pivoted wrapping and tying material supply	. 98
8.15	Twine tying	100
8.15.1	Connecting spools of twine with each other	100
8.15.2	Inserting tying twine	101
8.15.3	Swivelling the twine box to and fro	104
8.10		104
0.17	Crep blackages at the right hand and left hand and of the nick up	105
0.17.1	Crop blockage at the right-hand and left-hand end of the pick-up	105
0.17.2	Crop blockage in the pick-up	105
0.17.3	Crop blockage under the baling alament	100
0.17.4		100
9	KRONE operation unit DS 100	107
9.1	Overview	107
9.2	Switching the operation unit on/off	109
9.3	Call road travel screen	109
9.4	Accessing the working screen	110
9.5	Direction display	110
9.6	Start tying	111
9.7	Switching the working lights on/off	112
9.8	Switching warning beacon on/off	112
9.9	Setting the bale diameter	112
9.10	Setting advance signaling	113
9.11	Setting the sensitivity of the direction display	113
9.12	Setting the early control and adapt of the round halo	114
9.13	Setting the number of not lowers	110
9.14	Setting the twing start dolay	110
9.15	Displaying the customer counter	110
9.10	Sensor test for digital and analogue sensors	120
9.17	Calibrating sensors	120
9 19	Actuator test for digital and analogue actuators	123
9.20	From messages	125
9.21	Manual operation of the tving system	125
9.22	Setting user preferences	126
10	KRONE Terminal DS 500	128
10 1		100
10.1	Fouchable display	120
10.2	Design DS 500	120
10.5		129
11	KRONE ISOBUS terminal (CCI 800, CCI 1200)	131
11.1	Touchable display	131
11.2	Switching terminal on/off	132
11.3	Design of display	133
11.4	Design of the KRONE machine application	133
11.5	Setting units on the terminal	134
12	Foreign ISOBUS terminal	135
12.1	Varying functions to KRONE ISOBUS terminal	135
13	Terminal machine functions	136
13.1	Status line	136
13.2	Keve	137
13.3	Displays on the working screen	130
13.4	Displays on the information bar	141



13.6 13.7	Direction display Accessing the working screen Automatic call of the Road travel screen	142 143 144
13.8	Adjusting bale diameter	145
13.9	Operating TIM 1.0 (Tractor Implement Management)	145
13.9.1	Mode of operation of TIM 1.0	145
13.9.2	TIM displays and keys on the working screen	146
13.9.3	Activating TIM functions	147
13.9.4	Pausing TIM functions	140
13 10 1	Auxiliary functions (AUX)	148
13.10.2	Auxiliary assignment of a joystick	149
14	Terminal menus	152
14.1	Menu structure	152
14.2	Recurrent icons	153
14.3	Selecting a menu Level	154
14.4	Selecting a menu	154
14.5	Changing value	156
14.7	Tving in the menu level	157
14.8	Menu 1 "Number of net layers" (net wrapping)	158
14.9	Menu 1 "Number of twine layers" (twine tying)	158
14.10	Menu 3 "Advance signalling"	159
14.11	Menu 4 "Tying start delay"	159
14.12	Menu 6 "Electronic baling pressure adjustment"	160
14.13	Menu 7 "Sensitivity of direction display"	161
14.14	Monu 8 Select type of tying (for the inet wrapping and twine tying version)	162
14.15	Menu 10 "Manual operation" (for the "Net wrapping" version)	164
14.17	Menu 10 "Manual operation" (for version with "net wrapping and twine tving").	165
14.18	Menu 11 "Correction of start/end position of the twine tying system (for "net wrapping and tw	/ine
	tying" version)	167
1/ 10		107
14.19	Menu 12 "Moisture measurement"	169
14.19	Menu 12 "Moisture measurement" Menu 12-1 "Error message for moisture measurement"	169 169
14.19 14.19.1 14.19.2	Menu 12 "Moisture measurement" Menu 12-1 "Error message for moisture measurement" Menu 12-2 "Correction value for moisture measurement"	169 169 170
14.19 14.19.1 14.19.2 14.20 14.20	Menu 12 "Moisture measurement" Menu 12-1 "Error message for moisture measurement" Menu 12-2 "Correction value for moisture measurement" Menu 13 "Counters"	169 169 170 172
14.19 14.19.1 14.19.2 14.20 14.20.1 14.20.2	Menu 12 "Moisture measurement" Menu 12-1 "Error message for moisture measurement" Menu 12-2 "Correction value for moisture measurement" Menu 13 "Counters" Menu 13-1 "Customer counter" Menu 13-2 "Total counter"	169 169 170 172 172 172
14.19 14.19.1 14.19.2 14.20 14.20.1 14.20.2 14.21	Menu 12 "Moisture measurement" Menu 12-1 "Error message for moisture measurement" Menu 12-2 "Correction value for moisture measurement" Menu 13 "Counters" Menu 13-1 "Customer counter" Menu 13-2 "Total counter" Menu 14 "ISOBUS"	169 169 170 172 172 174 175
14.19 14.19.1 14.19.2 14.20 14.20.1 14.20.2 14.21 14.21.1	Menu 12 "Moisture measurement" Menu 12-1 "Error message for moisture measurement" Menu 12-2 "Correction value for moisture measurement" Menu 13 "Counters" Menu 13-1 "Customer counter" Menu 13-2 "Total counter" Menu 14 "ISOBUS" Menu 14-5 "KRONE SmartConnect"	169 169 170 172 172 174 175 176
14.19 14.19.1 14.20 14.20 14.20.1 14.20.2 14.21 14.21.1 14.21.2	Menu 12 "Moisture measurement"	169 169 170 172 172 172 174 175 176 177
14.19 14.19.1 14.20 14.20 14.20.1 14.20.2 14.21 14.21.1 14.21.2 14.21.3	Menu 12 "Moisture measurement" Menu 12-1 "Error message for moisture measurement" Menu 12-2 "Correction value for moisture measurement" Menu 13 "Counters" Menu 13-1 "Customer counter" Menu 13-2 "Total counter" Menu 14-5 "KRONE SmartConnect" Menu 14-5 "KRONE SmartConnect" Menu 14-6 "Configuring TIM software" (for "TIM 1.0" version) Menu 14-9 "Switching between terminals"	169 169 170 172 172 172 174 175 176 177 178
14.19 14.19.1 14.20 14.20 14.20.1 14.20.2 14.21 14.21.1 14.21.2 14.21.3 14.21.3 14.22	Menu 12 "Moisture measurement" Menu 12-1 "Error message for moisture measurement" Menu 12-2 "Correction value for moisture measurement" Menu 13 "Counters" Menu 13-1 "Customer counter" Menu 13-2 "Total counter" Menu 14 "ISOBUS" Menu 14-5 "KRONE SmartConnect" Menu 14-9 "Switching between terminals" Menu 15 "Settings"	169 169 170 172 172 174 175 176 177 178 179
14.19 14.19.1 14.19.2 14.20 14.20.1 14.20.2 14.21 14.21.1 14.21.2 14.21.3 14.22 14.22.1	Menu 12 "Moisture measurement" Menu 12-1 "Error message for moisture measurement" Menu 12-2 "Correction value for moisture measurement" Menu 13 "Counters" Menu 13-1 "Customer counter" Menu 13-2 "Total counter" Menu 14-5 "KRONE SmartConnect" Menu 14-5 "KRONE SmartConnect" Menu 14-6 "Configuring TIM software" (for "TIM 1.0" version) Menu 14-9 "Switching between terminals" Menu 15 "Settings" Menu 15-1 "Sensor test" Menu 15-1 "Sensor test"	169 169 170 172 172 174 175 176 177 178 179 180
14.19 14.19.1 14.20 14.20 14.20.1 14.20.2 14.21 14.21.1 14.21.2 14.21.3 14.22 14.22.1 14.22.1	Menu 12 "Moisture measurement" Menu 12-1 "Error message for moisture measurement" Menu 12-2 "Correction value for moisture measurement" Menu 13 "Counters" Menu 13-1 "Customer counter" Menu 13-2 "Total counter" Menu 14-5 "KRONE SmartConnect" Menu 14-5 "KRONE SmartConnect" Menu 14-6 "Configuring TIM software" (for "TIM 1.0" version) Menu 14-9 "Switching between terminals" Menu 15 "Settings" Menu 15-1 "Sensor test" Adjusting sensor B08 "Top blade cassette"	169 169 170 172 172 174 175 176 177 178 179 180 182
14.19 14.19.1 14.19.2 14.20 14.20.1 14.20.2 14.21 14.21.1 14.21.2 14.21.3 14.22 14.22.1 14.22.1 14.22.1.1 14.22.1.2 14.22.2	Menu 12 "Moisture measurement" Menu 12-1 "Error message for moisture measurement" Menu 12-2 "Correction value for moisture measurement" Menu 13 "Counters" Menu 13-1 "Customer counter" Menu 13-2 "Total counter" Menu 14-5 "KRONE SmartConnect" Menu 14-5 "KRONE SmartConnect" Menu 14-6 "Configuring TIM software" (for "TIM 1.0" version) Menu 14-9 "Switching between terminals" Menu 15 "Settings" Menu 15 "Settings" Menu 15-1 "Sensor test" Adjusting sensor B08 "Top blade cassette" Adjusting sensor B61 "Tying 1 (passive)"	169 169 170 172 172 172 174 175 176 177 178 179 180 182 183
14.19 14.19.1 14.19.2 14.20 14.20.1 14.20.2 14.21 14.21.1 14.21.2 14.21.3 14.22 14.22.1 14.22.1.1 14.22.1.2 14.22.2 14.22.2 14.22.3	Menu 12 "Moisture measurement" Menu 12-1 "Error message for moisture measurement" Menu 12-2 "Correction value for moisture measurement" Menu 13 "Counters" Menu 13-1 "Customer counter" Menu 13-2 "Total counter" Menu 14 "ISOBUS" Menu 14-5 "KRONE SmartConnect" Menu 14-6 "Configuring TIM software" (for "TIM 1.0" version) Menu 14-9 "Switching between terminals". Menu 15 "Settings" Menu 15-1 "Sensor test" Adjusting sensor B08 "Top blade cassette" Adjusting sensor B61 "Tying 1 (passive)" Menu 15-3 "Software info"	169 169 170 172 172 172 174 175 176 177 178 179 180 182 183 184 186
14.19 14.19.1 14.19.2 14.20 14.20.1 14.20.2 14.21 14.21.2 14.21.3 14.22 14.22.1 14.22.1.1 14.22.1.2 14.22.1.2 14.22.2 14.22.2 14.22.3 14.22.4	Menu 12 "Moisture measurement" Menu 12-1 "Error message for moisture measurement" Menu 12-2 "Correction value for moisture measurement" Menu 13 "Counters" Menu 13-1 "Customer counter" Menu 13-2 "Total counter" Menu 14 "ISOBUS" Menu 14-5 "KRONE SmartConnect" Menu 14-6 "Configuring TIM software" (for "TIM 1.0" version). Menu 14-9 "Switching between terminals". Menu 15 "Settings" Menu 15-1 "Sensor test" Adjusting sensor B08 "Top blade cassette" Adjusting sensor B61 "Tying 1 (passive)" Menu 15-2 "Actuator test" Menu 15-3 "Software info" Menu 15-4 "Error list".	169 169 170 172 172 172 174 175 176 177 178 179 180 182 183 184 186 186
14.19 14.19.1 14.19.2 14.20 14.20.1 14.20.2 14.21 14.21.2 14.21.3 14.22 14.22.1 14.22.1.2 14.22.1.2 14.22.1.2 14.22.2 14.22.2 14.22.3 14.22.4 15	Menu 12 "Moisture measurement"	169 169 170 172 172 172 174 175 176 177 178 179 180 182 183 184 186 186 189
14.19 14.19.1 14.19.2 14.20 14.20.1 14.20.2 14.21 14.21.2 14.21.3 14.22 14.22.1 14.22.1 14.22.1.1 14.22.1.2 14.22.2 14.22.2 14.22.2 14.22.3 14.22.4 15 15.1	Menu 12 "Moisture measurement"	169 169 170 172 172 172 174 175 176 177 178 179 180 182 183 184 186 186 189 190
14.19 14.19.1 14.19.2 14.20 14.20.1 14.20.2 14.21 14.21.1 14.21.2 14.21.3 14.22 14.22.1 14.22.1 14.22.1.1 14.22.2 14.22.2 14.22.2 14.22.3 14.22.4 15 15.1 15.2	Menu 12 "Moisture measurement"	169 169 170 172 172 172 174 175 176 177 178 179 180 182 183 184 186 186 186 189 190
14.19 14.19.1 14.19.2 14.20 14.20.1 14.20.2 14.21 14.21.1 14.21.2 14.21.3 14.22 14.22.1 14.22.1 14.22.1.2 14.22.2 14.22.3 14.22.3 14.22.4 15 15.1 15.2 15.3	Menu 12 "Moisture measurement"	169 169 170 172 172 172 174 175 176 177 178 179 180 182 183 184 186 186 186 189 190 191
14.19 14.19.1 14.19.2 14.20 14.20.1 14.20.2 14.21 14.21.2 14.21.3 14.22.1 14.22.1 14.22.1.1 14.22.1.2 14.22.1 14.22.2 14.22.3 14.22.4 15 15.1 15.2 15.3 15.4	Menu 12 "Moisture measurement"	169 169 169 170 172 172 172 174 175 176 177 178 179 180 182 183 184 186 186 189 190 191 192
14.19 14.19.1 14.19.2 14.20 14.20.1 14.20.2 14.21 14.21.2 14.21.3 14.22 14.22.1 14.22.1 14.22.1 14.22.2 14.22.2 14.22.2 14.22.3 14.22.4 15 15.1 15.2 15.3 15.4 15.5 15.6	Menu 12 "Moisture measurement"	169 169 170 172 172 172 174 175 176 177 178 179 180 182 183 184 186 186 189 190 191 192
14.19 14.19.1 14.19.2 14.20 14.20.1 14.20.2 14.21 14.21.1 14.21.2 14.21.3 14.22 14.22.1 14.22.1 14.22.1 14.22.2 14.22.2 14.22.3 14.22.4 15 15.1 15.2 15.3 15.4 15.5 15.6 15.6 15.6	Menu 12 "Moisture measurement"	169 169 169 170 172 172 172 174 175 176 177 178 179 180 182 183 184 186 186 180 190 191 192 192 193 103
14.19 14.19.1 14.19.2 14.20 14.20.1 14.20.2 14.21 14.21.2 14.21.3 14.22 14.22.1 14.22.1 14.22.1 14.22.2 14.22.3 14.22.2 14.22.3 14.22.3 14.22.4 15 15.1 15.2 15.3 15.4 15.5 15.6 15.6.1 15.6.1 15.6.2	Menu 12 "Moisture measurement"	169 169 169 170 172 172 174 175 176 177 178 179 180 182 183 184 186 186 190 191 192 193 193 194
14.19 14.19.1 14.19.2 14.20 14.20.1 14.20.2 14.21 14.21.2 14.21.3 14.22 14.22.1 14.22.1.2 14.22.1 14.22.2 14.22.3 14.22.2 14.22.3 14.22.4 15 15.1 15.2 15.3 15.4 15.5 15.6 15.6.1 15.6.2 15.6.3	Menu 12 "Moisture measurement"	169 169 169 170 172 172 172 174 175 176 177 178 179 180 182 183 184 186 189 190 191 192 193 193 194 194
14.19 14.19.1 14.19.2 14.20 14.20.1 14.20.2 14.21 14.21.1 14.21.2 14.21.3 14.22 14.22.1 14.22.1 14.22.1 14.22.2 14.22.3 14.22.2 14.22.3 14.22.4 15 15.1 15.2 15.3 15.4 15.5 15.6 15.6.1 15.6.2 15.6.3 15.6.3 15.6.4	Menu 12 "Moisture measurement"	169 169 169 170 172 172 174 175 176 177 178 179 180 182 183 184 186 186 189 190 191 192 193 193 194 194 195

(^M) KRONE

16	Settings	197
16.1	Setting the baling pressure	197
16.2	Setting the bale diameter	197
16.3	Setting net overhang on the wrapping material brake	197
16.4	Setting rubber cloth on the net wrapping	198
16.5	Adjusting the twine tension at the twine box	198
16.6	Adjusting the twine tension at the twine brake	199
16.7	Checking/adjusting blades at the twine tying system	199
16.8	Setting oil quantities for the central chain lubrication unit	201
16.9	Setting the cutting length	202
16.10	Setting the bale ejector	202
17	Service & maintenance	204
17 1	Maintenance table	204
17.1 1	Maintenance – Refore the season	204
17.1.1	Maintenance – After the season	205
17.1.2	Maintenance – once after 10 hours	205
17.1.0	Maintenance – once after 50 hours	205
17 1 5	Maintenance – Once after 500 round bales	206
17 1 6	Maintenance – every 10 hours at least daily	206
17.1.7	Maintenance – every 10 hours	206
17.1.8	Maintenance – Every 250 hours	206
17.1.9	Maintenance – every 500 hours	206
17.1.10	Maintenance – Every 1.000 round bales	206
17.1.11	Maintenance – Every 2 years	207
17.2	Lubrication chart	207
17.3	Lubricating the universal shaft	211
17.4	Tightening torques	212
17.5	Checking/maintaining tyres	215
17.6	Servicing the main gearbox	217
17.7	Checking hydraulic hoses	218
17.8	Cleaning the machine	218
17.9	Clean the bushing and the drawbar eye	219
17.10	Cleaning drive chains	220
17.11	Relieving baling belts	220
17.12	Checking the screw connections on the drawbar	221
17.13	Checking and adjusting the cleaning rollers	221
17.13.1	Cleaning roller on the drive shaft	222
17.13.2	Cleaning roller on the bottom deflection shaft in the tailgate	224
17.14	Checking the fire extinguisher	225
17.15	Removing corrosion from net support / holder	225
17.16	Releasing the cam clutch on the universal shaft	226
17.17	Briefly deactivating cutting unit and pick-up	226
17.18	Changing the blades	226
17.19	Unlocking/locking blade retaining shaft	228
17.20	Checking and moving the blade retaining shaft	229
17.21	Grinding the blades	229
17.22	Checking/lubricating the safety rolls of the single blade locking device	230
17.23	Adjust drive chains.	231
17.23.1	Drive chain of the bailing unit (no. 1).	231
17.23.2	Drive chain of the food cellar and the starter cellar (no. 2)	232
17.23.3	Drive chain of the feed roller and the starter roller (no. 3)	233
17.24 17.24 1	Checking oil level, tenning up oil and cleaning filter	233
17.24.1 17.24.2	Distribution of the oil brushes on the machine	233
17.24.2 17.25	Somicing the hydraulic system	204
17.20	Defore working on the hydraulic system	200
17.20.1	Checking bydraulic boses	230
17.20.2	อกองกักฐานขายเป็นของ	200
18	Malfunction, cause and remedy	237
18.1	Disturbances at the pick-up or during picking up of crops	237
18.2	Disturbances during or after the baling process	238

Table of contents

() KRONE

18.3	Disturbances at the tying unit or during the tying cycle	240
18.4	Malfunctions on the chain lubrication unit	242
18.5	Faults of the electrics/electronics	242
18.5.1	Error Messages	242
18.5.1.1	Possible error types (FMI)	243
18.5.2	Remedying sensor/actuator error	244
18.6	Checking the ratchet on the wrapping material brake	245
18.7	Checking positions of the feed rocker arm	245
18.8	Setting the tailgate lock	248
18.9	Checking the pressure limiting valve	249
18.10	Filling the accumulator	249
18.11	Cleaning deflection rolls and baling belts	250
18.12	Car jack contact points	250
19	Waste disposal	252
20	Appendix	253
20.1	Hydraulic diagram	253
04		
21	INGEX	255
22	Declaration of conformity	265



1 Information on This Document

1.1 Validity

This document is valid for machines of type:

RP201-21 (VariPack V 190 XC)

All information, illustrations and technical data in this document correspond to the latest state at the time of publication.

We reserve the right to make design changes at any time and without notification of reasons.

1.2 Significance of the document

This is an important document. It is addressed to the user and contains safety-relevant information.

- ▶ Prior to starting work, read the complete document and observe its contents.
- Keep this document ready to hand in the document storage tube for the user of the machine, see Page 43.
- Hand over this document to subsequent users.

1.3 Re-ordering

You can request a replacement document if this document became completely or partly unusable, or if you need it in a different language. Please specify the document number shown on the cover page in your order. Alternatively, you can download the document online from KRONE MEDIA <u>https://media.mykrone.green</u>.

1.4 Applicable documents

To ensure that the machine is used safely and as intended, observe the following further applicable documents.

- Operating instructions for universal shaft
- Operating instructions terminal
- AUX joystick operating instructions
- · Supplement to operating instructions "Error messages and parameters"
- Circuit diagram, KRONE
- Spare parts list, KRONE

1.5 Target group of this document

This document aims at the operator of the machine who fulfills the minimum requirements of personnel qualification, see Page 15.

1.6 How to use this document

1.6.1 Directories and references

Contents/headers

The contents and headers in this document ensure quick orientation in the chapters.

1.6 How to use this document



Index

The index contains catchwords in alphabetical order which enable to find information on a desired topic easily. The index can be found on the last pages of this document.

Cross references

Cross references to another place in the document or to another document are in the text with page number.

Examples:

- Check the tight seat of all screws on the machine, see Page 10. (INFO: If you use an electronic version of this document, click on the link to go to the specified page.)
- For further information, refer to the operating instructions of the universal shaft manufacturer.

1.6.2 Information on direction

Directional information in this document, such as front, rear, right and left, applies in the direction of travel of the machine.

1.6.3 Term "machine"

Throughout the rest of this document, the "round baler" will also be referred to as the "machine".

1.6.4 Figures

The figures in this document do not always represent the exact machine type. The information that refers to the figure always corresponds to the machine type of this document.

1.6.5 Scope of the document

In addition to standard equipment, accessories kits and versions of the machine are described in this document. Your machine may deviate from this document.

1.6.6 Means of representation

Icons in the text

The following means of representation (icons) are used to present the text more clearly:



This arrow characterizes an **action step**. Several arrows in a row identify a sequence of actions to be performed step by step.

This icon identifies a **prerequisite** that has to be fulfilled to perform an action step or a sequence of actions.



This arrow marks the intermediate result of an action step.



This arrow identifies the **result** of an action step or sequence of actions.

This bullet point identifies an **enumeration**. If the bullet point is intended, it identifies the second level of the enumeration.



Icons in figures

The following icons can be used in illustrations:

lcon	Explanation	lcon	Explanation	
1	Reference sign for part		Position of a part (e.g. move from position I to position II)	
X	Dimensions (e. g. also W = width, H = height, L = length)		Magnification of display detail	
LH	Left side of machine	RH	Right side of machine	
(1995)	Direction of travel	1	Direction of motion	
	Reference line for visible material		Reference line for covered mater- ial	
	Centre line		Cable routes	
9	Open	0	Closed	
	Apply liquid lubricant (e.g. lubric- ating oil)		Apply lubricating grease	

Warning signs

Warnings of dangers are separated from the remaining text as warning signs and are identified with a danger sign and signal words.

The warning signs must be read and the measures must be observed in order to prevent personal injury.

Explanation of danger sign



This is the danger sign that warns of a risk of injury.

Please observe all notes marked with the danger sign in order to avoid injuries or death.

Explanation of signal words

<u> A</u> DANGER

The signal word DANGER warns of a hazardous situation which will result in serious injuries or death if the warning sign is ignored.



The signal word WARNING warns of a hazardous situation which will result in serious injuries or death if the warning sign is ignored.

1.6 How to use this document





The signal word CAUTION warns of a hazardous situation which will result in minor to moderate injuries if the warning sign is ignored.

Example of a warning sign:

<u> WARNING</u>

Eye damage caused by flying dirt particles

When cleaning with compressed air, dirt particles are ejected at high speed and could get into the eyes. Therefore eyes could be hurt.

- ► Keep people away from the working area.
- Wear personal protective equipment when performing cleaning work with compressed air (e.g. eye protection).

Warnings of property damage/environmental damage

Warnings of property/environmental damage are separated from the remaining text and marked with "Notice".

Example:

NOTICE

Gearbox damage due to low oil level

The gearboxes could be damaged when the oil level is too low.

- Check gear oil level at regular intervals and top up oil, if necessary.
- Check gear oil level approx. 3 to 4 hours after the machine has been switched off. Check oil level only when machine is in horizontal position.

Notes with information and recommendations

Additional information and recommendations for trouble-free and productive operation of the machine are separated from the remaining text and marked with "Information".

Example:

INFO

Each safety label is provided with an order number and can be ordered directly from the manufacturer or from the authorized specialist dealer.

1.6.7 Conversion table

The following table can be used to convert metric units into US units.

Size	SI units (metric)		Factor	Inch-pound units	
	Unit name	Abbrevi- ation		Unit name	Abbrevi- ation
Area	Hectare	ha	2.47105	Acre	acres
Volume flow	Litres per minute	L/min	0.2642	US gallons per	gpm
	Cubic metres per hour	m³/h	4.4029	minute	



Information on This Document 1

How to use this document 1.6

Size	SI units (metric)		Factor	Inch-pound units	Inch-pound units	
	Unit name	Abbrevi- ation		Unit name	Abbrevi- ation	
Force	Newton	N	0.2248	Pound force	lbf	
Length	Millimetre	mm	0.03937	Inch	in.	
	Metre	m	3.2808	Foot	ft.	
Power	Kilowatt	kW	1.3410	Horsepower	hp	
Pressure	Kilopascal	kPa	0.1450	Pounds per	psi	
	Megapascal	MPa	145.0377	square inch		
	bar (non-SI)	bar	14.5038			
Torque	Newtonmeter	Nm	0.7376	pound-foot or foot-pound	ft·lbf	
			8.8507	pound-inch or inch-pound	in·lbf	
Temperature	Degrees Celsius	°C	°Cx1.8+32	Degrees Fahrenheit	°F	
Velocity	Metres per minute	m/min	3.2808	Feet per minute	ft/min	
	Metres per second	m/s	3.2808	Feet per second	ft/s	
	Kilometres per hour	km/h	0.6215	Miles per hour	mph	
Volumes	Litres	L	0.2642	US gallon	US gal.	
	Millilitre	ml	0.0338	US ounce	US oz.	
	Cubic centi- metre	ст³	0.0610	Cubic inch	in³	
Weight	Kilogram	kg	2.2046	Pound	lbs	

2 Safety

2.1 Intended use



2 Safety

2.1 Intended use

This machine is a round baler and is used to press crops to round bales.

The crops designated for the intended use of this machine are cut stalk and leaf crops.

This machine was specially developed for dry goods. Its field of application is therefore limited to the dry matter of the material to be harvested.

The moisture content in hay and straw should not exceed 16%.

The machine is designed exclusively for use in agriculture and may only be used when

- all safety devices are available according to the operating instructions and are located in the protective position.
- all safety instructions of the operating instructions have been observed and complied with, both in chapter "Basic safety instructions", *see Page 15*, and directly in the chapters of the operating instructions.

The machine may be used only by people who satisfy the personnel qualification requirements designated by the machine manufacturer, *see Page 15*.

These operating instructions are part of the machine and must therefore be at hand when the machine is in use. The machine may be operated only when the operator has received training and in compliance with these operating instructions.

If the machine is used for applications which are not described in these operating instructions, this may result in serious injuries or death and damage to the machine and other property.

Unauthorised modifications to the machine may affect the properties of the machine or disrupt the proper operation. For this reason, unauthorised modifications shall exclude any liability of the manufacturer for consequential damage.

The intended use shall also include the adherence to the operating, maintenance and repair conditions set by the manufacturer.

2.2 Reasonably foreseeable misuse

Any use beyond the intended use*see Page 14* is regarded as improper use and is therefore misuse according to the Machinery Directive. The manufacturer is not liable for damage resulting from this, the user alone bears the risk.

Such misuse is for example:

- Processing of crops which are outside the intended use of the machine, see Page 14
- Transport of people
- Transport of goods
- · Exceeding the permitted technical gross weight
- Non-compliance with the safety labels on the machine and safety notes in the operating instructions
- Performing troubleshooting, setting, cleaning, repair and maintenance work contrary to the information in the operating instructions
- Unauthorised modifications to the machine
- · Attachment of unauthorised or unapproved additional equipment
- Use of spare parts which are not KRONE original spare parts
- Stationary operation of the machine

Unauthorised modifications to the machine may affect the properties of the machine or disrupt proper operation. For this reason, unauthorised modifications will exclude any liability of the manufacturer for consequential damage.

2.3 Service life of the machine

- The service life of this machine depends on its proper operation and maintenance as well as the operating and harvesting conditions.
- By heeding the instructions and information in these operating instructions, permanent operational readiness and a long service life of the machine can be achieved.
- After each operating season, inspect the entire machine for wear and other damage.
- Replace damaged and worn components before recommissioning the machine.
- Carry out a full technical inspection of the machine after five years of machine operation and make a decision on further machine usage taking the results of this inspection into account.
- Theoretically, the service life of this machine is unlimited as all worn or damaged components can be replaced.

2.4 Basic safety instructions

Non-compliance with the safety instructions and warnings

Non-compliance with the safety instructions and warnings may result in injuries and damage to the environment and property.

2.4.1 Importance of operating instructions

The operating instructions are an important document and a part of the machine. They are intended for the user and contain information that is relevant to safety.

Only the procedures specified in the operating instructions are safe. If the operating instructions are not followed, there is a risk of serious or even fatal injuries.

- Prior to using the machine for the first time, read and observe the "Basic safety notices" completely.
- Prior to starting work, read and observe the respective sections in the operating instructions too.
- Keep the operating instructions ready to hand for the user of the machine in the document storage tube, *see Page 43*.
- ► Hand over the operating instructions to subsequent users.

2.4.2 Personnel qualification of the operating personnel

If the machine is not used properly, people may be seriously injured or killed. To avoid accidents, each person who works with the machine must satisfy the following minimum requirements:

- He is physically capable of controlling the machine.
- He can work safely with the machine in accordance with these operating instructions.
- He understands the method of operation of the machine within the scope of his work and can identify and avoid the dangers associated with the work.
- He has read the operating instructions and can implement the information in the operating instructions accordingly.
- He is familiar with driving vehicles safely.
- For road travel he has adequate knowledge of the highway code and has the stipulated driving licence.

Safety Basic safety instructions



2.4.3 Personnel qualification of the technicians

If the work (assembly, conversion, modification, extension, repairs, retrofitting) is performed improperly on the machine, people may be seriously or fatally injured. To avoid accidents, everyone who performs work according to these instructions must meet the following minimum requirements:

- Qualified professional, with relevant training.
- Capable of assembling the (partially) disassembled machine according to the assembly instructions provided by the manufacturer.
- He is capable, e.g. by attending a training course, of extending, modifying or repairing the function of the machine according to the relevant instructions provided by the manufacturer.
- He has read the operating instructions and can implement the information in the operating instructions accordingly.
- Ability to perform the work safely according to these instructions.
- Understands the mode of operation of the work to be performed and the machine and is able to identify and avoid risk in carrying out the necessary work.
- Has read these instructions and is able to implement the information explained in these instructions accordingly.

2.4.4 Children in danger

Children are not in a position to assess dangers and behave unpredictably.

Thus children are particularly at risk.

- Keep children away from the machine.
- ▶ Keep children away from consumables.
- Make sure that there are no children in the danger zone, especially when starting and triggering machine movements.

2.4.5 Connecting the machine

When tractor and machine are not correctly connected, there is a risk of causing serious accidents.

- ▶ When connecting, follow all operating instructions:
- the operating instructions of the tractor
- the operating instructions of the machine, see Page 60
- the operating instructions of universal shaft
- Observe the changed driving behaviour of the combination.

2.4.6 Structural modifications on the machine

Structural modifications and extensions that were not approved by KRONE can impair the functionality, operational safety and also the road traffic certification of the machine. As a result, persons can be seriously injured or killed.

Any structural modifications and extensions that are not authorised by KRONE are not permitted.

2.4.7 Additional equipment and spare parts

Additional equipment and spare parts that do not correspond to the requirements of the manufacturer may affect the operational safety of the machine and cause accidents.

To ensure operational safety, use original parts or standard parts which correspond to the requirements of the manufacturer.



2.4.8 Jobs on the machine

Passengers

Passengers may be seriously injured by the machine or fall off the machine and run over. Ejected objects may strike and injure passengers.

Never carry passengers on the machine.

2.4.9 Operational safety: Technically sound condition

Operation only after proper commissioning

The operational safety of the machine is not guaranteed without proper commissioning in accordance with these operating instructions. This may result in accidents and people may be seriously or fatally injured.

▶ Use the machine only after proper commissioning, see Page 60.

Technically sound state of the machine

Improper maintenance and setting could influence the operational safety of the machine and cause accidents. Thus there is a risk of serious injuries or death.

- All maintenance and setting work must be performed according to the chapters "Maintenance and Setting".
- Before performing any maintenance and setting work, shut down and safeguard the machine, see Page 27.

Danger resulting from damage to the machine

Damage to the machine may impair the operational safety of the machine and cause accidents. As a result, people may be seriously injured or killed. The following parts of the machine are particularly important for safety:

- Brakes
- Steering
- Safety Devices
- Connecting devices
- Lighting
- Hydraulics
- Tyres
- Universal shaft

If there are doubts about the operational safety of the machine, for example due to an unexpected change to the operational behaviour, visible damage or leaking consumables:

- Shut down and safeguard the machine, see Page 27.
- Immediately eliminate potential causes of damage, for example heavy soiling, or tighten slack screws.
- Determine the cause of damage according to these operating instructions and repair the damage, if possible, see Page 237.
- In case of damage which may affect operational safety and cannot be repaired according to these operating instructions: Have damage repaired by a qualified service centre.



Technical limit values

If the technical limit values of the machine are not observed, the machine may be damaged. As a result, accidents may occur and people may be seriously or fatally injured. With regard to safety, it is especially important to observe the following technical limit values:

- · maximum permitted operating pressure of the hydraulics
- maximum permitted drive speed
- maximum permitted total weight
- maximum permitted axle load/axle loads
- maximum permitted drawbar load
- · maximum permitted axle loads of the tractor
- · maximum permitted transport height and width
- maximum permitted speed
- ► Comply with limit values, see Page 49.

2.4.10 Danger zones

If the machine is switched on, its surrounding can present a danger zone.

Avoid entering the danger zone of the machine by observing the minimum safety distance.

If the safety distance is not observed, people may be seriously injured or killed.

- Do not switch on the drives and engine if the minimum safety distance has not been observed.
- ▶ If people fail to observe the minimum safety distance, switch off the drives.
- Switch the machine off in shunting and field mode.

The safety distance is:

For machine in shunting and field mode			
In front of the machine	3 m		
Behind the machine	5 m		
On either side of the machine 3 m			
For machine switched on without driving motion			
In front of the machine	3 m		
Behind the machine	5 m		
On either side of the machine	3 m		

The safety distances specified here are minimum distances in terms of intended use. If necessary, these safety distances must be increased according to the operating and ambient conditions.

- Before working in front of and behind the tractor and in the danger zone of the machine: Shut down and secure the machine, see Page 27. This also applies to brief inspection work.
- Consider the information in all relevant operating instructions:
- the operating instructions for the tractor
- · the operating instructions of the machine
- · the operating instructions of universal shaft



Danger zone universal shaft

People may be caught, pulled in and seriously injured by the universal shaft.

- Observe operating instructions of universal shaft.
- Ensure sufficient overlap of section tube and universal shaft guards.
- Make sure that the universal shaft guards are mounted and that they are fully functional.
- Allow the universal shaft locks to engage. There must be no areas of the locking device on the PTO shaft fork which could cause catching or entrapment (e.g. by annular design, protective collar around the locking pin).
- Attach chains to prevent the universal shaft guards from rotating with the shaft.
- Make sure that there is no one in the danger zone of PTO shaft and universal shaft.
- Ensure that the selected speed and direction of rotation of the PTO shaft of the tractor match the permitted speed and direction of rotation of the machine.
- Switch off the PTO shaft when the angles between the universal shaft and the PTO shaft are too large. The machine may be damaged. Parts may be hurled up and cause injury to people.

Danger zone PTO shaft

People may be caught, pulled in and seriously injured by the PTO shaft and the driven components.

Before switching on the PTO shaft:

- Ensure that all protective devices are mounted and brought into protective position.
- Make sure that there is no one in the danger zone of PTO shaft and universal shaft.
- Switch off drives if they are not needed.

Danger zone between tractor and machine

People standing between the tractor and machine may be seriously injured or killed if the tractor rolls away or by carelessness or machine movements:

- Before carrying out any work between the tractor and the machine: Always turn off and secure the machine, see Page 27. This also applies to brief inspection work.
- If the lifting device must be actuated, instruct all people to keep away from the range of movement of the lifting device.

Danger zone when drive is switched on

When the drive is switched on, there is a danger to life caused by rotating machine parts. Ensure that there are no persons in the danger zone of the machine.

- Before starting the machine, instruct all people to leave the danger zone of the machine.
- In case of dangerous situations, immediately switch off drives and instruct people to leave the danger zone.

Danger zone due to trailing machine parts

If machine parts are trailing, people may be seriously injured or killed.



After the drives have been switched off, the following machine parts will trail:

- universal shaft
- Drive chains
- Pick-up
- Cutting rotor
- Tying unit
- bale formation conveyor
- Shut down and safeguard the machine, see Page 27.
- Do not attempt to approach the machine until all moving machine parts have come to a standstill.

2.4.11 Ensuring functionality of safety devices

If safety devices are missing or damaged, people may be seriously injured or killed by moving machine parts.

- ► Replace damaged safety devices.
- Mount dismounted safety devices and machine parts again before start-up and move them to protective position.
- If it is doubtful whether all safety devices have been correctly installed and are functional, have a service centre check them.

Keeping universal shaft guard functional

The overlap of universal shaft and protective cap on the machine must not be less than 50 mm. This minimum overlap is also required for protective devices of wide-angle universal shaft and if couplings or other components are used. If the operator has to reach between the universal shaft guard and the protective cap to connect the universal shaft, the clearance on one level must be at least 50 mm. On all levels the clearance must be no more than 150 mm.

2.4.12 Personal protective equipment

The wearing of personal protective equipment is an important safety measure. Missing or unsuitable personal protective equipment increases health risks and injuries.

Personal protective equipment includes, for example:

- Suitable protective gloves
- Safety shoes
- Tight-fitting protective clothing
- Hearing protection
- Protective goggles
- If dust is generated: appropriate breathing protection
- Specify and provide personal protective equipment for the particular job.
- Use only personal protective equipment which is in proper condition and offers effective protection.
- Adjust personal protective equipment to the person, for example the size.
- Remove unsuitable clothing and jewellery (e.g. rings, necklaces) and cover long hair with a hairnet.

2.4.13 Safety markings on the machine

Safety labels on the machine warn of hazards at danger points and are an important component of the machine's safety equipment. Missing safety labels increase the risk of serious and fatal injuries.

- ► Clean dirty safety labels.
- ▶ After each cleaning, check to ensure that the safety labels are complete and legible.
- ▶ Immediately replace missing, damaged and unrecognisable safety labels.
- Label spare parts with the required safety labels.

Descriptions, explanations and order numbers of the safety labels, see Page 29.

2.4.14 Road safety

Dangers during road travel

Other road users can be put at risk when you drive on public roads and the machine is not properly illuminated and/or exceeds the maximum dimensions and weights laid down by national law.

- Prior to driving on public roads, ensure that the maximum permissible dimensions, weights and axle, support and trailer loads are not exceeded which are applicable under national law for driving on public roads.
- Before driving on roads, switch on the road travel lighting and ensure that it functions properly.
- Before driving on roads, close all stop cocks for the hydraulic supply to the machine between tractor and machine.
- Before driving on roads, move the tractor control units to the neutral position and lock them.

Danger when driving on road and field

Hitched and mounted machines change the handling characteristics of the tractor. The handling characteristics depend for instance on operating state and ground. If changed handling characteristics are not considered, the driver may cause accidents.

Observe measures for driving on road and field, see Page 189.

Dangers if the machine is not prepared properly for road travel

If the machine is not prepared properly for road travel, serious accidents may occur with traffic.

▶ Before driving on roads, prepare the machine for road travel, see Page 190.

Danger when cornering with a machine hitched and due to the overall width

Accidents may occur when cornering due to the machine swinging out and also due to the overall width.

- Consider the overall width of the combined tractor and machine.
- Consider the larger swivel range when cornering.
- Adjust the driving speed when cornering.
- ▶ When turning, watch out for people, oncoming traffic and obstacles.



Dangers when operating the machine on slopes

The machine may tilt when it is used on slopes. As a result, accidents may occur and people may be seriously injured or killed.

- Do not work and drive on a slope unless the ground of the slope is flat and the adhesion of the tyres to the ground is ensured.
- ▶ Turn the machine at low speed. Turn in a large arc.
- Avoid driving across a slope because the centre of gravity of the machine will be changed by payload and by executing machine functions.
- Avoid abrupt steering movements on slopes.
- On slopes always deposit a round bale in such a way that it cannot move on its own.
- Do not park the machine on slopes.

Fire hazard

Frequent braking when driving on public roads, for example when driving downhill, can cause the brake to produce more heat.

Dust, contamination and crop residues can ignite on the hot surfaces of the brake. People can be seriously injured or killed by the fire.

- Prevent excessive heat from building up on the brake by driving with foresight in road traffic.
- Check and clean the machine in the brake area at regular intervals during the working day.

2.4.15 Parking the machine safely

An incorrectly parked and insufficiently safeguarded machine can represent a danger for people, especially children, and can be set into motion or fall over in an uncontrolled manner. People may be injured or killed.

- ▶ Park the machine on a horizontal and level ground capable of bearing the load.
- Before adjusting, repairing, servicing and cleaning the machine, ensure that it is securely positioned.
- ▶ Observe section "Parking the Machine" in chapter Driving and Transport.see Page 190
- Before parking: Shut down and safeguard the machine, see Page 27.

2.4.16 Consumables

Unsuitable consumables

Consumables which do not comply with the requirements of the manufacturer may impair the operational safety of the machine and cause accidents.

▶ Use only consumables which comply with the requirements of the manufacturer.

For requirements on consumables, see Page 52.

Contamination of hydraulic system and/or fuel system

Foreign objects and/or liquids in the hydraulic system and/or fuel system may impair the operational safety of the machine and cause accidents.

- Clean all connections and components.
- Close open connections by means of protective caps.

Environmental protection and disposal

Consumables such as diesel fuel, brake fluid, antifreeze and lubricants (e.g. gearbox oil, hydraulic oil) may damage the environment and the health of people.

- ► Do not release consumables into the environment.
- Fill consumables in a liquid-tight labelled container and dispose of according to the official regulations.
- Absorb leaked consumables with an absorbent material, fill them in a liquid-tight labelled container and dispose of according to the official regulations.

2.4.17 Dangers arising from environment

Fire hazard

Combustible materials may accumulate in the machine due to operation or animals, such as rodents or nesting birds, or dust resuspension.

In case of dry usage conditions, dust, impurities and crop residue may ignite on hot parts and the resulting fire may seriously injure or kill people.

- Check and clean the machine every day before using it for the first time.
- Check and clean the machine regularly during the working day.

Life-threatening electric shock from overhead lines

With tailgate open, the machine may reach the height of overhead lines. This may cause voltage to flash over to the machine and cause a fatal electric shock or fire.

- ► Keep a safe distance from electric overhead lines when opening the tailgate.
- Never open the tailgate near pylons and overhead lines.
- ▶ Keep a safe distance from electric overhead lines when the tailgate is open.
- To avoid a potential electric shock caused by a voltage flashover, never exit from or climb into the tractor under overhead lines.

Behavior in the case of voltage flashover of overhead lines

High electric voltage may be applied to electrically conducting parts of the machine due to voltage flashover. In case of voltage flashover, a voltage drop where major voltage differences are present is created on the ground around the machine. Due to major voltage differences in the ground, people may be killed by electric shocks when making big steps, laying on the ground or supporting themselves with their hands.

- Do not leave the cabin.
- Do not touch any metal parts.
- Do not establish any conductive connection to the ground.
- Warn people: Do not approach the machine. Electrical voltage differences on the ground may lead to severe electric shocks.
- ▶ Wait for help from professional rescue teams. The overhead line must be switched off.



If people have to leave the cabin despite the voltage flashover, for example because there is an imminent danger to life due to fire:

- Avoid simultaneous contact with machine and ground.
- Jump away from the machine. Jump into a safe standing position. Do not touch the machine from the outside.
- ▶ Move away from the machine in very small steps keeping your feet close together.

2.4.18 Sources of danger on the machine

Noise may damage your health

The noise development of the machine during operation may cause health damage such as hardness of hearing, deafness or tinnitus. When using the machine at high rotational speed, the noise level also increases. The height of the sound pressure level depends mainly on the tractor used. The emissions value was measured with the cabin closed under conditions according to DIN EN ISO 4254-1, Appendix B, *see Page 49*.

- ▶ Before starting up the machine, estimate the risk caused by noise.
- Depending on the ambient conditions, working hours and the working and operating conditions of the machine, specify and use suitable hearing protection.
- Specify rules for the use of hearing protection and for the working time.
- During operation keep windows and doors of the cabin closed.
- Remove hearing protection for road travel.

Liquids under high pressure

The following liquids are under high pressure:

Hydraulic oil

Liquids escaping under high pressure may penetrate through the skin and cause severe injuries.

- Shut down and safeguard the machine and contact qualified specialist workshop upon suspicion of damaged hydraulic system.
- Never search for leaks with bare hands. Even a very pin-sized hole may lead to serious injuries.
- ▶ When searching for leaks, use suitable aids, e.g. a piece of cardboard to avoid injuries.
- Keep body and face away from leaks.
- If liquids penetrate the body, immediately consult a doctor. The liquid must be removed from the body as quickly as possible.

Hot liquids

Persons can suffer burns and/or scalding when hot liquids are drained.

- ▶ Wear personal protective equipment when hot consumables are drained.
- If necessary, allow liquids and machine parts to cool down before you start repair, maintenance and cleaning work.



Damaged compressor unit

Damaged compressed-air hoses of compressor unit can tear off. Hoses moving in an uncontrolled manner can cause severe injuries.

- Contact a specialist workshop immediately if you suspect that the compressor unit is damaged.
- Shut down and safeguard the machine, see Page 27.

Damaged hydraulic hoses

Damaged hydraulic hoses may tear off, burst or cause oil leaks. As a result, the machine may be damaged and people may be seriously injured.

- Shut down and safeguard the machine, see Page 27.
- If it is suspected that hydraulic hoses are damaged, immediately contact a service centre, see Page 218.

Hot surfaces

The following components may become hot during operation and may burn people:

- Bale chamber
- Magnetic coils of the regulating valves
- Gearbox
- Maintain an adequate distance from hot surfaces and adjacent components.
- ► Leave machine parts to cool down and wear protective gloves.

2.4.19 Dangers in connection with certain activities: Working on the machine

Only perform work when the machine is at standstill

If the machine is not shut down and safeguarded, parts may move unintentionally or the machine may start moving. Thus there is a risk of serious injuries or death.

Before carrying out any repair, maintenance and cleaning work on the machine, shutdown and safeguard it, see Page 27.

Maintenance and repair work

Improper maintenance and repair work endanger operational safety. Thus there is a risk of accidents, serious injuries or death.

- Only perform work which is described in this operating instructions. Prior to any work, stop and safeguard the machine, see Page 27.
- All other maintenance and repair work must only be performed by qualified specialist workshop.



Working at or on heights of the machine

There is a risk of falling when working at or on heights of the machine. As a result, accidents may occur and people may be seriously or fatally injured.

- ▶ Prior to any work, stop and safeguard the machine, see Page 27.
- Make sure you stand securely.
- Use a suitable fall protection.
- Secure the area below the assembly point against falling objects.

Raised machine and machine parts

The raised machine and machine parts may fall or tilt unintentionally. People may be seriously injured or killed, as a result.

- Do not stay under the raised machine or machine parts which are not safely supported, see Page 28.
- Prior to all work on raised machines or machine parts, lower the machine or machine parts.
- Before performing any work under raised machines or machine parts, secure the machine or machine parts with rigid safety support or with hydraulic shut-off device or by supporting against lowering.

Danger associated with welding work

Improper welding work will endanger the operational safety of the machine. As a result, accidents may occur and people may be seriously or fatally injured.

- Never perform welding work on the following components:
- Gearbox
- Components of the hydraulics
- Components of the electronics
- Frame or supporting components
- Running gear
- Before carrying out welding work on the machine, obtain consent by KRONE customer service and, if required, identify alternatives.
- Before performing welding work on the machine, park the machine safely and disconnect it from the tractor.
- ▶ Welding work must only be performed by experienced qualified personnel.
- Attach the earthing of the welding device near the welding points.
- Caution when performing welding work near electric and hydraulic parts, plastic parts and pressure accumulators. The parts may be damaged, endanger people or cause accidents.

2.4.20 Dangers in connection with certain activities: working on wheels and tyres

Improper assembly or disassembly of wheels and tyres will endanger the operational safety. As a result, accidents may occur and people may be seriously injured or killed.



The fitting of wheels and tyres requires adequate knowledge and approved mounting tools.

- If there is a lack of knowledge, have the wheels and tyres fitted by the KRONE dealer or by a qualified tyre service.
- ▶ When fitting tyres on the rims, never exceed the maximum permitted pressure specified by KRONE, otherwise the tyre or even the rim may explode, *see Page 49*.
- When mounting the wheels, mount the wheel nuts with the specified tightening torque, see Page 215.

2.4.21 Behaviour in dangerous situations and in case of accidents

Any measures not taken or incorrect measures in dangerous situations can make it difficult or impossible to rescue exposed persons. Due to the impeded conditions of rescue, the chances to help and heal injured people deteriorate.

- As a matter of principle: Park the machine.
- Get an overview of the existing danger and identify the reason.
- ► Secure the accident site.
- Save persons from the danger zone.
- Leave danger zone and do not enter it again.
- ► Alarm rescue workers and seek help, if possible.
- Carry out immediate lifesaving actions.

2.5 Safety routines

2.5.1 Shutting down and safeguarding the machine

<u> WARNING</u>

Risk of injury due to movement of the machine or machine parts

If the machine has not been shut down, machine or machine parts may move unintentionally. As a result, people may be seriously injured or killed.

▶ Before leaving the operating position: Shut down and safeguard the machine.

To shut down and safeguard the machine:

- ▶ Park the machine on a stable, horizontal and level ground.
- Switch off the drives and wait until coasting parts have come to a complete stop.
- Switch off the tractor engine, remove the ignition key and take it with you.
- Secure the tractor against rolling away.
- Secure the machine against rolling away by using wheel chocks.
- ▶ If fitted, apply the parking brake on the machine.



2.5.2 Securing raised machine and machine parts against lowering

<u> WARNING</u>

Crushing hazard due to movement of machine or machine parts

If the machine or machine parts are not secured against lowering, the machine or machine parts may roll, fall or sag. Thus people could be squeezed or killed.

- ► Lower the raised machine parts.
- Shut down and safeguard the machine, see Page 27.
- Before working on or under raised machine parts: Secure machine or machine parts against lowering by means of hydraulic shut-off device (e.g. stop cock) on machine side.
- Before working on or under raised machine parts: Safely support machine or machine parts.

In order to safely support the machine or machine parts:

- To support, only use suitable and sufficiently dimensioned materials that do not break or yield.
- Bricks and hollow blocks are not suitable for safely supporting the machine and machine parts. Therefore they must not be used.
- Car jacks are also not suitable for safely supporting the machine and machine parts. They
 must not be used, as well.

2.5.3 Carrying out oil level check and oil and filter element changes safely

<u> WARNING</u>

Safely checking the oil level and changing oil and filter element

The operational safety of the machine can be impaired if oil level check and oil and filter element changes are not carried out safely. This can lead to accidents.

Safely check the oil level and change oil and filter element.

To check the oil level and change oil and filter element safely:

- ▶ Lower raised machine parts or secure them against falling down, see Page 28.
- ▶ □Shut down and safeguard the machine, see Page 27.
- ▶ Observe the intervals for oil level check, oil and filter element changes, see Page 204.
- ▶ Use only the oil grades/oil quantities specified in the consumables table, see Page 52.
- Ensure that the oil and the equipment for filling are clean.
- Clean the area around the components (for example gearbox, high-pressure filter) and make sure that no foreign objects get into the components or the hydraulic system.
- Check installed seal rings for damage. Replace them if necessary.
- Collect leaking oil and/or waste oil in a container provided for this purpose, and dispose of it properly, see Page 23.



2.5.4 Running actuator test

A WARNING		
Run actuator test safely		
When actuators are energised, functions are carried out directly and without a safety prompt. This may cause the unintentional movement of machine parts, trapping and seriously or fatally injuring persons.		
\checkmark Only persons familiar with the machine are permitted to perform the actuator test.		
 The person performing the test must know which machine parts are activated by controlling the actuators. 		
Run the actuator test safely.		
To run the actuator test safely:		

- ▶ Lower raised machine parts or secure them against falling, see Page 28.
- Shut down and secure the machine, see Page 27.
- Cordon off the danger zone of the actuated moving machine parts in a clearly visible manner.
- Ensure that there is nobody in the danger zone of the actuated moving machine parts.
- Switch on the ignition.
- The actuator test must only be performed from a safe position outside the area that is affected by machine parts moved by the actuators.

2.6 Safety labels on the machine

Every safety label is provided with an order number and can be ordered directly from the authorised KRONE dealer. Immediately replace missing, damaged and unrecognisable safety labels.

When attaching safety labels, the contact surface on the machine must be clean and free of dirt, oil and grease to ensure optimum adhesion of the labels.



Position and meaning of safety labels



RPG000-165



1. Ord. no. 939 471 1 (1x)



2. Order no. 939 100 4 (1x) without "gearbox 1000 rpm" version

Order no. 939 101 4 (1x) with "gearbox 1000 rpm" version

Max. 1000/min	Danger when exceeding the maximum permissible PTO speed or the maximum permissible operating pressure
MAX. 200 bar	When exceeding the permissible PTO speed, machine parts may be destroyed or ejected.
	If the maximum permissible operating pressure is exceeded, hydraulic parts may be damaged.
	As a result, people may be seriously or fatally injured.
	 Observe the permissible PTO speed.
	Observe the permitted operating pressure.

3. Ord. no. 942 196 1 (8x)

Danger due to crushing or shearing
Risk of injury due to crushing or shearing points on moving machine parts.
While parts are moving, never reach into areas where there is a risk of being crushed.

4. Ord. no. 939 407 1 (2x)

	Danger due to rotating pick-up
	There is a danger of being drawn in if you approach the danger zone and if you use your hands or feet to remove crop blockages.
X	Before working on the pick-up, switch off the PTO shaft and the engine.



5. Ord. no. 939 125 1 (2x)



6. Ord. no. 27 014 371 0 (3x)

Danger due to impact or crushing
There is danger to life due to the tailgate lowering.
 Before carrying out any maintenance work in the area of the tailgate, close the stop cock on the left lifting cylinder. Ensure that there is no one under the raised tailgate.

7. Order no. 942 290 0 (1x) for "support for fire extinguisher" version



01	
	Danger due to fire
	Risk of injury due to fire on the machine.
	Do not operate the machine unless there is a functional fire extinguisher available.

8. Ord. no. 939 520 1 (2x)

	Danger due to rotating auger
Jest .	There is a risk of being pulled in or caught by the rotating auger.
	Never reach into the rotating auger.
	Maintain an adequate distance from moving machine parts.

9. Ord. no. 942 002 4 (5x)

	Danger due to rotating machine parts
	When the machine is running, there is a risk of injury due to rotating machine parts.
	Before starting up, move the guards into their protective position.



10. Ord. no. 942 360 4 (1x)

	Danger due to unintended movement of the machine when opening the tailgate
	Risk of injury due to the machine rolling away or overturning.
	 Before opening the tailgate, ensure that the machine has been correctly coupled to the tractor.
62.200 x	When uncoupling the machine, ensure that the tailgate is closed.

11. Ord. no. 939 408 2 (2x)

Danger due to rotating machine parts
When climbing onto the machine while the PTO shaft is run- ning, there is a risk of being pulled in by rotating machine parts.
Before climbing onto the machine, switch off the PTO shaft and the engine.

12. Ord. no. 27 028 023 0 (1x)



Danger due to electric shock
Life-threatening injuries due to voltage flashover if machine parts come too close to overhead lines.
 Maintain the prescribed safety distance from overhead power lines.

13. Ord. no. 27 013 422 0 (2x)

	Danger due to impact
	Risk of injury from the rolling bale.
	Ensure that no one remains in the danger zone.



14. Ord. no. 939 412 2 (2x)

Danger due to impact or crushing
When opening the tailgate, there is a risk of people being crushed in the danger zone between the tailgate and a fixed obstacle.
Ensure that there is nobody between the tailgate and a fixed obstacle.

15. Order no. 27 018 010 0 (1x)

Danger due to high-pressure liquid
Hydraulic pressure tanks contain pressurised oil and gas. Risk of injury due to incorrect removal of a pressure tank or im- proper repairs to the hydraulic system.
 Removal of a pressure tank or repairs to a hydraulic system may be carried out by a service centre only.

16. Ord. no. 27 014 439 0 (1x)



2.7 Information labels on the machine

Each information label has an order number. You can order the labels directly from your KRONE dealer. Replace missing, damaged and illegible information labels immediately.

Prior to attaching an information label, ensure that the contact surface on the machine is clean and free of dirt, oil and grease so that the label can adhere to properly.



Location and meaning of the information labels



1. Ord. no. 27 025 114 0 (1x)



The label shows how to load the net in the machine, *see Page 94*.



2. Ord. no. 27 023 843 0 (1x)

27 023 843 0 • T • T • T	The label shows the possible hydraulic connections of the ma- chine. For additional information about connecting the hy- draulic hoses <i>see Page 62</i> .
$\begin{array}{c} \hline \\ \hline $	

3. Ord. no. 27 028 145 0 (1x)

0				
-n;	<u></u>	<u>]</u> 80 cr		verter Brown
	3 m	-	10-20 m	27 558 166 0

To obtain an evenly shaped round bale, tractor and machine should be guided over the swath as shown in the figure, *see Page 77*.

4. Ord. no. 942 038 1 (4x)

	Areas marked with this label shall be protected against splash- ing water. Never direct the water jet of a high-pressure cleaner at bearings and electric/electronic components.
--	--

5. Ord. no. 939 194 1 (2x)



39 194-1	Use a load beam when the machine is lifted, see Page 194.

6. Ord. no. 27 029 221 0 (1x)

7. Ord. no. 27 029 222 0 (1x)

The drawbar height adjustment is optimal when the distance between the centre of the cutting rotor is 835 mm for hay and 855 mm for straw when the machine is connected to the tractor, see Page 56.
--


8. Ord. no. 27 005 758 0 (1x)



The label marks the sensor B08 "Blade cassette up" and that it must be adjusted if necessary, *see Page 182*.

9. Order no. 27 028 859 0 (1x) for "net wrapping and twine tying" version



IX)	for her wrapping and twine tying version
	The label shows how the spools of twine and the twine must be loaded into the machine and knotted, see Page 100.

10. Order no. 939 478 3 (1x) for "Drawbar eye top" version

Anhänger ist mit einer Zugöse DIN 11026 ausgerüstet. Er darf nur an Zugmaschinen mit einer

• Ord. no. 27 021 260 0

Ю
27 021 260 0

There are several lubrication points on the machine which must be lubricated at regular intervals, *see Page 207*. Lubrication points that are not directly visible are additionally marked with this information label.

• Ord. no. 27 018 170 0



There are jacking points on the machine that are identified with this label, *see Page 250*.

Order no. 942 012 2



• Ord. no. 27 023 958 0





There are lashing points on the machine that are identified with this label, *see Page 195*.



2.8 Safety equipment



2.8 Safety equipment



Pos.	Designation	Explanation
1	Parking brake (country-specific)	• The parking brake is used to secure the machine from unintentionally rolling away, see <i>Page 81</i> .
		 The additional safety cable applies the parking brake if the machine breaks away from the tractor while it is driving, <i>see Page 82</i>. In order to prevent the machine from rolling away, also use the wheel chocks, <i>see Page 83</i>.
2	Safety chain	 The safety chain is used for the additional protection of trailed machines in case they become unhitched during transport, see Page 64. The country-specific regulations for using the safety chain during transportation of the
	Catch loop	The catch loop is used for the additional protection of hitched machines.
3.1	Overload protection universal shaft	The overload protection guards the tractor and the machine from load peaks, see Page 44.
3.2	Pick-up overload protection	• The overload protection guards the tractor and the machine from load peaks, <i>see Page 44</i> .
4	Ladders for tying	• The ladders for the tying system are used to facilitate tying and to insert the net more easily, see Page 82.
5	Support jack	• The support jack is used to keep the machine stable when it is not connected to the tractor, <i>see Page 79</i> .
6	Fire extinguisher	For "support for fire extinguisher" version
		Register the fire extinguisher.
		This is the only way of ensuring that due inspec- tion intervals (every 2 years) are observed.
		 Observe country specifications.
		The inspection intervals may differ from one country to another. If this is the case, follow the instructions on the fire extinguisher.
		Further information, see Page 225.



Safety equipment 2.8

Pos.	Designation	Explanation
7	Wheel chocks	 The wheel chocks secure the machine against rolling away. 2 wheel chocks are affixed to the machine, <i>see Page 83</i>. To prevent the machine from rolling away, use the parking brake in addition to the wheel chocks, <i>see Page 81</i>.
8	Stop cock tailgate	• The tailgate stop cock is a safety component which prevents the tailgate from unintentionally closing, see Page 80.
10 (de- pending on country version)	SMV emblem	 The Slow-Moving Vehicle emblem may be attached to slow-moving machines or vehicles, <i>see Page 41</i>. The country-specific specifications must be observed. The SMV emblem is at the rear in the centre or on the left. If the machine is transported on transport vehicles (e.g. lorry or train), the SMV emblem must be covered or removed.

2.8.1 SMV emblem

For the version with "SMV emblem"



KM000-567

The SMV emblem (Slow-Moving Vehicle) (1) can be mounted on slow-moving machines or vehicles. The country-specific specifications must be observed.

The SMV emblem (1) is at the rear in the centre or on left.

If the machine is transported on transport vehicles (for example lorry or train), the SMV emblem must be covered or dismounted.



3 Data memory

A large number of electronic components of the machine contains data memories which save temporarily or permanently technical information on machine condition, events and errors. This technical information generally documents the condition of a part, a module, a system or the environment:

- Operating states of system components (e.g. filling levels)
- Status messages of the machine and its individual components (e.g. number of revolutions of wheel, wheel speed, motion delay, lateral acceleration)
- · Malfunctions and defects in essential system components (e.g. light and brakes)
- Reactions of the machine in special driving situations (e.g. activation of the stability control systems)
- Ambient conditions (e.g. temperature).

This data, which is of an exclusively technical nature, is used to identify and eliminate faults and to optimise machine functions. The data cannot be used to generate movement profiles of travelled distances.

For service activities (e.g. repair services, service processes, warranty cases, quality assurance), employees of the service network (including manufacturer) can use special diagnostic units to read this technical information from the event and error data memories. If necessary, you can obtain further information there. After the error has been eliminated, the information in the error memory is either deleted or continuously overwritten.

When using the machine, situations are possible in which this technical data, in conjunction with other information (accident protocol, damage to the machine, witness statements etc.) - if necessary with the assistance of an expert - can be related to persons.

Additional functions, which are contractually agreed with the customer (e.g. teleservice), allow the transmission of certain machine data from the machine.

(^M) KRONE

4 Machine description

4.1 Machine overview



- 1 Hose and cable support
- 2 Tying
- 3 Document storage tube
- 4 Front hood
- 5 Wheel chock (mounted on both sides)
- 6 Road travel lighting
- 7 Bale ejector
- 8 Blade cassette
- 9 Integral cutting rotor

- 10 Guide wheel
- 11 Pick-up
- 12 Baffle sheet on the crop press roller unit
- 13 Crop press roller unit
- 14 Support jack
- 15 Drawbar
- 16 Safety chain (depending on country version)
- 17 Lanyard (depending on country version)



4.2 **Overload protections on the machine**

NOTICE

Machine damage due to load peaks

The overload protections protect the tractor and the machine from load peaks. For this reason, overload protections must not be modified. The warranty for the machine becomes void if other than the factory-specified overload protections are used.

- Only use the overload protections installed in the machine.
- To avoid early wear of the overload protection, switch the PTO shaft off if the overload protection responds for a longer period of time.
- Shut down and safeguard the machine, see Page 27.
- ▶ Remedy the malfunction, see Page 237.

Universal shaft

To prevent an overload, there is a cam clutch on the universal shaft. It is not necessary to bleed this cam clutch.

If the cam clutch is actuated due to a machine overload, see Page 226.

Pick-up drive

To prevent an overload, there is a claw coupling on the pick-up drive. This claw coupling has been set at the factory and must not be adjusted without consulting your KRONE service partner.

4.3 Identification plate

INFO

The entire identification plate represents a legal document and should not be altered or rendered illegible!



RPG000-007

The machine data are specified on a type plate (1). This is located on the right side of the machine under the front hood.



Machine description 4

Identification plate 4.3



DVG000-004

Example image

- 1 Series
- 2 Type/variant/version (T/V/V)
- 3 Model year
- 4 Year of manufacture
- 5 Vehicle identification number
- 6 Total weight of the machine
- 7 Drawbar load (A-0)
- 8 Axle load (A-1)
- 9 Axle load (A-2)
- 10 Axle load (A-3)

In case of queries about the machine and when ordering spare parts, ensure that you specify the series (1), the vehicle identification number (5) and the year of manufacture (4) of the corresponding machine. The machine number results from the last 7 digits of the vehicle identification number (5).

To ensure that the data is always available, KRONE recommends that you enter it in the boxes on the front cover of these operating instructions.

4.4 Function description net wrapping



4.4 Function description net wrapping



RP001-024

The net roll (2) lies in the net holder (1) and is inserted into the double wrapping unit. Here, the net path is shown in red.

(I) End position

The double wrapping unit is in the end position (I) when no round bale is wrapped. The feed rocker arm (3) is swung away from the bale chamber.

(II) Feed position

The tying cycle starts automatically or manually when the round bale is completely pressed in the bale chamber. The feed rocker arm (3) moves to the feed position (II) and guides the net to the round bale in the bale chamber. The bale chamber rollers guide the net to the round bale.

(III) Tying position

When the net is pulled, the double wrapping unit moves to the tying position (III) and continues to release net until the tying cycle with the selected number of net layers is completed. The double wrapping unit then moves back to the end position (I). This movement triggers the blade (4) to cut the net.



Machine description4Function description of twine tying4.5

4.5 Function description of twine tying



RP001-281

(I) Zero position

The double wrapping unit is in the zero position (I) when no round bale is wrapped. The twine arms (1) and the blade (2) are completely retracted.

(II) Feed position

The tying cycle starts automatically or manually when the round bale is completely pressed in the bale chamber. The twine arms (1) move to the bale chamber in feed position (II) such that the twine can be pulled off the round bale.

(III) Tying start position

When both twines are pulled, the twine arms (1) move to the previously stored tying start position (III) at the outer edge of the round bale. The tying cycle starts there with the selected number of twine layers.

(IV) End position

During the tying cycle, the twine arms (1) move from the outer edge to the centre of the round bale to the previously stored end position (IV). When the selected number of twine layers is reached, the twine arms move back to the zero position (I). At the same time, the blade (2) cuts both twines one by one in succession.

4 Machine description

4.6 Function description cutting unit



4.6 Function description cutting unit

The machine has a cutting unit with cutting rotor and fixed blades. Cutting helps to improve further processing of the round bales and to increase baling density. From the tractor, the blade cassette can be swivelled hydraulically out of the feed channel if there are any crop blockages, *see Page 89*.



5 Technical data

5.1 Dimensions



RPG000-229

Dimensions			
Width [W] depending on tyres	2,541–2,765 mm		
Height [H] (with standard tyres)	3,000 mm		
Length [L] (with bale ejector)	5,090 mm		
Working width [X]	2,150 mm		

5.2 Weights

Weights	
Weights	See information on the type plate, see Page 44.

5.3 Technically permitted maximum speed (road travel)

The technically permitted maximum speed may be restricted by different equipment features (e.g. coupling device, axle, brake, tyres, etc.) or by statutory regulations in the country of use.

Technically permitted maximum speed (road travel)		
Technically permitted maximum speed (road travel)	40 km/h	

5.4 Airborne noise emission

Airborne noise emission		
Emissions value (sound pressure level)	73.2 dB	
Measurement device	Bruel & Kjaer, Type 2236	
Accuracy class	2	
Measurement uncertainty (according to DIN EN ISO 11201)	4 dB	



5.5 Ambient temperature

Ambient temperature

Temperature range for machine operation	-5 to +45 °C

5.6 Tyres

Tyre designation	Minimum pressure V _{max} =10 km/h	Maximum pressure	Recommended tyre pressure ¹
Guide wheels on the pick-up			
15x6.00-6		3.2 bar	
Tyres on the machine			
15.0/55-17 (standard tyres)	1.8 bar	3.6 bar	2.6 bar
500/50-17	1.5 bar	2.8 bar	2.0 bar
500/55-20	1.5 bar	3.0 bar	1.5 bar

¹ The recommendation applies in particular to the usual mixed operation (field/road) at the maximum permitted speed of the machine. If required, the tyre pressure can be reduced to the indicated minimum air pressure. However, the associated maximum speed must then be observed.

5.7 Safety chain

Safety chain	
Tensile strength	89 kN

5.8 Bale dimensions

Bale dimensions		
Width	1,200 mm	
Diameter	dia. 800-1900 mm	

5.9 Twine wrapping and tying material

Twine wrapping and tying material		
Run length plastic twine	400–600 m/kg	
Run length sisal	150–300 m/kg	
Maximum diameter of the spool of twine	270 mm	
Maximum height of the spool of twine	270 mm	



5.10 Net wrapping and tying material

Net wrapping and tying material		
Net width	1,300 mm	
Tear resistance	260 320 kgf	
Diameter of the net roll	dia. max. 310 mm (3000 m roll)	
Length of the sleeve	1,250–1,330 mm	

5.11 Requirements for tractor - power

Requirements for tractor - power		
Tractor power	66 kW (90 HP)	
PTO speed	540 rpm	
PTO speed (without version "Gearbox 1000 rpm"	540 rpm	
PTO speed (for "Gearbox 1000 rpm" version	1000 rpm	
PTO shaft end	1 3/8"; Z=6	

5.12 Tractor requirements – hydraulics

Tractor requirements – Hydraulics		
Volume flow of the hydraulic system	30 60 L/min	
Minimum operating pressure of the hydraulic system	150 bars	
Maximum operating pressure of the hydraulic system	200 bar	
Maximum hydraulic oil temperature	80°C	
Hydraulic oil quality	Oil ISO VG 46	
Hydraulic connection (T)/depressurised return in the tank	1x	
Single-acting hydraulic connection	1x	
Double-acting hydraulic connection	1x	

5.13 Requirements for tractor – electrics

Requirements for tractor – electrics		
Road travel lighting	12 volt, 7-pin socket	
DS 100 operation unit power supply	12 volt, 3-pin socket	
DS 500 operation unit power supply	12 volt, 9-pin socket	
CCI 800/CCI 1200 terminal power supply	12 volt, 9-pin socket	
ISOBUS	12 volt, 9-pin socket	



5.14 Requirements for tractor – brake system

Requirements for tractor – brake system	
Compressed-air connection for "Compressed-air brake" ver- sion	2x
Maximum operating pressure for "Hydraulic brake" version	100 bars

5.15 Consumables

NOTICE

Complying with change intervals for biooils

To ensure high life expectancy of the machine, it is absolutely necessary to comply with change intervals for biooils due to the ageing of the oils.

NOTICE

Machine damage due to mixing of oil

If oils, which have different specifications, are mixed with each other, the machine may be damaged.

- Never mix oils, which have different specifications, with each other.
- Contact your KRONE service partner before using an oil with a different specification after changing the oil.

Biodegradable consumables can be used on request.

5.15.1 Oils

Designation	Filling quantity	Specification
T-gearbox main drive	2.00 L	SAE 90 GL4
Central chain lubrication unit	8.00 L	SAE 10W-40

5.15.2 Lubricating greases

Designation	Filling quantity	Specification
Lubrication points (manual lubrication)	The filling quantity is as re- quired. Lubricate the lubrica- tion points until lubricating grease comes out of the bear- ing position. After lubricating, remove the grease coming out of the bearing position.	Lubricating grease as spe- cified in DIN 51818 of NLGI class 2, Li soap with EP addit- ives
Lubrication points on the ADR axle	The filling quantity is as re- quired. Lubricate the lubrica- tion points until lubricating grease comes out of the bear- ing position. After lubricating, remove the grease coming out of the bearing position.	Lubricating grease as spe- cified in DIN 51825: KP 3 N-20.
Lubrication points on the BPW axle	The filling quantity is as re- quired. Lubricate the lubrica- tion points until lubricating grease comes out of the bear- ing position. After lubricating, remove the grease coming out of the bearing position.	BPW ECO-Li Plus

For a list of the lubrication points to be lubricated see Page 207.



6 Initial operation

This chapter describes assembly and adjustment work on the machine which may be carried out by qualified technicians only. Here, the notice "Personnel qualification of technicians" applies, *see Page 16*.

<u> WARNING</u>

Risk of injury or damage to the machine due to faulty initial operation

If the initial operation is carried out incorrectly or incompletely, the machine may present defects. As a result, people may be injured or killed or the machine may be damaged.

- ► Initial operation must only be carried out by authorised technicians.
- ▶ Read in full and observe the "Personnel qualification of technicians", see Page 16.

<u> WARNING</u>

Risk of injury due to non-observance of relevant safety notices

If the relevant safety notices are not observed, persons may get seriously injured or killed.

To avoid accidents, the basic safety instructions must be read and observed, see Page 15.

<u> WARNING</u>

Risk of injury due to non-observance of safety instructions

If the relevant safety routines are not observed, persons may be seriously injured or killed.

► The safety routines must be read and observed to avoid accidents, see Page 27.

6.1 Checklist for initial operation

- ✓ All screws and nuts are checked for tightness, and are tightened to the specified tightening torques, see Page 212.
- ✓ All sensors have been checked for tight fit and tightened to the specified tightening torques. The location of the sensors is shown in the circuit diagram.
- ✓ The safety devices are mounted and checked for completeness and damage.
- ✓ The machine is fully lubricated, see Page 207.
- ✓ The universal shaft is lubricated, see Page 211.
- ✓ The hydraulic system has been checked for leaks.
- ✓ The tractor corresponds to the machine requirements, see Page 49.
- ✓ The supplied operating instructions are in the document storage tube.
- ✓ Hose and cable support are mounted, see Page 55.
- ✓ The tyres have been checked and the tyre pressure is adjusted correctly, see Page 215.
- ✓ For the "Support for fire extinguisher" version: The fire extinguisher is mounted.
- ✓ The drawbar height is adjusted, see Page 56.
- ✓ The length of the universal shaft has been checked and adjusted, see Page 58.
- ✓ The universal shaft is mounted, see Page 57.
- ✓ The cable ties, which were mounted to secure the storage box flap and the side hood, were removed.

6.2 Scope of delivery

The machine is delivered together with the following additional parts.

Initial operation 6







RPG000-056

- 1 universal shaft
- 2 Ring spanner
- 3 Terminal (depending on version)
- 4 Small parts
- 5 7-pole connection cable for road travel lighting
- 6 Hose and cable support
- 7 Warning foil
- 8 Test roll KRONE excellent, net for net wrapping
- 9 Universal shaft bracket

6.3 Mounting hose and cable support



RPG000-010

- ✓ The machine has been shut down and secured, see Page 27.
- Place the hose and cable support (1) as shown with the support (2) on the frame tube (4).
- ▶ Mount hose and cable support (1) with the screw connections (3).
- Using the screw connections (3), adjust the inclination of the hose and cable support (1) as required for the tractor.
- Route the hoses and cables (5) as close together as possible, pass them through the front ring (6) and secure them with cable ties (7) to the hose and cable support (1) as shown in the figure.
- Ensure that the hoses and cables (5) do not rub against each other or against the front ring (6).



6.4 Adjusting the drawbar height

NOTICE

When the tractor and machine are in a horizontal position, the hitched mechanical connection devices (e.g. ball-head hitch) must be in a horizontal position $(+/-3^{\circ})$ with respect to the ground so as not to obstruct the operational swivel angle between the mechanical connection devices.

To ensure that the pick-up evenly picks up the crops, the drawbar height of the machine must be adjusted to the tractor used.



RPG000-058

The drawbar height adjustment is optimal when the distance X between the centre of the cutting rotor and the ground is **835 mm** when the machine is connected to the tractor.

The distance can be different for straw (large swaths): X=855 mm.

INFO

For high driving speeds on uneven terrain, KRONE recommends a **distance of X=855 mm**. If the machine is too low, there is no support pressure relief for the pick-up.

Checking drawbar height

- ✓ The tyre pressure matches the value in the tyre table, see Page 50.
- To ensure optimum operating conditions, hitch the machine so that the dimension X matches the aforementioned values.
 - ⇒ If the measured dimension differs from dimension X, adjust the drawbar height as follows.

Adjusting the drawbar height



RPG000-087

M KRONE

- \checkmark The machine is disconnected from the tractor and stands on the support jack.
- Loosen the screw connections (1) on the right and left sides of the drawbar until the drawbar (3) can be moved in the toothed disc connections (2).
- Adjust the drawbar (3) to the height of the tractor hitch.
- Ensure that the toothed disc connections (2) mesh.



RPG000-136

To adjust the height of the drawbar eye (6):

- Loosen the screw connections (5) until the drawbar (6) can be moved in the toothed disc connections (4).
- Align the drawbar eye (6) parallel to the ground.
- Ensure that the toothed disc connections (4) mesh.
- ▶ Tighten the screw connections (1) and (5). Torque, see Page 212.
- ▶ After 10 operating hours tighten the screw connections (1) and (5).

6.5 Universal shaft

6.5.1 Mounting the universal shaft on the machine



RP000-281

- ✓ The machine has been shut down and secured, see Page 27.
- ✓ The length of the universal shaft is adjusted to the tractor, see Page 58.
- Remove the screw connection (2) from the universal shaft (1).

(Y) KRONE



RPG000-179

- ► To facilitate access to the screw connection (2) on the universal shaft (1), remove the screw connections (7) and the cover (6) on the protective cap (3).
- ▶ Push the universal shaft (1) onto the PTO shaft end of the machine.
- Mount the screw connection (2) through the resulting hole behind the cover (6). The tightening torque is specified in the operating instructions provided with the universal shaft.
- Mount the cover (6).
- To prevent the supporting chain (5) from rotating, hook it into the eye (4) on the protective cap (3).

INFO

More details can be found in the operating instructions for the universal shaft.

6.5.2 Adjusting the length of the universal shaft

NOTICE

Changing the tractor

There is a risk of damaging the machine if the length of the universal shaft is not checked when the tractor is changed.

► To prevent damage to the machine, check the length of the universal shaft whenever you change tractors. Have it corrected by a KRONE service partner if necessary.

The universal shaft must be shortened as far as the narrowest position of both universal shaft halves permits.

To move the machine into the shortest position:

- Turn the steering of the tractor all the way to the left or to the right and move tractor and machine forwards until the narrowest position is reached when driving around curves.
- Switch off the engine and remove the ignition key and carry it with you.
- Secure machine and tractor against rolling away.
- Instructions on how to shorten the universal shaft can be found in the operating instructions of the universal shaft manufacturer.



6.5.3 Mounting universal shaft bracket



RPG000-133

The universal shaft bracket (1) is only required if the drawbar is in the bottom hitching.

The universal shaft bracket (1) is required to support the universal shaft when the machine has been uncoupled from the tractor.

- ✓ The machine has been shut down and secured, see Page 27.
- \checkmark The universal shaft chain (4) and the chain holder have been removed.
- ▶ To mount the universal shaft bracket (1), remove the screw connection (3).
- Clamp the ends of the bolt (2) on both sides in the boreholes in the drawbar beams.

NOTE! These are the boreholes of the universal shaft chain which was removed beforehand.

- ▶ Mount the screw connection (3). Torque: see Page 212.
- The universal shaft can be deposited with the bottom hitching of the drawbar on the universal shaft bracket (1), see Page 191.



7 Commissioning



Risk of injury due to non-observance of relevant safety notices

If the relevant safety notices are not observed, persons may get seriously injured or killed.

To avoid accidents, the basic safety instructions must be read and observed, see Page 15.

A WARNING

Risk of injury due to non-observance of safety instructions

If the relevant safety routines are not observed, persons may be seriously injured or killed.

▶ The safety routines must be read and observed to avoid accidents, see Page 27.



Risk of injury or damage to the machine due to connection lines which have been incorrectly connected, interchanged or improperly installed

If the connection lines of the machine have been incorrectly connected to the tractor or have been improperly installed, they may pull off or be damaged. This may result in serious accidents. If connection lines are interchanged, functions may inadvertently be actuated which may also result in serious accidents.

- Correctly connect and secure the hoses and cables.
- Lay the hoses, cables and ropes so that they do not scrape, come under tension or become jammed or come into contact with other components (e.g. tractor tyres).
- Couple and connect the hoses and cables to the designated connections as described in the operating instructions.

7.1 Connecting machine to tractor

NOTICE

When the tractor and machine are in a horizontal position, the hitched mechanical connection devices (e.g. ball-head hitch) must be in a horizontal position $(+/-3^{\circ})$ with respect to the ground so as not to obstruct the operational swivel angle between the mechanical connection devices.



RP000-098 Example image

For version with "Drawbar eye"

WARNING! Increased risk of injury! Ensure that there is no one between the tractor and the machine while connecting the machine (especially while driving the tractor backwards).

- Reverse the tractor onto the drawbar until the drawbar eye of the machine has been inserted into the hitching device of the tractor.
- Shut down and safeguard the machine, see Page 27.
- Secure the hitching device according to the operating instructions of the tractor manufacturer.

For version with "Ball drawbar eye"

WARNING! Increased risk of injury! Ensure that there is no one between the tractor and the machine while connecting the machine (especially while driving the tractor backwards).

- Drive the tractor backwards onto the drawbar and move the ball-head hitch of the tractor under the ball-head attachment of the machine.
- Lower the drawbar using the support jack until the ball-head drawbar eye is positioned on the ball-head attachment.
- Shut down and safeguard the machine, see Page 27.
- Secure the hitching device according to the operating instructions of the tractor manufacturer.

7.2 Mounting the universal shaft on the tractor

<u> WARNING</u>

Risk of injury by failure to take account of the danger zone of the universal shaft

If the danger zone of the universal shaft is ignored, persons can be seriously hurt or killed.

▶ To avoid accidents, observe the danger zone of the universal shaft, see Page 19.

NOTICE

Changing the tractor

There is a risk of damaging the machine if the length of the universal shaft is not checked when the tractor is changed.

- ► To prevent damage to the machine, check the length of the universal shaft whenever you change tractors. Have it corrected by a KRONE service partner if necessary.
- ✓ The machine has been shut down and secured, see Page 27.





RPG000-096

Push the universal shaft (1) onto the tractor PTO shaft and secure against turning by attaching the supporting chain in a suitable location.

7.3 Connecting hydraulic hoses

🛝 WARNING

Risk of injury from escaping hydraulic oil

The hydraulic system operates at very high pressure. Escaping hydraulic oil may seriously injure skin, limbs and eyes.

- Prior to connecting the hydraulic hoses to the tractor, depressurise both sides of the hydraulic system.
- Depressurise the hydraulic system before you uncouple the hoses and work on the ► hydraulic system.
- When connecting the guick couplings, ensure that they are clean and dry.
- Check hydraulic hoses at regular intervals see Page 218 and replace them if they are damaged (e.g chafing areas or points of contact) or aged. The replacement lines must comply with the technical requirements of the device manufacturer.

NOTICE

Damage to the machine due to soiling of the hydraulic system

If foreign objects or liquids get into the hydraulic system, the hydraulic system may be severely damaged.

- When connecting the quick couplings, ensure that they are clean and dry.
- Check the hydraulic hoses for abrasion and pinch point and replace if required.



RPG000-117

() KRONE

Control units which can be locked in neutral position against unintentional operation must be used on the tractor.

To connect the hydraulic hoses (1) correctly, the hydraulic hoses (1) are marked with numbers.

Additional explanations of the markings on the handles can be found on the label (2) on the machine.

- Depressurise the tractor hydraulics.
- Shut down and safeguard the machine, see Page 27.
- Clean and dry the connections of the hydraulic quick connector.

Hydraulic connection for return to the tank

Connect the hydraulic hose (blue, T) with the depressurised return on the tractor.

Opening/closing the hydraulic connection for the tailgate

► Connect the hydraulic hose (red, 1+) to a single-acting control unit of the tractor.

Lifting/lowering hydraulic connection for pick-up and for swivelling blades in/out and for lifting/lowering blade cassette

► Connect the hydraulic hoses (yellow, 3+, 3-) to a double-acting control unit of the tractor.

7.4 Connecting hydraulic brake (export)

A hydraulic brake may be required on the machine to meet country specific standards. A brake valve is required on the tractor for the hydraulic brake. The corresponding hydraulic hose is connected to the brake valve on the tractor. The brake is activated by actuating the brake pedal.

- ✓ The machine has been shut down and secured, see Page 27.
- Connect the hydraulic hose of the hydraulic brake to the connection for the hydraulic brake on the tractor.

7.5 Connecting the road lighting

NOTICE

Short circuit caused by impurities and moisture in the plug connection

The machine may be damaged by a short circuit.

Make sure that the plugs and sockets are clean and dry.



BPG000-067

7.6 Mounting safety chain



The road travel lighting is connected by means of the enclosed 7-pin lighting cable (2).

- ✓ The machine has been shut down and secured, see Page 27.
- Connect the 7-pin plug of the lighting cable (2) to the 7-pin socket (1) of the machine.
- Connect the 7-pin plug of the lighting cable (2) to the 7-pin socket (3) of the tractor.
- Route the lighting cable (2) so that it does not come into contact with the tractor wheels or other moving parts of the machine.

7.6 Mounting safety chain

MWARNING

Risk of accident due to a incorrectly dimensioned safety chain

When using an incorrectly dimensioned safety chain, the safety chain may tear if the machine loosens unintentionally. This may result in serious accidents.

Always use a safety chain with a minimum tensile strength of 89 kN (20,000 lbf).



Risk of injury or damage to the machine due to incorrectly installed safety chain.

If the installed safety chain is too taut or too slack, the safety chain may tear. As a result, people may be seriously injured or the tractor and machine may be damaged.

Install the safety chain in such a way that, when cornering, it is not tensioned and does not come into contact with the tractor wheels or other parts of the tractor or machine.

INFO

The country-specific regulations for using the safety chain during transportation of the machine must be observed.

This safety chain is on the net storage container on the left side of the machine.

The safety chain serves as an additional safety precaution for trailed devices in case these come loose from the hitch during transport. Attach the safety chain with the respective mounting parts to the hitching device holder of the tractor or to another specified coupling point. The safety chain should have enough play when driving around curves.

✓ The machine has been shut down and secured, see Page 27.





RP000-104

• Mount the safety chain (1) on the machine.



BP000-106

▶ Install the safety chain (1) at a suitable position (for example: [I] or [II]) on the tractor.

7.7 Connecting the KRONE DS 100 operation unit

NOTICE

Short circuit caused by impurities and moisture in the plug connection

The machine may be damaged by a short circuit.

• Make sure that the plugs and sockets are clean and dry.



Tractors with integrated ISOBUS system



EQG003-125

✓ The machine has been shut down and secured, see Page 27.

Connection terminal to tractor

• Connect the 9-pin plug (1) of the terminal to the 9-pin socket (2) (In-cab).

Connection tractor to machine

INFO

The cable (5) can be ordered by quoting the order number 20 086 886 * .

- Connect the 9-pin plug (4) of the cable (5) to the 9-pin ISOBUS socket (3) of the tractor.
- Connect the 11-pin plug (6) of the cable (5) to the 11-pin socket (7) of the machine.



Tractors without ISOBUS system



EQG003-124

- ✓ The machine has been shut down and secured, see Page 27.
- ✓ The accessories kit B290 "KRONE tractor retrofitting" is mounted.

Connection terminal to tractor

Connect the 9-pin plug (1) of the terminal to the 9-pin socket (2) (In-cab).

Connection tractor to machine

INFO

The cable (5) can be ordered by quoting the order number 20 086 886 *.

- Connect the 9-pin plug (4) of the cable (5) to the 9-pin ISOBUS socket (3) of the tractor.
- Connect the 11-pin plug (6) of the cable (5) to the 11-pin socket (7) of the machine.

7.8 Connecting KRONE terminal DS 500

NOTICE

Short circuit caused by impurities and moisture in the plug connection

The machine may be damaged by a short circuit.

• Make sure that the plugs and sockets are clean and dry.



Tractors with integrated ISOBUS system



EQ003-251

✓ The machine has been shut down and secured, see Page 27.

Connection terminal to tractor

▶ Connect the 9-pin plug (2) of the cable (1) to the 9-pin socket (3) (In-cab).

Connection tractor to machine

INFO

The cable (6) can be ordered by quoting the order number 20 086 886 *.

- ► Connect the 9-pin plug (5) of the cable (6) to the 9-pin ISOBUS socket (4) of the tractor.
- Connect the 11-pin plug (7) of the cable (6) to the 11-pin socket (8) of the machine.



Tractors without ISOBUS system



EQ003-252

- ✓ The machine has been shut down and secured, see Page 27.
- ✓ The accessories kit B290 "KRONE tractor retrofitting" is mounted.

Connection terminal to tractor

Connect the 9-pin plug (2) of the cable (1) to the 9-pin socket (3) (In-cab).

Connection tractor to machine

INFO

The cable (6) can be ordered by quoting the order number 20 086 886 *.

- Connect the 9-pin plug (5) of the cable (6) to the 9-pin ISOBUS socket (4) of the tractor.
- Connect the 11-pin plug (7) of the cable (6) to the 11-pin socket (8) of the machine.

7.9 Connecting the KRONE ISOBUS terminal (CCI 800, CCI 1200)

NOTICE

Short circuit caused by impurities and moisture in the plug connection

The machine may be damaged by a short circuit.

Make sure that the plugs and sockets are clean and dry.

INFO

To mount the terminal in the tractor cabin, observe the provided operating instructions of terminal.

7.9 Connecting the KRONE ISOBUS terminal (CCI 800, CCI 1200)



Tractors with integrated ISOBUS system



EQ001-173

✓ The machine has been shut down and secured, see Page 27.

Connection terminal to tractor

- Connect the 12-pin plug (2) of the cable (3) to the 12-pin socket (1) of the terminal.
- ► Connect the 9-pin plug (4) of the cable (3) to the 9-pin socket (5) (In-cab).

Connection tractor to machine

INFO

The cable (8) can be ordered by quoting the order number 20 086 886 *.

- Connect the 9-pin plug (7) of the cable (8) to the 9-pin ISOBUS socket (6) of the tractor.
- Connect the 11-pin plug (9) of the cable (8) to the 11-pin socket (10) of the machine.



Tractors without ISOBUS system



EQ001-181

- ✓ The machine has been shut down and secured, see Page 27.
- ✓ The accessories kit B290 "KRONE tractor retrofitting" is mounted.

Connection terminal to tractor

- Connect the 12-pin plug (2) of the cable (3) to the 12-pin socket (1) of the terminal.
- Connect the 9-pin plug (4) of the cable (3) to the 9-pin socket (5) (In-cab).

Connection tractor to machine

INFO

The cable (8) can be ordered by quoting the order number 20 086 886 *.

- ► Connect the 9-pole plug (7) of the cable (8) to the 9-pole ISOBUS socket (6) of the tractor.
- Connect the 11-pole plug (9) of the cable (8) to the 11-pole socket (10) of the machine.

7.10 Connecting foreign ISOBUS terminal

NOTICE

Short circuit caused by impurities and moisture in the plug connection

The machine may be damaged by a short circuit.

Make sure that the plugs and sockets are clean and dry.

7.11 Connecting joystick



INFO

To mount the terminal in the tractor cabin, observe the provided operating instructions of terminal.



EQ001-146

✓ The machine has been shut down and secured, see Page 27.

Connection tractor to machine

- Connect the 9-pole plug (5) of the cable (2) to the 9-pole ISOBUS socket (1) of the tractor.
- Connect the 11-pole socket (4) of the cable (2) to the 11-pole socket (3) of the machine.

7.11 Connecting joystick

INFO

Follow the supplied joystick operating instructions for attachment of the joystick in the tractor cabin.


KRONE ISOBUS terminal on tractors with integrated ISOBUS system



EQ001-150

- ✓ The machine has been shut down and secured, see Page 27.
- Connect the 9-pin plug (2) of the cable (1) to the 9-pin socket (3) of the joystick.
- Connect the 9-pin plug (4) of the joystick to the 9-pin socket (5) (In-cab).



7.11 Connecting joystick



KRONE ISOBUS terminal on tractors without integrated ISOBUS system

EQ001-151

- ✓ The machine has been shut down and secured, see Page 27.
- ✓ The accessories kit B290 "KRONE tractor retrofitting" is mounted.
- Connect the 9-pin plug (2) of the cable (1) to the 9-pin socket (3) of the joystick.
- Connect the 9-pin plug (4) of the joystick to the 9-pin socket (5) (In-cab).



7.12 Connecting the camera to the KRONE ISOBUS terminal CCI 800 or **CCI 1200**



EQ000-212

(1) KRONE

- Insert the plug (4) on the camera (2) cable (3) into the connection C (1) of the KRONE ► ISOBUS terminal CCI 800 or CCI 1200.
- To connect the plug (4) correctly, ensure that it is aligned with the marked points (5).

7



8 Operation



Risk of injury due to non-observance of relevant safety notices

If the relevant safety notices are not observed, persons may get seriously injured or killed.

To avoid accidents, the basic safety instructions must be read and observed, see Page 15.

MWARNING

Risk of injury due to non-observance of safety instructions

If the relevant safety routines are not observed, persons may be seriously injured or killed.

▶ The safety routines must be read and observed to avoid accidents, see Page 27.



Risk of injury due to unpredictable movement of the round bales when the machine is operating on a slope

If round bales are deposited on a slope, they may start moving on their own. Once round bales have started moving, their weight and cylindrical shape may cause serious accidents and injure people.

- On slopes, deposit round bales in manual mode only.
- On slopes, always deposit round bales in such a way that they cannot start moving on their own.

8.1 Preparation before baling

- ✓ The pick-up is in working position, see Page 84.
- ✓ The crop press roller unit has been correctly set according to the amount of crops, see Page 87.
- ✓ The net has been correctly inserted, see Page 94.
- ✓ The baling pressure has been set. For version with "operation unit DS 100": see Page 114 For the remaining terminals: see Page 160
- ✓ The bale diameter has been set.
 For version with "operation unit DS 100": see Page 112
 For the remaining terminals: see Page 145
- ✓ The required cutting length has been set, see Page 202.
- ✓ The customer counter has been set to 0, see Page 172.
- ✓ The tailgate is closed.
- ✓ The working screen has been selected, see Page 143.

8.2 Filling the bale chamber

NOTICE

Machine damage due to machine overload

Too firm or too large round bales can damage the machine and reduce the service life considerably. In the event of an overload, forced tying is automatically actuated which is saved on the terminal.

- Press only round bales which do not exceed the maximum set bale diameter.
- Observe the following information on the even filling of the bale chamber.

NOTICE

Baling belts damaged by barrel-shaped round bales

Unevenly shaped and compressed round bales may damage the baling belts.

- ▶ Bale only evenly shaped and compressed round bales.
- Observe the following information on the even filling of the bale chamber.

To attain a consistent bale density inside the round bale, the bale chamber must be filled evenly. The appropriate swath width is important for this. The swath width is optimal when the swath has exactly the same width as the bale chamber.

Procedure



RP000-736

To obtain an evenly shaped round bale, the right and left sides of the swath must be changed quickly while crops are being picked up.

At the beginning, change the side every **3 m** until the bale diameter is approx. 80 cm.

Next, crops must be picked up on each side approx. every **10 ... 20 m**. The crops will then be distributed evenly on the right and left sides of the bale chamber.

8.2 Filling the bale chamber



While crops are being picked up, it is advisable to monitor the baling belts in the machine:

- If the baling belts move to the left, steer the tractor to the right to pick up the crops on the left side of the bale chamber.
- If the baling belts move to the right, steer the tractor to the left to pick up the crops on the right side of the bale chamber.
- At the start of the baling process change quickly from the left to the right side of the swath so that crops can be fed alternately on the left and right sides of the bale chamber. On each side pick up crops approx. 3 m long (Section (X)). Perform this quick change until a bale diameter of approx. 80 cm has been reached.
- ▶ Drive approx. **10–20 m** and pick up crops on one side of the swath.
- Quickly change the side, drive on the other side approx. **10–20 m** and pick up crops.
- Repeat the procedure until the required bale diameter has been reached and a tying cycle can be actuated.

If swaths are too wide

The pressed round bales do not have an exact shape. Also the round bale is frayed on the sides and difficult to eject from the bale chamber.

- Make the swaths narrower on the field.
- Reduce the baling pressure, *see Page 197*.

If swaths are too narrow

- Also retain the procedure for driving on alternate sides.
- Drive quickly over the swath.
- Do not drive in wavy lines.
- ▶ If the baling belts do not run smoothly, reduce the PTO speed.

If the swath is small and flat

- Reduce the PTO speed.
- Increase the driving speed.

For short and brittle straw

- Reduce the baling pressure. For version with "operation unit DS 100":see Page 114. For the remaining terminals: see Page 160.
- Reduce the number of blades in the cutting unit or completely swivel out the blades, see Page 89.
- Start the tying cycle earlier than indicated.
- To largely prevent short, brittle straw from falling out of the bale chamber when driving from one swath to the next swath, switch off the PTO shaft in the meantime.

Driving speed

KRONE recommends a driving speed of 5 ... 12 km/h.

The driving speed while working must be adapted to the following circumstances:

• Type of crop

KRONE

- Moisture content of crops
- Swath height
- Selected cutting length
- Ground conditions

Additional tips for filling the bale chamber

- Reduce the driving speed at the end of the filling process to obtain consistent bale sizes.
- Start the tying cycle at the end of the filling process. This will prevent crops from getting between the net layers.
- The shorter the crops in the bale chamber, the greater the friction on the side walls. As such, the overload clutch can engage more frequently. Moreover, short crops can be compressed more easily. That's why the baling pressure can be lowered with the blades swivelled in without the bale density being reduced, *see Page 197*. The response of the overload clutch can be reduced in this way.
- Do not operate the machine for too long a time with empty bale chamber.
- After the tying mechanism has been actuated 3 times, the accumulator of the machine is empty and must be filled again, *see Page 249*.

8.3 Completing the baling process, starting tying cycle and ejecting round bales

- ► For version with "Operation unit DS 100": Read off the status of the bale chamber filling on the warning lights of the DS 100, see Page 107.
- For the remaining terminals: Read off the status of the bale chamber filling on the terminal, see Page 139.
- ► Stop the tractor.
- Start the tying process in automatic mode or start it in manual mode.
- ► Wait until the tying process is complete.
- Open the tailgate and eject the round bale.
- ► Close the tailgate.
- ► Start the next baling process.

8.4 Reducing the pressure on the side walls of the bale chamber

If very heavy crops without structure are picked up, the round bales may become very hard and press on the side walls of the machine. Then reliable rotation of the round bale can be increased in the bale chamber by taking the following measures:

- ► To reduce the pressure on the side walls, do not drive too far to the right or left.
- Take the outer blades out of the cutting unit or completely switch off the cutting unit.
- ▶ Reduce the baling pressure, see Page 197.

8.5 Operating the support jack

INFO

In order to increase the base of the support jack when the ground is soft, use a suitable support.



The support jack is used to keep the machine stable when it is not connected to the tractor. The support jack must be used whenever the machine is parked.

- ✓ The machine has been shut down and secured, see Page 27.
- ✓ The machine is connected to the tractor, see Page 60.



RPG000-063

Moving the support jack into support position

- ▶ Pull the handle (5) and fold the support jack (2) downwards.
- ► Turn the crank handle (1) several revolutions anti-clockwise.

WARNING! Crush hazard due to the support jack! Keep hands and feet out of the danger zone of the support jack.

- Pull out the securing pin (4), extend the parking support (2) and secure the position using the securing pin (4).
- Turn the support jack (2) anti-clockwise firmly down onto the ground using the crank handle (1) until the drawbar is relieved.

Moving the support jack into transport position

► Turn the crank handle (1) several revolutions clockwise until the support plate (3) is relieved.

WARNING! Crush hazard due to the support jack! Keep hands and feet out of the danger zone of the support jack.

- Pull out the securing pin (4), push in the support jack (2) and secure the position with the securing pin (4).
- ► Turn the support jack (2) clockwise all the way up using the crank handle (1).
- ► Fold the side support jack (2)upwards and engage it.
- ► Turn the crank handle (1) towards the machine so that it cannot touch the tractor wheel.

8.6 Using the stop cock of the tailgate

<u> WARNING</u>

Risk of injury if the stop cock of the tailgate is opened

When working on or underneath the opened tailgate or inside the bale chamber, the tailgate may drop down in an uncontrolled manner if the stop cock is opened. As a result, people may be seriously injured or killed.

Always close the stop cock when carrying out work with the tailgate open.

Operation 8

(¹) KRONE

Releasing/applying the parking brake 8.7



RPG000-014

The tractor supplies the machine hydraulics via hydraulic hoses. The tailgate stop cock (1) is a safety component which prevents the tailgate from unintentionally closing. The tailgate stop cock (1) must be closed if working in the bale chamber or on the tailgate.

The tailgate stop cock (1) is located at the front of the machine near the support jack.

✓ The machine has been shut down and secured, see Page 27.

Opening the stop cock

- ► Turn the stop cock (1) into position (I).
- ➡ The tailgate can be closed.

Closing the stop cock

- ► Turn the stop cock (1) into position (II).
- ➡ The tailgate cannot be closed.

8.7 Releasing/applying the parking brake



RPG000-131

The parking brake (2) is located on the front side of the machine on the drawbar. The parking brake (2) is used to secure the machine from unintentionally rolling away, .

In order to prevent the machine from rolling away, also use the wheel chocks, see Page 83.

Applying the parking brake (2)

Apply the parking brake (2) until the resistance has increased noticeably.



Releasing the parking brake (2)

• Push in the key (1) and press parking brake (2) all the way down.

Attaching safety cable of the parking brake



RP000-399

The safety cable (1) applies the parking brake (3) if the machine breaks away from the tractor while it is driving.

- To attach the safety cable (1) to the machine, attach the safety cable (1) to the parking brake (3). To do this, pull the safety cable (1) through the smaller loop of the safety cable (1) and through the ring (2).
- To attach the safety cable (1) to the tractor, attach the other end of the safety cable (1) to a suitable point at the back of the tractor.
- Ensure that the safety cable (1) cannot slip or become detached.

8.8 Using ladders for the tying system



RP000-812

The ladders (1) and (3) are located at the front of the machine to facilitate tying and to insert the net more easily.

When driving on roads and working in fields, the ladders (1) and (3) must be folded up to prevent damage to the tractor tyres and to the ladders themselves.

Folding the ladder (1) up and down (RH)

- Folding up: Fold the lowest step of the ladder (1) upwards in the direction of the arrow until it engages.
- Folding down: Pull the knob (2) and fold the ladder downwards against the direction of the arrow.



Folding the ladder (3) up and down (LH)

- Folding up: Pull the knob (4) and fold the side ladder (3) upwards to the left in the direction of the arrow until it engages.
- ► Folding down: Pull the knob (4) and fold the side ladder (3) downwards against the direction of the arrow until it engages.

8.9 Fitting wheel chocks



RPG000-012

The wheel chocks (1) secure the machine against rolling away. 2 wheel chocks are affixed to the machine.

For "Parking brake" version: In order to prevent the machine from rolling away, use the parking brake in addition to the wheel chocks (1), see Page 81.

- ✓ The machine is parked on a stable, horizontal and even surface.
- ✓ The machine has been shut down and secured, see Page 27.
- To dismount the wheel chocks (1) from the machine, press the supports (2) down, pull the wheel chocks (1) upwards, and remove them.



RPG000-180

Place the wheel chocks (1) so tightly in front of and behind the same wheel that the machine is prevented from rolling away.

8.10 Removing/mounting the safety device which prevents unauthorised use

The safety device is used to prevent unauthorised use when the machine has been switched off.

✓ The machine has been parked, see Page 190.



For version with "ball-head attachment" or "drawbar eye attachment"



KS000-414

I Version with ball-head attachment

II Version with drawbar eye attachment

Removing

Remove the padlock (1), the latch (2) and the bracket (3) and take them with you.

Mounting

Mount the bracket (3) with the latch (2) and secure with the padlock (1) and keep the key in a safe place.

8.11 Pick-up

8.11.1 Bringing the pick-up to transport/working position

Working position

WARNING! Risk of injury due to falling pick-up! While the pick-up is being lowered, remove people from the movement range of the pick-up.

► For "Operation unit DS 100" version: To preselect the pick-up, press the 😥 key, see

Page 107.

- \Rightarrow The indicator lamp above the key lights up.
- ► For the other terminals: To preselect the pick-up, press the 1 key on the terminal, see

Page 137.



To lower the pick-up into the working position, actuate the control unit on the tractor (yellow, 3+).

(¹) KRONE

Transport position

WARNING! Risk of injury due to rising pick-up! While the pick-up is being raised, tell people to leave the movement range of the pick-up.

► For "Operation unit DS 100" version: To preselect the pick-up, press the 😥 key, see

Page 107.

- \Rightarrow The indicator lamp above the key lights up.
- ► For the other terminals: To preselect the pick-up, press the terminal, see

Page 137.

- \Rightarrow The key switches to 🔀
- To lift the pick-up into the transport position, actuate the control unit on the tractor (yellow, 3+).

8.11.2 Setting the pick-up working height



RPG000-151

The working height of the pick-up (3) must be set so that the distance between the tines and the ground is approx. **20-30 mm**. Also the working height of the pick-up (3) must be adjusted to the ground conditions.

✓ The drawbar height has been set correctly, see Page 56.

Make the following setting on the right and left sides of the pick-up in the same way:

- ► Lift the pick-up (3) hydraulically, see Page 84.
- Shut down and safeguard the machine, see Page 27.
- Remove the linch pin (2).
- Push the perforated bar (1) to the required position and secure it with the linch pin (2).
- ▶ Lower the pick-up (3) hydraulically, see Page 84.
- Shut down and safeguard the machine, see Page 27.
- Check whether the distance between the tines and the ground is approx. **20-30 mm**.
- ▶ If required, re-adjust the perforated bar (1).



8.11.3 Activating/deactivating the bearing pressure relief for the pick-up



RPG000-153

To be able to negotiate uneven ground better, the pick-up is relieved on the right and left sides of the machine with the aid of the spring (2). This bearing pressure relief function can be activated or deactivated.

KRONE recommends activating the bearing pressure relief for the pick-up to protect the sward and to protect the machine from damage.

Position	Explanation	
1	Bearing pressure relief for the pick-up activated	
II	Bearing pressure relief for the pick-up deactivated, the linch pin (1) is located in the loss protection borehole.	

Deactivating the bearing pressure relief

- ▶ Move the pick-up into the transport position, see Page 84.
- Switch off the tractor, remove the ignition key and take it with you.

Make the following setting on the right and left sides of the machine in the same way:

- Dismount the linch pin (1) from position (I) and mount in position (II).
- The spring (2) has been relieved and therefore the bearing pressure relief for the pick-up has been deactivated. The spring (2) and the bushings can move freely on the shaft.

If the bearing pressure relief has been deactivated, the height of the pick-up can also be set, see Page 87.

Activating the bearing pressure relief

- ▶ Move the pick-up into the transport position, see Page 84.
- Switch off the tractor, remove the ignition key and take it with you.

Make the following setting on the right and left sides of the machine in the same way:

- ▶ Dismount the linch pin (1) from position (II) and mount in position (I).
- The spring (2) has been tensioned and therefore the bearing pressure relief for the pick-up has been activated.

2 positions can be selected in position (I):

- Borehole with notch: bearing pressure relief lower
- · Borehole without notch: bearing pressure relief higher

MKRONE

Crop collection without using guide wheels

If the bearing pressure relief for the pick-up has been deactivated, the working height of the pick-up can be set independently of the guide wheels.

This is suitable for uneven ground and light crops.



RP000-801

Make the following setting on the right and left sides of the machine in the same way:

- Move the pick-up into the transport position, see Page 84.
- Switch off the tractor, remove the ignition key and take it with you.
- Push up the bushing (3) and insert the linch pin (1) into one of the boreholes (2) and secure.

If the gaps between the boreholes (2) are too great and therefore the working height cannot be set exactly enough:

• Use the borehole (4) without machined groove in the bushing (3).

The higher the borehole, the higher the pick-up has been set.

8.12 Crop press roller unit

MWARNING

Risk of injury if the machine is used without a crop press roller unit

The crop press roller unit is used for accident protection! If the machine is operated without a roller crop guide, people can be seriously injured or killed.

▶ Never operate the machine without a crop press roller unit.

8.12.1 Setting the crop press roller unit



RPG000-110

The crop press roller unit (3) guides the crops at the intake via the pick-up.



The height of the crop press roller unit (3) must be set so that the operating crop press roller (2) continuously touches the swath.

Adjusting the height of the crop press roller unit

Make the following setting on the right and left side of the pick-up in the same way:

- ✓ The machine has been shut down and secured, see Page 27.
- Remove the linch pin (5).
- Hook in the chain (1) higher or lower according to the swath: In doing so, first thread the load-bearing chain link, then thread the chain overhang up to 2 more times.
- Mount the linch pin (5).

If the linch pin (5) is not required, the linch pin (5) can be inserted into the borehole (4).

8.12.2 Removing/mounting the baffle sheet on the crop press roller unit

In operation the baffle sheet must have been mounted on the crop press roller unit. The baffle sheet on the crop press roller unit can be briefly removed in the event of crop blockages.



Removing crop blockages: see Page 105

RPG000-152

✓ The machine has been shut down and secured, see Page 27.

Dismounting

- ▶ Remove the linch pins (3) from the right and left sides of the pick-up.
- Push the baffle sheet (1) to one side and remove.

Mounting

Place the baffle sheet (1) on the crop press roller (2) and secure with the linch pins (3) on the right and left sides of the pick-up.



8.13 Cutting unit

8.13.1 Lifting/lowering blade cassette

M WARNING

Crush hazard due to lowering or lifting of the blade cassette

Lifting and lowering the blade cassette may crush body parts.

- Before lifting or lowering the blade cassette, ensure that there is nobody inside the danger zone of the blade cassette.
- Before doing any work on the blade cassette, shut down and safeguard the machine, see Page 27.

Lowering the blade cassette

When the blade cassette is lowered, the blade cassette is moved into maintenance position. In a closed sequence, first the blade cassette is lowered and then the blades swivel out (deactivated). This maintenance position is used, for example, to change the blades or to remove crop blockages.

For "Operation unit DS 100" version: To preselect the blade cassette, press the

key, see Page 107.

- \Rightarrow The indicator lamp below the key lights up.
- For the other terminals To preselect the blade cassette, press the x key on the

terminal, see Page 137.

 \Rightarrow The key switches to 12

- To lower the blade cassette, actuate and hold down the control unit in the tractor (yellow, 3-).
- The blade cassette moves into maintenance position: The blade cassette is lowered and the blades are swivelled out (deactivated).
- For version with "Operation unit DS 100": The warning lamp / below the key

is lit as soon as the blade cassette and the blades are in maintenance position.

For the remaining terminals: is lit in the status line as soon as the blade cassette

and blades are in maintenance position.

NOTE! To lower the blade cassette, so that the maintenance position can be reached, do not move the control unit in the tractor into float position. When the control unit is put to floating position, only the blade cassette is lowered, the blades remain in the feed channel.



Lifting the blade cassette

When the blade cassette is raised, the blade cassette and blades are put into operation again. The number of blades set beforehand is swivelled in (activated).

For "Operation unit DS 100" version: To preselect the blade cassette, press the

key, see Page 107.

- ⇒ The indicator lamp below the key lights up.
- For the other terminals To preselect the blade cassette, press the x key on the

terminal, see Page 137.

- \Rightarrow The key switches to **1**
- To raise the blade cassette, actuate and hold down the control unit in the tractor (yellow, 3+).
- The blade cassette is raised and the number of blades set beforehand is swivelled in (activated).
- For version with "Operation unit DS 100": The warning lamp / below the key

goes out as soon as the blade cassette has been raised and the number of blades set

beforehand has been swivelled in.

• For the remaining terminals: or is lit in the status line as soon as the blade

cassette has been raised and the number of blades set beforehand has been swivelled in.

8.13.2 Swivelling in/out blades

The blades can be swivelled in/out via the terminal and the tractor hydraulics without lowering the blade cassette.

Swivelling in (activating) blades

- For "Operation unit DS 100" version: To preselect the blades, press the 4 key.
 - ⇒ The indicator lamp under the key is lit until the blades have been swivelled in.
- For the other terminals: To preselect the blades, press the x key.



Press the t key.

The **1** key is displayed with a green arrow **1** wutil the blades are swivelled in.



To swivel in (activate) the blades, actuate and hold down the control unit in the tractor (yellow, 3+).

The following prompt to move the blades via the tractor hydraulics appears if the control unit is **not** pressed after approx. 3 seconds:

lcon	Explanation
522014-7	Moving blades
*	

For the "DS 100 operation unit" version: As soon as the blades are swivelled in (activated), the indicator lamp above the field above the key lights up as a status display. All blade groups were swivelled out in the mechanical blade group control system if the indicator lamp above the field of the key does not shine, *see Page 92*.

For the remaining terminals:

is lit in the status line as soon as the blades have been

swivelled in (activated).

lf

is displayed in the status line, all blade groups were swivelled out with the mechanical

blade group control system, see Page 92.

Swivelling out (deactivating) blades

- For "Operation unit DS 100" version: To preselect the blades, press the key.
 - \Rightarrow The indicator lamp under the key is lit until the blades have been swivelled out.
- For the other terminals: To preselect the blades, press the x key.
 - \Rightarrow The **t** key appears additionally on the display.
- Press the **1** key.
 - \Rightarrow The **t** key is displayed with a green arrow **t** which until the blades are swivelled out.
- To swivel out (deactivate) the blades, actuate and hold down the control unit in the tractor (yellow, 3-).

The following prompt to move the blades via the tractor hydraulics appears if the control unit is **not** pressed after approx. 3 seconds:

lcon	Explanation
522014-7	Moving blades
*	

For "DS 100 operation unit" version: As a status display, the indicator lamp does not shine above the field above the key as soon as the blades are swivelled out (deactivated).



For the remaining terminals:



is lit in the status line as soon as the blades have been

swivelled out (deactivated).

8.13.3 Swivelling blade groups in/out

The blades of the cutting unit can be individually swivelled in or out in 2 groups or both groups can be completely swivelled in or out. The number of blades used determines the cutting length of the crops, *see Page 202*.

- ✓ The pick-up is fully raised in transport position, see Page 84.
- ✓ The blades have been swivelled out (inactive), see Page 90.
- ✓ The machine has been shut down and secured, see Page 27.



RP000-802

Position	Explanation	
1	0 blades	
II	8 blades as a group	
III	9 blades as a group	
IV	17 blades	

- ▶ Remove the maintenance key (1) which is attached near the blade cassette.
- Using the maintenance key (1), rotate the blade control shaft (3) in the direction of the arrow into the required position.
- Ensure that the pointer (2) is pointing towards the required position.
- ✤ 8 blades are illustrated here.

If individual blades did not swivel in

The following steps must be performed if individual blades did not swivel in after the blade groups were mechanically or hydraulically swivelled in.

(I) KRONE

Move the blades and the blade cassette into the maintenance position as follows:

► For "Operation unit DS 100" version: To preselect the blade cassette, press the

key, see Page 107.

- \Rightarrow The indicator lamp below the key lights up.
- For the other terminals To preselect the blade cassette, press the key on the

terminal, see Page 137.

- \Rightarrow The key changes to
- ► To lower the blade cassette, actuate the control unit on the tractor (yellow, 3-).
- The blades and blade cassette are in maintenance position: The blades have been swivelled out and the blade cassette has been lowered.



RPG000-154

- ✓ The tailgate is opened and secured, see Page 80.
- Clean the blades (3) and the blade cassette (1) from the rear side of the machine. In particular, clean the area (2) on the cutting edge of the blade (3).
- Swivel the blade groups back into the working position.
- If required, move individual blades, which have not swivelled in, into the working position using a suitable tool, e.g. a plastic hammer, by tapping the back of the blade.

8.13.4 Storing blades on the blade support

The blade support on the left and/or right side of the machine is used to suspend a set of blades for storage. Here, you can store either the new or the used set of blades.



For "Blade support left" version, for "Blade support right" version



RPG001-242

The blade support (1) sits on the left or right side of the machine, under the side hood. Here, the blade support (1) is shown on the left-hand side as an example.

- ✓ The machine has been shut down and secured, see Page 27.
- Remove the linch pin (2).
- Dismount the bolt (4) and the spring cotter pin (3).
- Push the blades onto the blade support (1) for storage.
- Mount the bolt (4) and secure it by means of the spring cotter pin (3).
- Mount the linch pin (2).

8.14 Net wrapping

8.14.1 Inserting the net roll



RP000-722



Position	Explanation
Position (I)	The pressure pipe (1) and the net support / holder (2) have been folded in.
Position (II)	The pressure pipe (1) and the net support / holder (2) have been folded out. A net roll can be inserted.

- ✓ The machine has been shut down and secured, see Page 27.
- ▶ Using the handle, fold the pressure pipe (1) upwards in the direction of the arrow.
- To release the net support / holder (2), move the lever (3) to the right in the direction of the arrow.
- ► At the same time fold the net support / holder (2) downwards in the direction of the arrow.
- Dismount one of the two alignment sheets (4) to make it easier to insert the net roll in the next step.



RPG001-243

On the right and left side of the machine there is a net roll support behind the side hood. This support can be used to stow a net roll (1) in the packaging.

The net roll (1) is secured with the straps (2).

- ▶ Lift the net roll (1) off the net roll support and lean it on the right or left side on the net holder.
- Stow the straps (2) on the net roll support such that they cannot get into machine movements.



RP000-723

- Slip the net roll (3) sideways on the net holder (2).
- Ensure that the net roll (3) rotates in the direction of the arrow and can be pulled out from below as illustrated.
- To centre the net roll (3), insert the alignment sheets (1) identically on both sides of the net support / holder (2). Ensure that a gap of approx. 2 mm is maintained on both sides between the net roll (3) and alignment sheet (1).





INFO

Ensure that the net holder (2) is folded up again after the net has been loaded. This is described in the next chapter, *see Page* 97.

8.14.2 Inserting the net



RP000-724

The net path (3) is shown in red on the drawing.

- ✓ The machine has been shut down and secured, see Page 27.
- Unwind approx. 2 metres forwards off the net roll (1).
- Route the net underneath the yellow rubber roll (4).
- ▶ Place the net over the deflection roll (2).
- ▶ Place the end of the net (7) between the spreading roll (5) and net pusher (8).

() KRONE

INFO

A length of approx. 2 metres is reached when the net is pulled upwards off the net roll as far as the opened front hood and back.

To make it easier to thread the net, you can tie a knot in the end of the net.

Folding back net support / holder



RP000-946

Position	Explanation
Position (I)	The pressure pipe (9) and the net support / holder (10) for insertion of the net have been folded out.
Position (II)	The pressure pipe (9) and the net support / holder (10) have been folded in. When the net roll and the net have been completely inserted, the tying system is now ready for operation.

- ► To release the net support / holder (10), move the lever (11) to the right.
- ► At the same time fold the net support / holder (10) upwards in the direction of the arrow.

Actuating the net pusher (8)

- Move the net pusher (8) several times up and down in the direction of the arrow so that the net is pushed under the spreading roll (5).
- Ensure that approx. **10 cm** of the net protrudes between the rubber pads (6).
- After the last pushing movement, push the net pusher (8) back into the upper position.

If there is still net under the net roll

This surplus net is shown in the area (12).

▶ Roll the net back onto the net roll and lightly tension the net.

WARNING! Risk of injury to fingers! Always use the handle to move the pressure pipe (9)!

 Using the handle, fold the pressure pipe (9) downwards in the direction of the arrow onto the inserted net roll.



8.14.3 Cutting the net

For version with "Pivoted wrapping and tying material supply"

If the start of the net roll is damaged, this damaged part must be cut off. The installed blades on the machine can be used for this purpose.



RPG000-188

- ✓ The machine has been shut down and secured, see Page 27.
- Place the net in the notches (1) and pull the net in the direction of the arrow.
- ➡ The net is cut off by the installed blades in the notches (1).
- Dispose of the net remainders properly.

8.14.4 Using pivoted wrapping and tying material supply

For version with "Pivoted wrapping and tying material supply"

Fitting pivoted wrapping and tying material supply



RPG000-166

A new net roll can be entrained during operation on the pivoted wrapping and tying material supply (1) on the left side of the machine under the side hood. The net roll can be placed on the pivoted wrapping and tying material supply with little effort.

- ✓ The machine has been shut down and secured, see Page 27.
- ✓ The left side hood is open.
- Pull the handle (2) and manually guide the pivoted wrapping and tying material supply (1) and swivel out to the side.

(¹) KRONE



RP000-828

- Lean a new net roll (3), including protective sleeve, on the wrapping and tying material supply (1) swivelled out to the side (Position I).
- Ensure that the net roll was rotated in the correct direction (4).
- Push the net roll (3) in the direction of the arrow onto the wrapping and tying material supply (1) (Position II).
- Using the handle (2), manually guide the wrapping and tying material supply (1) and swivel back onto the machine.

Changing the net roll

The new net roll can be pushed with little effort from the pivoted wrapping and tying material supply onto the net support / holder on the tying system.

Beforehand prepare the net support / holder on the tying system as follows:



RP000-722

Position	Explanation
Position (I)	The pressure pipe (1) and the net support / holder (2) have been folded in.
Position (II)	The pressure pipe (1) and the net support / holder (2) have been folded out. A net roll can be inserted.

- ✓ The machine has been shut down and secured, see Page 27.
- ▶ Using the handle, fold the pressure pipe (1) upwards in the direction of the arrow.
- To release the net support / holder (2), move the lever (3) to the right in the direction of the arrow.
- At the same time fold the net support / holder (2) downwards in the direction of the arrow.
- Dismount one of the two alignment sheets (4) to make it easier to insert the net roll in the next step.





RP000-829

- ✓ The pivoted wrapping and tying material supply (1) with the new net roll (2) has been swivelled out to the side (Position I).
- ▶ Pull the knob (4) and swivel the retaining clip (3) downwards.
- ▶ Dismount the alignment sheet (6) from the net support / holder (5).
- Push the net roll (2) in the direction of the arrow onto the net support / holder (5) (Position II).

For the following steps for inserting the net roll and for inserting the net, see Page 94 and see Page 96.

8.15 Twine tying

For the "Net wrapping and twine tying" version

8.15.1 Connecting spools of twine with each other

NOTICE

Damage to the machine due to soiling of the components of twine tying system

If the twine or components of the twine tying are soiled by oil or lubricating grease, the machine may suffer damager.

- Cut off any soiled section of twine or use a new twine spool.
- Clean the components of the twine tying before inserting the twine.





RPG000-201

Producing tying twines 1 and 2

The twine tying system of the machine works with 2 tying twines which are tied around the round bale. Before the tying twines are inserted into the machine, the spools of twine (2) in the twine storage box (1) are knotted together in the following way.

- ✓ The machine has been shut down and secured, see Page 27.
- ✓ The right side hood is open.
- Thread the twine front end of spool of twine 1.6/2.6 through the lateral eyelet (3) and connect it with a reef knot (4) to the twine end of spool of twine 1.5/2.5.
- ▶ Using the same procedure (see figure above), also connect the adjacent spools of twine.
- Lead the twine front end of spool of twine 1.1/2.1 through the lateral eyelet (3) out of the twine storage box (1).
- Shorten the twine ends of all reef knots to X=15 ... 20 mm.

8.15.2 Inserting tying twine

- ✓ The machine has been shut down and secured, see Page 27.
- ✓ The spools of twine are connected with each other in the twine box, see Page 100.





RP001-027

The tying twines (1) and (2) are coloured in the figures below:

- Yellow: Bottom tying twine (1) from the bottom row of the twine box
- Red: Top tying twine (2) from the top row of the twine box
- Using your fingers, loosen the spring plates (5) slightly so that the tying twines can be threaded through them.
- Route the tying twines (1) and (2) through the eyelets (4) out of the twine box (3) to the outside.



RP001-028

▶ Route the tying twines (1) and (2) through the eyelets (6), (7), (8) and (9).

For assistance, the eyelets on the machine are marked with 1 and 2.

Operation 8

Twine tying 8.15





RP001-034

Bottom tying twine (1)

- After the eyelet (10), route the tying twine (1) around the sensor roll (11) and through the eyelet (12).
- Swivel the brake plate of the twine brake (14) to the side.
- ▶ Thread the tying twine (1) from above through the eyelet (15).
- Route the tying twine (1) through the guide tube (13) to the centre of the machine, leaving about 15 cm of excess thread at the end.
- Put the brake plate of the twine brake (14) back onto the eyelet (15), so that the twine (1) is pinched.

Top twine (2)

- After the eyelet (16), route the tying twine (2) around the sensor roll (17) and through the eyelet (18).
- Swivel the brake plate of the twine brake (20) to the side.
- ▶ Thread the tying twine (2) from above through the eyelet (21).
- Route the tying twine (2) through the guide tube (19) to the centre of the machine, leaving about 15 cm of excess thread at the end.
- Put the brake plate of the twine brake (20) back onto the eyelet (21), so that the twine (2) is pinched.

To adjust the twine tension on the twine brake see Page 199.



8.15.3 Swivelling the twine box to and fro



RPG000-202

The twine box (1) sits on the right side of the machine. To carry out maintenance and adjustment work on the right-hand side of the machine, you can swivel the twine box (1) forward.

- ✓ The machine has been shut down and secured, see Page 27.
- ▶ To swivel the twine box (1) forward, pull and turn the unlocking handle (2) so that it locks.



RP001-032

To secure the twine box (1) in the unfolded position, insert the wire bracket (3) from the mounting bracket (4) into the borehole (2).

8.16 Open/close tailgate

<u> WARNING</u>

Risk of injury due to unpredictable movement of the round bales when the machine is operating on a slope

If round bales are deposited on a slope, they may start moving on their own. Once round bales have started moving, their weight and cylindrical shape may cause serious accidents and injure people.

- On slopes, deposit round bales in manual mode only.
- On slopes, always deposit round bales in such a way that they cannot start moving on their own.
- ► To open the tailgate, actuate the control unit on the tractor (red, 1+) until the tailgate is open.
- ▶ To close the tailgate, move the control unit on the tractor (red, 1+) into the float position.

8.17 Removing crop blockages

8.17.1 Crop blockage at the right-hand and left-hand end of the pick-up

- Lower the rotational speed.
- While the PTO shaft is running, reverse and actuate the control unit in the tractor (yellow, 3+) several times to lift and lower the pick-up.
- Ensure that the crop press roller unit does not collide with the chassis when raised.

If this does not remove the crop blockage:

Shut down and safeguard the machine, see Page 27.

CAUTION! Risk of injury due to sharp parts! Always wear appropriate protective gloves when removing crop blockages.

- Remove the accumulated crops manually.
- After remedying the crop blockage, increase the speed to the rated speed again.

8.17.2 Crop blockage in the pick-up

- Lower the rotational speed.
- While the PTO shaft is running, reverse and actuate the control unit in the tractor (yellow, 3+) several times to lift and lower the pick-up.
- Ensure that the crop press roller unit does not collide with the chassis when raised.

If this does not remove the crop blockage:

- Shut down and safeguard the machine, see Page 27.
- ▶ Remove the baffle sheet, see Page 88.

CAUTION! Risk of injury due to sharp parts! Always wear appropriate protective gloves when removing crop blockages.

- Manually remove the accumulated crops.
- ▶ Mount the baffle sheet, see Page 88.

8.17.3 Crop blockage under the cutting rotor



RPG000-164

8.17 Removing crop blockages



To remove the accumulated crops from under the cutting rotor (1), proceed as follows:

- Switch off the PTO shaft.
- Reverse.
- Ensure that the tractor is in straight alignment with the machine.
- For "Operation unit DS 100" version: To preselect the blade cassette, press the

key, see Page 107.

- \Rightarrow The indicator lamp below the key lights up.
- For the other terminals To preselect the blade cassette, press the 😿 key on the

terminal, see Page 137.



- ► To lower the blade cassette, actuate the control unit on the tractor (yellow, 3-).
- The blades and blade cassette are in maintenance position: The blades have been swivelled out and the blade cassette has been lowered.
- Switch on the PTO shaft and test at idling speed whether the crop blockage is being removed.

If this does not remove the crop blockage:

Shut down and safeguard the machine, see Page 27.

CAUTION! Risk of injury due to sharp parts! Always wear appropriate protective gloves when removing crop blockages.

Manually remove the accumulated crops.

When the crop blockage has been removed, put the cutting unit back into operation as follows:

- Switch on the PTO shaft.
- ▶ Hydraulically raise the blade cassette, see Page 89.
 - \Rightarrow The blade cassette is raised.

8.17.4 Crop blockage in the baling element

- Switch on the PTO shaft.
- Open the tailgate.
- Shut down and safeguard the machine, see Page 27.
- ▶ Close the stop cock, see Page 80.

CAUTION! Risk of injury due to sharp parts! Always wear appropriate protective gloves when removing crop blockages.

- Manually remove the accumulated crops from the baling element.
- Open the stop cock, see Page 80.
- Switch on the tractor engine and the PTO shaft.
- ► Close the tailgate.
- Resume baling.



9 KRONE operation unit DS 100

For version with "Net wrapping"

NOTICE

Penetration of water in the operation unit could lead to malfunction. As a result, the machine can no longer be operated safely.

- Protect the operation unit from water.
- If the machine is not used for an extended period of time (for example in winter), the terminal must be stored in a dry place.
- For installation and repair work, especially for welding jobs on the machine, interrupt the voltage supply to the operation unit.

9.1 Overview



9 KRONE operation unit DS 100

9.1 Overview



Pos.	Icon/designation	Explanation
1		Direction display arrows, see Page 110
2	LEDs A-H	The LEDs indicate the direction or the progress of the tying cycle on the working screen. Additionally, the LEDs can indicate different set-
3	4550	Display for various indications and settings
	13 14	Various settings can be made via the Plus and Minus keys.
		 Setting the bale diameter, see Page 112 Setting advance signaling, see Page 113 Setting the sensitivity of direction display, see Page 113
		Setting the baling pressure, see Page 114
		Setting the density and diameter of the bale core, see Page 115
		 Setting the number of net layers, see Page 117 Setting the tying start delay, see Page 118
		Display customer counter, see Page 119
		Preselect blades to be able to lift/lower the blades via the control unit, see Page 90.
		There is an indicator lamp above the key which is lit when the blades have been swivelled in.
		 Preselect pick-up to be able to move pick-up into transport/working position via the control unit, <i>see Page 84</i> Preselect blade cassette to be able to lift/lower the blade cassette via the control unit, <i>see Page 89</i>


KRONE operation unit DS 100 9

Switching the operation unit on/off 9.2

Pos.	Icon/designation	Explanation
		 Start tying process in manual mode Switch the automatic mode of tying on/off, see Page 111
		Switching working lights on/off, see Page 112
		Switching warning beacon on/off, see Page 112
4	Ý	Switching the operation unit on/off, see Page 109

9.2 Switching the operation unit on/off

When the operation unit is connected to the power supply of the tractor, the operation unit is switched on automatically. For connecting the operation unit, *see Page 65*.

When the operation unit is switched on:

- All indicator lamps and the background lighting emit light briefly and an acoustic signal is sounded.
- If an indicator lamp does not light up, this lamp is defective.
- The operation unit is ready for operation and is in road travel screen mode.

INFO

If another terminal is connected to the machine and a function is enabled on this terminal

which the DS 100 operation unit cannot show on the display, it is no longer possible to press

the keys on the DS 100 operation unit. The indicator lamp above the (U) key flashes.

- ► To exit this state, press the (U) key and hold for approx. 1 second.
- \Rightarrow The operation unit is in road travel screen mode.

9.3 Call road travel screen

After the operation unit is switched on , it is in road travel screen mode. In road travel screen

mode, only the indicator lamp above the (U) key emits light.

▶ To change from working screen to road travel screen, press the () key and hold for

approx. 1 second.

9 KRONE operation unit DS 100

9.4 Accessing the working screen



9.4 Accessing the working screen

The working screen can show the following data:

- The display shows the actual bale diameter in cm.
- During filling of the bale chamber, the LEDs A-H serve as direction display, see Page 110.
- During the tying cycle, the LEDs A-H show the process of the tying.
- ▶ To change from road travel screen to working screen, press the () key.

9.5 Direction display

EQ003-242

The direction display (1) shows the driver to which side and to what extent he must correct his direction when driving over the swath in order to ensure the bale chamber is filled evenly.

The LEDs below the icons emit light to indicate the direction of travel. The icons have the following meaning:

lcon	Explanation
	Step 1:
	The bale chamber is filled slightly too much on the left side. Steer the tractor to the left to pick up the swath on the right of the bale chamber
LED C/D	
	Step 2:
	The bale chamber is filled too much on the left side. Steer the tractor to the
LED B/C	left to pick up the swath on the right of the bale chamber.
	Step 3:
	The bale chamber is filled very heavily on the left side. Steer the tractor to
LED A/B	the left to pick up the swath on the right of the bale chamber.
	Step 4:
	The bale chamber is filled very heavily on the left side. Steer the tractor to
LED A	the left to pick up the swath on the right of the bale chamber.
LED D/E	Swath is picked up in the middle
	Step 1:
	The bale chamber is filled slightly too much on the right side. Steer the tractor to the right to pick up the swath on the left of the bale chamber.

Icon	Explanation
	Step 2:
	The bale chamber is filled too much on the right side. Steer the tractor to
LED F/G	the right to pick up the swath on the left of the bale chamber.
	Step 3:
	The bale chamber is filled very heavily on the right side. Steer the tractor to
LED G/H	the right to pick up the swath on the left of the bale chamber.
	Step 4:
	The bale chamber is filled very heavily on the right side. Steer the tractor to
LED H	the right to pick up the swath on the left of the bale chamber.

How the bale chamber is optimally filled by the pick-up, see Page 77.

- If the swath is the same width as the bale chamber, pick up the swath as centrally as possible.
 - \Rightarrow The D and E LEDs light up.
- ▶ If the swath is too narrow, pick it up alternatingly on the left and right sides. Ensure that you

do not move too far to the left or right.

9.6 Start tying

Start tying process in manual mode

Once the bale chamber has been filled, the indicator lamp above the 🖉 key flashes, and the

tying cycle can be started manually.

- To start the tying cycle, press the key.
- The indicator lamp above the key emits light. The LEDs A-H indicate the progress of the tying cycle.

Switching automatic tying on/off

- ► To switch automatic tying on, press the AUTO key.
- The indicator lamp under the key lights up. The next tying cycles are started as soon as the set bale chamber filling level is reached.
- ► To switch automatic tying off, press the AUTO key.
- The indicator lamp below the key goes out. The next tying cycles must be started manually



9.7 Switching the working lights on/off



9.7 Switching the working lights on/off

- To switch on the working lights, press the key.
- ➡ The indicator lamp above the key emits light.
- To switch off the working lights, press the key.
- ➡ The indicator lamp above the key goes out.

9.8 Switching warning beacon on/off

- To switch on the warning beacon, press the key.
- ➡ The indicator lamp above the key emits light.
- To switch off the warning beacon, press the key.
- ➡ The indicator lamp above the key goes out.

9.9 Setting the bale diameter



EQG003-119

In the working screen, the bale diameter for the entire round bale in cm can be set at the operation unit.

- ▶ Press the (3) to call the "Bale diameter" menu.
- The indicator lamp above the key and the LED A (1) emit light.
- The display (2) shows the set target bale diameter in cm.
- To change the value, press the $\frac{1}{12}$ teys (4).
- The value is saved automatically.
- ▶ To return to the working screen, press the OT key (3) again.

To set a separate diameter for the core of the round bale, see Page 115.



9.10 Setting advance signaling

Pre-signaling is used to warn if the round bale in the bale chamber is near completion. On the operation unit, you can set the filling at which advance signaling starts.



EQG003-117

On the operation unit, advance signaling can be set in cm on the working screen.

- ► To call the "Pre-signaling" menu, first press the key (3) and then the key once.
 - \Rightarrow The indicator lamp above the \bigcirc key and the LED F (1) emit light.
 - \Rightarrow The display (2) shows the set cm value for pre-signaling.
- ► To change the value, press the ____ keys (4).
- ➡ The value is saved automatically.

► To return to the working screen, press the tey (3) again.

9.11 Setting the sensitivity of the direction display



EQG003-118

This menu is used to set the sensitivity of the direction display on the working screen.

The direction display indicates whether the swath is picked up in the centre by the pick-up and provides information about the required direction of travel. The higher the number on the display (2), the more sensitive the direction display is set. The higher the sensitivity of the direction display is set, the stronger the motion indication appears in the form of arrows on the working screen.

9.12 Setting the baling pressure



How the bale chamber is optimally filled by the pick-up, see Page 77.

► To call the "Sensitivity of direction display" menu, first press the O key (3) and then the

AUTO key twice.

- \Rightarrow The indicator lamp above the \bigcirc key and the LED H (1) emit light.
- \Rightarrow The display (2) shows the set sensitivity of the direction display.
- ► To change the value, press the ____ keys (4).
- ➡ The value is saved automatically.
- To return to the working screen, press the key (3) again.

9.12 Setting the baling pressure



EQG003-116

At the operation unit, the baling pressure in % can be set for the round bale in the working screen.

- ✓ The setting for the various baling pressures is deactivated, see Page 115.
- Press the Key (3) to call the "Baling pressure" menu.
 - \Rightarrow The indicator lamp above the 60 key and the LED B (1) emit light.
 - \Rightarrow The display (2) shows the set target baling pressure in %.
- To change the value, press the $\frac{1}{13}$ keys (4).
- The value is saved automatically.
- ► To return to the working screen, press the O key (3) again.

To set a separate baling pressure for the core and the centre of the round bale, see Page 115.



Releasing the baling pressure

The baling pressure can be released for maintenance work at the baling belts or in the bale chamber.

- ✓ The working screen has been selected, see Page 110.
- Press the Okey (3) and hold it for approx. 5 seconds.
- ➡ The baling pressure is released and the indicator lamp above the key flashes.
- ► To build up the baling pressure, once more press the key (3) and hold it for approx. 5

seconds.

The baling pressure is built up and the indicator lamp above the key goes out.

9.13 Setting the core, centre and edge of the round bale



EQ003-247

A different baling pressure can be set for the core, the centre and the edge of the round bale, and a diameter for the core.

The following values are possible:

	Baling pressure	Diameter
Core	0-100 %	Up to 80 cm
Middle	0-100 %	Is calculated automatically from core and edge
Edge	0-100 %	Set bale diameter, <i>see Page 112</i>

As an alternative, the same baling pressure, see Page 114 and a bale diameter can be set for the entire round bale, see Page 112.

Activating the setting for different baling pressures for core, centre and edge of the round bale

- Press the key (8).
- ➡ The indicator lamp above the key (8) and the LED C (4) and the LED D (3) emit light.

The following data is shown in the display (5):

9 KRONE operation unit DS 100

9.13 Setting the core, centre and edge of the round bale



Data in the display (3)	Preselected setting
ON	The setting for different baling pressures is ac- tivated
OFF	The setting for different baling pressures is de- activated. The baling pressure for the entire round bale is set in the "Baling pressure" menu, <i>see Page 114</i> .

- ► To activate the setting, press the ____ keys (9) until the display shows "ON".
- The setting is saved automatically.
- To deactivate the setting, press the $\frac{1}{13}$ keys (9) until the display shows "OFF".
- The setting is saved automatically.

Setting different baling pressures for the core, centre and edge of the round bale and a diameter for the core of the round bale

The baling pressure for the core, centre and edge of the round bale is set in %.

The diameter for the core is set in a range of 1 to 80 cm.

✓ The setting for different baling pressures is activated.

Setting the diameter of the core

- Press the AUTO key to go to the diameter setting.
 - \Rightarrow The indicator lamp above the \bigcirc key (9) and the LED C (4) emit light and the current

diameter of the core is indicated in the display (5).

- ► To change the value, press the ____ keys (9).
 - \Rightarrow The value is saved automatically.

Setting the baling pressure of the core

- ► To set the baling pressure for the core, press the AUTO key again.
 - \Rightarrow The indicator lamp above the key (6) and the LED D (3) emit light, and the display
 - (5) indicates the current baling pressure of the core.
- To change the value, press the 13 keys (9).
 - \Rightarrow The value is saved automatically.

(¹) KRONE

Setting the baling pressure of the centre

- ► To set the baling pressure for the centre of the round bale, press the AUTO key again.
 - \Rightarrow The indicator lamp above the key (6) and the LED E (2) emit light, and the display

(5) indicates the current baling pressure of the core.

- ► To change the value, press the ____ keys (9).
 - \Rightarrow The value is saved automatically.

Setting the baling pressure of the edge

- To set the baling pressure for the edge of the round bale, press the AUTO key again.
 - \Rightarrow The indicator lamp above the key (6) and the LED F (1) emit light, and the display

(5) indicates the current baling pressure of the core.

- ► To change the value, press the ____ keys (9).
 - \Rightarrow The value is saved automatically.
 - \Rightarrow Press the key (6) to return to the working screen.

9.14 Setting the number of net layers



EQ003-248

On the operation unit, between 1.5 and 5.0 net layers can be set in the working screen. The display shows the net layers in tenths, for example 35 at 3.5 network layers.

- To call the "Number of net layers" menu, press the key (3).
 - \Rightarrow The indicator lamp above the \bigcirc key and the LED E (1) emit light.

9.15 Setting the tying start delay



- \Rightarrow The display (2) shows the set number of net layers.
- To change the value, press the $\frac{1}{12}$ teys (4).
- The value is saved automatically.
- ► To return to the working screen, press the 🧷 key (3) once more.

9.15 Setting the tying start delay

Tying start delay is used to set the period of time which is required between completion of round bale in the bale chamber and triggering the tying cycle. The tying start delay is set in milliseconds.

Setting range: 0-8,000 ms



EQ003-249

On the operation unit, the tying start delay can be set in milliseconds (ms) in the working screen.

► To call the "Tying start delay" menu, first press the 🔊 key (3) and then the AUTO key

once.

- \Rightarrow The indicator lamp above the 20 key and the LED G (1) emit light.
- \Rightarrow The display (2) shows the set tying start delay in ms.
- ► To change the value, press the ____ keys (4).
- ➡ The value is saved automatically.
- ► To return to the working screen, press the key (3) once more.



9.16 Displaying the customer counter



EQ003-250

The customer counter shows the number of the pressed round bales in the display (1). 8 different customer counters can be indicated and saved. Each LED from A-H corresponds to one customer counter. The respective LED emits light when the customer counter has been selected, and flashes when the corresponding customer counter is activated.

After scrolling through to LED H, the display (1) shows the total counter.

- To call the "Customer counter" menu, press the key (2).
 - ⇒ The indicator lamp above the key and the corresponding LED emit light.
 - \Rightarrow The display (1) shows the number of the pressed round bales.
- ► To scroll between the customer counters, press the 🧳 key to scroll up and the Auto key

to scroll down.

⇒ One after another, the LEDs emit light, and the corresponding number of pressed round bales is indicated in the display (1). After LED H, all LEDs emit light and the display (1) shows the total counter.

key.

- ► To call the total counter directly, press the key and hold for approx. 1 second.
- To activate the customer counter which is currently displayed, press the key.
 - ⇒ The LED of the activated customer counter flashes.
- To change the number of round bales, press the
- To set the indicated customer counter to 0, press the key and hold for approx. 1 second.



9.17 Sensor test for digital and analogue sensors

M WARNING

Danger of injury in the danger zone of the machine

If the PTO shaft runs during the sensor test, machine parts may start to move unintentionally. Thus there is a risk of serious injuries or death.

► Turn off PTO shaft.

In the sensor test, the sensors installed on the machine are checked for faults. Furthermore the sensors can be correctly set in the sensor test. There is no guarantee the machine is working correctly until after the sensors have been adjusted.

Access to the sensor test for digital sensors is possible in road travel screen mode only, see Page 109.

To call up the diagnostics section, press the key and hold it while pressing the



key.



EQ003-530

- To access the "Sensor test" menu, press the key (2).
 - \Rightarrow The indicator lamp above the key emits light.
 - ⇒ Digital sensors: The display (1) shows the sensor number on the left and the status of the sensor on the right.
 - Analogue sensors: The display (1) indicates the sensor number on the left and the current voltage in 1/10 V on the right (e.g. 1.5 = 15 V).

The following status displays for digital sensors are possible:

Status	Display	Sensor status
1	Is lit and a warning sounds	Sensor is attenuated (metal in front of the sensor)
2	Is lit	Sensor is not attenuated
20	Flashes	Short circuit
21	Flashes	Cable break
26	Flashes	General fault

The following sensors can be displayed:

(¹) KRONE

KRONE operation unit DS 100 9

Calibrating sensors 9.18

No.	Designation	Sensor type
B01	Speed of bale chamber	digital
B02	Tying process active	digital
B08	Blade cassette up	digital
B09	Filling display left	analogue
B11	Tailgate lock hook left	digital
B12	Tailgate lock hook right	digital
B15	Bale ejection	digital
B61	Tying 1 (passive)	analogue
B67	Blade pre-selection active	digital
B68	Blade pre-selection inactive	digital
B69	Blade active	digital
B82	Direction indicator	analogue
B83	Overload protection baling belts	digital

An overview of the position of the sensors, actuators and control units is provided in the circuit diagram.

► To switch between the sensors, press the 🖉 key to scroll up and the AUTO key to scroll

down.

- ▶ To eliminate an error on the sensor, see Page 244.
- ► To quit the diagnostics section, press the (U) key and hold for approx. 1 second.

9.18 Calibrating sensors



EQ003-529

- ✓ The "Sensor test" menu has been selected, see Page 120.
- To access the "Calibrate sensors" menu, press the key.



key is lit.

9.18 Calibrating sensors

- The display shows the currently measured voltage of the selected sensor is indicated in ⇒ 1/10 V.
- ⇒ One of the LEDs A-E is lit.

The LEDs A–E stand for the following sensors:

LED	Sensor		Additional
A	B09	Filling display left	
В	B10	Filling display right	
С	B61	Tying 1 (passive)	Set feed position of the feed rocker arm
D	B61	Tying 1 (passive)	Set end position of the feed rocker arm
E	B82	Direction indicator	

key to scroll up and the AUTO key To switch between the sensor calibrations, press the to scroll down.

Calibrating sensor B61 "Tying 1 (passive)"

- Call sensor B61.
- To change the value, press the keys.
 - ⇒ As soon as the sensor value is within a valid range, the indicator lamp under the key is lit.
- To save the value, press and hold down the 430key.
- The sensor has been calibrated and a confirmation tone sounds.

Calibrating the remaining sensors

The remaining sensors must be mechanically set on the machine if they display an error in the sensor test.

An overview of the position of the sensors, actuators and control units is provided in the circuit diagram.

Set feed position of the feed rocker arm

- The LED C is lit.
- To move the feed rocker arm in the direction of the feed position, press the

keys.

- To save the value, press and hold down the key.
- The sensor has been calibrated and a confirmation tone sounds.









Set end position of the feed rocker arm

- ✓ The LED D is lit.
- To move the feed rocker arm in the direction of the end position, press the set keys.
- To save the value, press and hold down the 4 key.
- The sensor has been calibrated and a confirmation tone sounds.

9.19 Actuator test for digital and analogue actuators

MWARNING

Risk of injury due to non-observance of the safety routines

If the relevant safety routines are not observed, persons may be seriously injured or killed.

▶ The safety routines must be read and observed to avoid accidents, see Page 27.

The actuator test is used to test the actuators installed on the machine. An actuator can only be tested when current is flowing through it. Therefore, in the "Actuator test" menu, the actuator must be controlled manually for a short time in order to determine possible errors in the actuator system.

The actuator test can be called up from the road traffic screen only, see Page 109.

• To call up the diagnostics section, press the



key and hold it while pressing the

key.



EQ003-531

To access the "Actuator test" menu, press the key (2).

- ⇒ The indicator lamp above the key emits light.
- ⇒ The display (1) shows the actuator number on the left and the status of the actuator on the right.

The following status displays for actuators are possible:

9 **KRONE** operation unit DS 100

9.19 Actuator test for digital and analogue actuators



Status	Display	Actuator status
3	Is lit	Actuator ON
4	Is lit	Actuator OFF
20	Flashes	Short circuit
21	Flashes	Cable break
26	Flashes	General fault

The following actuators can be displayed:

No.	Designation
E20	Working lights net roll (for the "Working lights" version)
E22/E23	Maintenance lighting side hood left/right
K01	Pick-up
К03	Raising/lowering blade cassette
K21	Blade control shaft A active
Q26	Lowering the feed rocker arm
Q27	Lifting the feed rocker arm
Q41	Baling pressure
M01	Motor tying 1 (passive)

An overview of the position of the sensors, actuators and control units is provided in the circuit diagram.

To switch between the actuators, press the 🖉 key to scroll up and the AUTO key to scroll ►

down.

Switching actuators on/off

- key to switch the indicated actuator on. Press the
- key to switch the indicated actuator off. Press the

Increase/decrease the currents of the analogue actuators

With the analogue actuators Q30 and Q41, the mA values of the current can be increased or decreased .

- Select the required actuator.
 - ⇒ The currently set current is indicated in the display in mA.
- key to increase the current of the indicated actuator. Press the
- Press the key to reduce the current of the indicated actuator.

9.20 Error messages

The error messages can be indicated in the working screen or road travel screen. If an error message is pending, the LEDs A-H flash.

The display shows the error number of the error message.

To indicate the FMI of the error message, press the key.

For an explanation of the configuration of an error message, see Page 242.

Acknowledging error message

- Note down the error number.
- Press the $rac{1}{13}$ or $rac{1}{14}$ key.
- The acoustic signal stops and the error message is no longer indicated.
- Eliminate the disturbance; see Chapter "Error list" in the supplement to the operating instructions (software).

If the fault occurs again, the error message will be displayed again.

9.21 Manual operation of the tying system



EQ003-528

When the tying system is manually operated, the feed rocker arm can be manually moved. For an overview of the positions of the feed rocker arm, see Page 245.

To access the "Manual operation" menu, press the key (2) and hold down for

approx.4 seconds.

 \Rightarrow The indicator lamp above the \bigcirc key flashes.

⇒ The display shows the current position of the feed rocker arm.

The following displays are possible:



Display	Explanation
	The feed rocker arm is in the limit position.
-	The feed rocker arm is in the feed position.
	The feed rocker arm is between the limit and feed position. This display is also shown while the feed rocker arm is moving.

► To move the feed rocker arm to the limit position, press the key and hold down



To return to the working screen, press the key and hold down.

9.22 Setting user preferences



EQG003-123

The following is set in the user settings:

- volume,
- background lighting for day or night design,
- display lighting for day or night design

. Additionally, day or night design can be activated.

- ✓ The road travel screen is open, see Page 109.
- To call the "User settings" menu, press the key and the

key (4) simultaneously.

The display (1) shows the number of the setting (2) and the set value (3).

()) KRONE

KRONE operation unit DS 100 9

Setting user preferences 9.22

Number of the set- ting (2)	Setting type	Value range (3)
1	Volume	0-10
2	Background lighting day design	0-10
3	Background lighting night design	0-10
4	Display lighting day design	1-10
5	Display lighting night design	1-10
6	Day or night design	d for day n for night

- ► To change between the settings, press the or AUTO key.
- To change the value, press the 13 keys (4).
- ➡ The value is saved automatically.



10 KRONE Terminal DS 500

NOTICE

Penetration of water in the terminal could lead to malfunction. As a result, the machine can no longer be operated safely.

- Protect the terminal from water.
- If the machine is not used for an extended period of time (for example in winter), the terminal must be stored in a dry place.
- For mounting and repair jobs, especially for welding jobs on the machine, disconnect the power supply to the terminal.

10.1 Touchable display

To provide menu guidance and entry of values/data, the terminal is equipped with a touchcapable display. By touching the display, you can call up and change values in blue font.

10.2 Switching terminal on/off



EQ003-253

Before switching on the terminal for the first time, check that the connections are correct and tight.

INFO

When the terminal is switched on for the first time, the machine configuration is loaded into the terminal and saved in the terminal memory. Loading may take a few minutes.

Switching ON

- Press and hold down the key (1).
 - \Rightarrow If the machine is not connected, the display shows the main menu after switching on.
 - ⇒ If the machine is connected, the display shows the road travel screen after switching on.
- The terminal is ready to operate.

Switching off

Press and hold down the key (1).



10.3 Design DS 500



EQ003-254

The KRONE machine application is divided into the following areas:

Status line (1)

The status line (1) indicates current states of the machine (depending on how it is equipped), see Page 136.

Keys (2)

The machine is operated by pressing the keys (2) via touch function, see Page 137.

Main window (3)

Values (figures) shown in blue in the main window can be selected using the touch function.

There are the following main window views:

- Road travel screen, see Page 109
- Working screen, see Page 139
- Menu level, see Page 154

Information bar (4)

The information bar shows information on the working screen, see Page 141.

Keys (5)

Alternatively, the machine is operated by pressing the keys (5) without the touch function.

10.3 Design DS 500



Keys (6)

The keys (6) can be used to open the main menu or the working screen and to confirm the error messages and set the brightness.

Icon	Designation	Explanation
n	Main menu	Open the main menu of the terminal.
\bigcirc	Swap key	Switch between the main menu and the working screen of the terminal.
		With more than one machine mask, the views switches to the next one.
ACK	ACK (acknowledgement key)	Confirm error messages.
ESC×	ESC (back key)	Leave the menu without saving.
·*/(Brightness	Switch from day to night design and vice versa.

Scroll wheel (7)

Alternatively, the values (figures) shown in the main window (3) can be selected and set using the scroll wheel (7). The scroll wheel (7) can also be used to navigate between the individual menus.

Turning the scroll wheel to the right:

- Increase the value.
- Navigate to the next value in the menu.
- Navigate to the next menu.

Turning the scroll wheel to the left:

- Reduce the value.
- Navigate to the previous value in the menu.
- Navigate to the previous menu.

Press the scroll wheel:

- Select the value.
- Save the value.
- Open the menu.



Touchable display 11.1

KRONE ISOBUS terminal (CCI 800, CCI 1200) 11

NOTICE

Penetration of water in the terminal could lead to malfunction. As a result, the machine can no longer be operated safely.

- Protect the terminal from water.
- If the machine is not used for an extended period of time (for example in winter), the terminal must be stored in a dry place.
- For mounting and repair jobs, especially for welding jobs on the machine, disconnect the power supply to the terminal.

The ISOBUS system is an internationally standardised communications system for agricultural machines and systems. The designation of the associated series of standards is: ISO 11783. The agricultural ISOBUS system enables information and data to be exchanged between tractor and unit of different manufacturers. For this purpose, both the required plug connections and the signals are standardised which are required for the communication and transmission of commands. The system also enables machines to be operated with operation units (terminals) which are already available on the tractor or have been attached e.g. to the tractor cabin. The relevant information can be found in the technical documents of the operation device or on the units themselves.

KRONE machines, which have ISOBUS equipment, are coordinated with this system.



EOG000-057

The electronic equipment of the machine consists essentially of the job computer (1), the terminal (2) and the control and function elements.

The job computer (1) is located on the right side of the machine under the side hood.

Functions of the job computer (1):

- Control of actuator system installed on the machine.
- Transmission of error messages.
- Evaluation of sensor system.
- Diagnostics of sensor system and actuator system.

11.1 Touchable display

To provide menu guidance and entry of values/data, the terminal is equipped with a touchcapable display. By touching the display, you can call up and change values in blue font.



Switching terminal on/off

11.2

11.2 Switching terminal on/off



EQ001-174

KRONE ISOBUS terminal CCI 1200	KRONE ISOBUS terminal CCI 800

Before switching on the terminal for the first time, check that the connections are correct and tight.

INFO

When the terminal is switched on for the first time, the machine configuration is loaded into the terminal and saved in the terminal memory. Loading may take a few minutes.

Switching ON

- Press and hold down the key (1).
 - \Rightarrow If the machine is not connected, the display shows the main menu after switching on.
 - ⇒ If the machine is connected, the display shows the road travel screen after switching on.
- The terminal is ready to operate. •

If machine is not connected: "Main menu"

If machine is connected: "Road travel screen"



EQG000-056

The display appears in landscape mode after starting the terminal. Refer to the CCI terminal operating instructions if you want the display in portrait rather than landscape mode or if you wish to expand the terminal applications to full view.

Switching off

Press and hold down the key (1).



INFO

► For more details on how the terminal functions, follow the terminal operating instructions.

11.3 Design of display



EQG000-058

Pos.	Designation	Explanation
1	Status line	
2	Main view left/right	When operating the machine, KRONE recom- mends positioning the machine application in the main view.
3	Information view	Additional applications (apps) can be selected from the App menu and displayed in the Informa- tion view. The apps can be dragged and dropped into the Main view.

INFO

► For more details on how the terminal functions, follow the terminal operating instructions.

11.4 Design of the KRONE machine application



EQG000-059

The KRONE machine application is divided into the following areas:

Status line (1)

The status line (1) indicates current states of the machine (depending on how it is equipped), see Page 136.

11.5 Setting units on the terminal



Keys (2)

The machine is operated by pressing the keys (2) via touch function, see Page 137.

Main window (3)

Values (figures) shown in blue in the main window can be selected using the touch function.

There are the following main window views:

- Road travel screen, see Page 109
- Working screen, see Page 139
- Menu level, see Page 154

Information bar (4)

The information bar shows information on the working screen, see Page 141.

11.5 Setting units on the terminal

The units, e.g. metric or imperial, can be set on the terminal in the menu "User settings". This setting is accepted after the terminal has been restarted as well as for the machine software.

The procedure and other settings can be found in the operating instructions for the terminal.



12 Foreign ISOBUS terminal



Risk of injury caused by utilization of foreign terminal or other operation units

When using terminals and other operation units which have not been delivered by KRONE mind that the user:

- ✓ assumes the responsibility for the use of KRONE machines when using the machine on operation units (terminal / other operating elements) which have not been delivered by KRONE.
- ✓ only connects such systems (if possible) which have passed a AEF/DLG/VDMA test (socalled ISOBUS COMPATIBILITY TEST).
- ✓ has to follow the operating and safety instructions of the supplier of ISOBUS operation unit (e.g. terminal).
- must ensure that the used operating elements and machine controls concerning IL (IL = Implementation Level; describes compatibility levels of different software versions) must fit together (condition: IL same or higher).
- Before using the machine, make sure that all machine functions are performed according to the enclosed operating instructions.

INFO

KRONE ISOBUS systems regularly pass the ISOBUS COMPATIBILITY TEST (AEF/DLG/ VDMA test). The operation of this machine at least requires implementation level 3 of ISOBUS system.

The ISOBUS system is an internationally standardised communications system for agricultural machines and systems. The designation of the associated series of standards is: ISO 11783. The agricultural ISOBUS system enables information and data to be exchanged between tractor and unit of different manufacturers. For this purpose, both the required plug connections and the signals are standardised which are required for the communication and transmission of commands. The system also enables machines to be operated with operation units (terminals) which are already available on the tractor or have been attached e.g. to the tractor cabin. The relevant information can be found in the technical documents of the operation device or on the units themselves.

KRONE machines, which have ISOBUS equipment, are coordinated with this system.

12.1 Varying functions to KRONE ISOBUS terminal

The job computer provides information and control functions of the machine on the display of the external ISOBUS terminal. Operation with an external ISOBUS terminal is similar to operation with the KRONE ISOBUS terminal. Before commissioning, refer to the mode of operation of the KRONE ISOBUS terminal in the operating instructions.

A major difference to the KRONE ISOBUS terminal is the arrangement and number of keys with functions determined by the selected external ISOBUS terminal.

13.1 Status line



13 Terminal machine functions

<u> WARNING</u>

Personal injuries and/or machine damage caused by non-compliance of error messages

If error messages are ignored and the malfunction is not remedied, people may be injured and/or the machine may be damaged seriously.

- Remedy the malfunction when the error message is displayed, see Page 242.
- ▶ If the malfunction cannot be remedied, consult a KRONE service partner.

13.1 Status line

INFO

Using a terminal with a resolution of less than 480x480 pixels.

On terminals with a resolution of less than 480x480 pixels, only 7 fields are displayed in the status line. Thus, not all icons for the status line are shown.

On terminal with a resolution of more than/equal to 480x480 pixels, 8 fields are shown in the status line.



EQ000-901

Icons displayed with shading () can be selected. If an icon with shading is selected:

- a window with further information opens or
- a function is activated or deactivated.

The status line shows the current states of the machine (depending on how it is equipped):

lcon	Explanation
	There are one or more error messages. For version with "Touch-capable display": If this icon is pressed, the pending error messages open in sequence, <i>see Page 242</i> .
	Blades swivelled in (activated).
	Blades swivelled out (deactivated).
	Blade and blade cassette in maintenance position: The blade cassette has been lowered and blade pre-selection has been deactivated.



lcon	Explanation
	Blades in undefined state.
	Pre-signalling set.
For version	n with "TIM 1.0"
	TIM status: The machine is being registered and authenticated with the tractor.
	TIM status: The machine has been registered and authenticated. By pressing the key time, the TIM status switches to .
	TIM status: The machine waits for confirmation of the tractor. Confirmation on the terminal or on another control panel on the tractor causes the TIM status to switch to
\mathbb{Q}	TIM status: The machine and the tractor are successfully connected. The machine automatically takes over control of the TIM functions on the tractor, <i>see Page 145</i> .
\bigcirc	Flashing: 2 TIM functions are currently active, one TIM function of which has been overridden. The connection is restored by pressing the key and then confirming on the tractor.
For "Worki	ng lights" version
	Switched on.
	Switched off.

13.2 Keys

The keys that are available depend on the machine configuration. The keys listed below are not always available.

Dimmed keys are currently not available.

Icon	Designation	Explanation
	Feeding wrapping and ty- ing material in manual mode.	Press the key to feed wrapping material to the round bale.
	Switching tying to auto- matic operation.	The previously selected mode of operation, "Manual operation" or "Automatic opera- tion", is shown on the key. Press the key to
00	Switching tying to manual operation.	change the mode of operation.
14	Preselect blades.	When the key has been pressed, the con- trol unit must be actuated to swivel the blades in or out.

13.2 Keys



Icon	Designation	Explanation	
	Pre-select pick-up.	The setting previously selected, pick-up or blade adjustment is displayed. Press the key to change the setting.	
t	Pre-select blade adjust- ment.		
	Switching working lights off.	The previously selected setting "Working lights switched off" or "Working lights switched on" is displayed on the key. Press	
	Switch the working lights on.	the key to change the setting.	
	Switch the warning beacon	(Warning beacon only for certain countries)	
· ^ `	оп.	The previously selected setting "Warning	
*	Switch the warning beacon on.	n switched on" is displayed on the key. Pres	
0	Menu level on the terminal.	Press the key to open the menu level on the terminal, see Page 154.	
	Open the Counters menu.	Press the key to open Menu 13 "Counters", see Page 172.	
	Scrolling display pages.		

For version with "TIM 1.0"

The keys can be used to operate the following functions. If the key is greyed out, the function is not available.

Icon		Explanation
		Start TIM functions (can be selected only when tailgate closed).
		Pause TIM functions. In doing so, registration and authen- tication are not disconnected between tractor and ma- chine.



13.3 Displays on the working screen



The available icons comply with the equipment of the machine. The following represented icons are not always available.

Icon	Explanation		
STOP	For version with "TIM 1.0": A TIM function is active on the machine.		
	Direction display.		
	Direction display arrows:		
	Arrows appear during operation on the left and right sides of the direction display. The arrows have three different sizes, numbered from 1 to 3.		
	The arrows show the driver to which side and to what extent he must cor- rect his direction when driving over the swath in order to ensure the bale chamber is filled evenly.		
	If the direction of travel is not corrected, the arrow displayed starts flashing and an acoustic signal sounds.		
	Detailed information on the direction display, see Page 142		
100/168 cm	Set and display bale diameter.		
70 120 170	The bale diameter can be set directly on the working screen, <i>see Page 145</i> .		
	For version with "TIM 1.0": TIM function "Opening and closing tailgate at the end of the tying cycle" has been activated. The TIM function can be switched off individually via the checkbox, e.g. if the machine is in an unfavourable position for ejecting the round bale. To configure the TIM software, <i>see Page 177</i>		

13.3 Displays on the working screen



Round baler



EQG003-122

The round baler in the centre of the working screen shows

- the progress of the baling process by means of the expanding round bale (3),
- the progress of the tying process by means of the net roll (1) and by means of the red net running around the round bale,
- the positions of the blade cassette (4)
- and the bale ejection by means of the opening tailgate (2) and the position of the bale ejector (5).

The blade cassette (4) can show the following positions:

lcon	Explanation
	The blades have been swivelled in and the blade cassette is in the upper position.
	The blades have been swivelled out and the blade cassette is in the upper position.
	The blade cassette is in the lower position.
0	This maintenance position is used, for example, to change the blades, <i>see Page 226</i> , or to remove crop blockages, <i>see Page 105</i> .
	The blade cassette is in the lower position.



Icons during net wrapping or twine tying

Icon		Explanation
1		Value of bale diameter/baling pressure has been reached (flashing).
2N 🧕	2G 🔘	Net/twine is fed.
3N The second se	3G	Net/twine is not pulled.
4N 0	4G	Net wrapping/twine tying is active.
51	56	Net wrapping/twine tying is stopped.
6N 00 000	6G	Net/twine is cut off.
7N 0 ×	7G	Net wrapping/twine tying has not been cut off.
8N 🔘	8G 🔘	Net wrapping/twine tying is complete.
9N N N	9G	Net/twine is pulled without a tying cycle having been ac- tuated.

In addition, the progress of the net wrapping or twine tying is displayed as a percentage under the icon.

13.4 Displays on the information bar



EQG003-111

The available icons comply with the equipment of the machine. The following represented icons are not always available.

13 **Terminal machine functions**

13.5 Direction display



lcon	Designation	Explanation
	Customer counter	The selected customer counter is dis- played and shows the current total of pressed round bales.
12		If the display is pressed, Menu 13-1 "Cus- tomer counter" opens, <i>see Page 172</i> .
	Baling pressure	The selected target baling pressure in % is shown on the left. The actual baling pressure in % is shown at the bottom right.
00/ 32		If the display is pressed, Menu 6 "Elec- tronic baling pressure setting" opens so that the baling pressure can be set, <i>see</i> <i>Page 160</i> .
%	Moisture measurement	The current degree of moisture of the crops is displayed.
0,0		For settings in the moisture measurement, see Menu 12-1 "Error message for mois- ture measurement", <i>see Page 169</i> . or Menu 12-2 "Correction value for mois- ture measurement", <i>see Page 170</i> .
	Bale cycle time	The time is displayed how long the last round bale was pressed.
35s		

Direction display 13.5



The direction display (1) shows the driver to which side and to what extent he must correct his direction when driving over the swath in order to ensure the bale chamber is filled evenly.

The following displays are possible:



lcon	Explanation	
	Swath is picked up in the middle	
	Step 1:	
	The bale chamber is filled slightly too much on the left side. Steer the tractor to the left to pick up the swath on the right of the bale chamber.	
	Step 2:	
	The bale chamber is filled too much on the left side. Steer the tractor to the left to pick up the swath on the right of the bale chamber.	
3	Step 3:	
	The bale chamber is filled very heavily on the left side. Steer the tractor to the left to pick up the swath on the right of the bale chamber.	
2	Step 4:	
Arrow flashes	The bale chamber is only filled on the left side. Steer the tractor to the left to pick up the swath on the right of the bale chamber.	
	Step 1:	
	The bale chamber is filled slightly too much on the right side. Steer the tractor to the right to pick up the swath on the left of the bale chamber.	
2	Step 2:	
	The bale chamber is filled too much on the right side. Steer the tractor to the right to pick up the swath on the left of the bale chamber.	
3	Step 3:	
	The bale chamber is filled very heavily on the right side. Steer the tractor to the right to pick up the swath on the left of the bale chamber.	
3	Step 4:	
Arrow flashes	The bale chamber is only filled on the right side. Steer the tractor to the right to pick up the swath on the left of the bale chamber.	

For more information on how the bale chamber is filled, see Page 77.

▶ If the swath is the same width as the bale chamber, pick up the swath as centrally as

possible _____.

▶ If the swath is too narrow, pick it up alternately (on left/right). Ensure that you do not move

too far to the left 3 or right 3.

13.6 Accessing the working screen

Road travel screen

Example menu







EQG003-045

From the road travel screen

- 🕨 Press ᅿ .
- ➡ The working screen is shown, see Page 139.

In each menu

- ✓ A menu is displayed.
- ▶ Press and hold **ESC** for a moment.

13.7 Automatic call of the Road travel screen



EQG000-026

The terminal switches automatically to the Road travel screen after roughly five minutes when the following requirements are met:

- ✓ The PTO shaft is switched off.
- ✓ The tailgate is closed.
- \checkmark The machine is in field mode.


13.8 Adjusting bale diameter



EQG003-037

- 1 Set setpoint bale diameter in cm
- 2 Actual bale diameter in cm

Adjusting the bale diameter via the scroll wheel

- Select the blue value to be changed using the scroll wheel.
 - \Rightarrow The icon is shown in reverse colours.
- Press the scroll wheel.
 - \Rightarrow An input field opens.
- To increase or reduce the value, turn the scroll wheel.
- To save the value, press the scroll wheel.
 - \Rightarrow The setting is accepted, the input field closes.

Adjusting the bale diameter via the touch-capable display

- ► Touch the blue value you want to change.
 - ⇒ An input field opens.
- ► Enter the desired value and press **OK**
 - \Rightarrow The value is saved and the input field is closed.

13.9 Operating TIM 1.0 (Tractor Implement Management)

13.9.1 Mode of operation of TIM 1.0

<u> WARNING</u>

Risk of injury due to unpredictable movement of the round bales when the machine is operating on a slope

If round bales are deposited on a slope, they may start moving on their own. Once round bales have started moving, their weight and cylindrical shape may cause serious accidents and injure people.

- On slopes, deposit round bales in manual mode only.
- On slopes, always deposit round bales in such a way that they cannot start moving on their own.



TIM 1.0 (Tractor Implement Management) uses data exchange between the ISOBUS job computers on machine and tractor so that the machine can control the tractor and therefore take pressure off the driver.

When the tying cycle starts, the tractor is automatically stopped by TIM. When the tying cycle is complete, the tailgate is automatically opened by TIM, the round bale is ejected and the tailgate is closed. To bale the next round bale, the driver only has to approach the tractor. Then the tractor driver must independently drive at a speed adjusted to visibility, weather or ground conditions.

13.9.2 TIM displays and keys on the working screen



EQG003-096

The following TIM displays are possible:

lcon	Explanation
	For version with "TIM 1.0": TIM function "Opening and closing tailgate at the end of the tying cycle" has been activated. The TIM function can be switched off individually via the checkbox, e.g. if the machine is in an unfavourable position for ejecting the round bale. To configure the TIM software, <i>see Page 177</i>
STOP	For version with "TIM 1.0": A TIM function is active on the machine.

The following status displays could appear in the status line:

Icon	Explanation		
For version with "TIM 1.0"			
	TIM status: The machine is being registered and authenticated with the tractor.		
	TIM status: The machine has been registered and authenticated. By pressing the key time, the TIM status switches to .		

VariPack V 190 XC



lcon	Explanation
	TIM status: The machine waits for confirmation of the tractor. Confirmation on the terminal or on another control panel on the tractor causes the TIM status to switch to
\bigcirc	TIM status: The machine and the tractor are successfully connected. The machine automatically takes over control of the TIM functions on the tractor, <i>see Page 145</i> .
\bigcirc	Flashing: 2 TIM functions are currently active, one TIM function of which has been overridden. The connection is restored by pressing the key and then confirming on the tractor.

The keys can be used to operate the following functions. If the key is greyed out, the function is not available.

Icon		Explanation
		Start TIM functions (can be selected only when tailgate closed).
		Pause TIM functions. In doing so, registration and authen- tication are not disconnected between tractor and ma- chine.

13.9.3 Activating TIM functions

If the machine was switched off and is switched on again, registration and authentication between tractor and machine are automatically restored. The same control unit is used for the TIM function "Opening and closing tailgate at the end of the tying cycle" which was used the last time the machine was commissioned.

To activate the TIM functions, only the connection between machine and tractor must be established.

- ✓ In menu 14-5 "Configuring TIM software"(see Page 177)
 - the required TIM functions were selected and
 - registration and authentication were run on the tractor.
- ✓ The TIM status on the working screen is on



- ► Press (Tim)►.
- Confirm the TIM functions on the terminal or on another control panel on the tractor.
- The TIM status switches to

. The machine automatically takes over control of the

TIM functions on the tractor.

If no TIM status is displayed on the working screen, the TIM functions must be selected and registered and authenticated via menu 14-5 "Configuring TIM software", *see Page 177*.

INFO

In the case of the TIM function "Stop tractor when the tying cycle starts", the tractor must be driven at a speed of at least 0.5 km/h before the TIM function can be confirmed on the tractor.



INFO
If 2 TIM functions are active and one of them is overridden, the TIM status flashes.
If only one TIM function is active and is overridden, the TIM status switches to
► To restore the connection, press the key .

13.9.4 Pausing TIM functions

If TIM is not to be used for the time being, TIM can be paused. In doing so, registration and authentication are retained between tractor and machine.

✓ The TIM status on the working screen is on



- ► Press (Tim) .
- ➡ The TIM functions are paused and must be operated manually via the tractor control units.

The TIM status switches to



▶ To reactivate the TIM functions, see Page 147.

It is also possible to deactivate only the individual TIM function "Opening and closing tailgate at the end of the tying cycle", e.g. if the machine is in an unfavourable position for ejecting the round bale.

▶ To deactivate the TIM function "Opening and closing tailgate at the end of the tying cycle",

select the checkbox by checking

 \mathbf{I} next to the icon \mathbf{I}

- The checkbox is empty and the TIM function has been deactivated.
- In addition the key appears on the display in order to be able to start tailgate opening and hale circuits menually.

and bale ejection manually.

13.10 Operating machine via joystick

13.10.1 Auxiliary functions (AUX)

There are terminals which support the additional function "Auxiliary" (AUX). By means of this function, programmable keys of peripheral equipment (e.g. joystick) can be assigned with functions of the connected job computers. A programmable key can be assigned with several different functions. If key assignments are saved, the display shows corresponding menus when switching on the terminal.

The following functions are available in the "Auxiliary" (AUX) menu:



Icon	Explanation
Ŭ. 	For "TIM 1.0" version: Putting down round bales
2 0 1	Start tying
	Select type of operation for tying: Automatic or manual mode
10	Increasing bale diameter
10	Reducing bale diameter

13.10.2 Auxiliary assignment of a joystick

INFO

If a joystick on the tractor side is to be configured with functions from the operating terminal, the joystick must feature AUX functionalities.

For further information, see the operating instructions for the terminal and tractor used.

INFO

The examples below represent a recommendation. The assignment of the joystick can be adapted to own desires.

For further information, please refer to the operating instructions of the used terminal.

13.10 Operating machine via joystick



Recommended configuration of a WTK joystick



EQG003-040

The keys on the WTK joystick can be assigned on 2 levels.

- Change between the levels using the switch (2).
- ➡ The LED (1) is lit green or red.

Recommended configuration of an AUX joystick CCI A3



VariPack V 190 XC Original operating instructions 150001187_03_en-GB



The indicator lamp (2) shines, showing that operating level 1 is active.

• Actuate the switch (1) on the rear of the joystick to display the next operating level.

14.1 Menu structure



14 Terminal menus

14.1 Menu structure

The menu structure is divided into the following menus depending on the machine configuration.

Menu	Sub-menu	Designation	
		Number of net layers, <i>see Page 158</i>	
		Number of twine layers (for "net wrapping and twine tying" version), <i>see</i> <i>Page 158</i>	
3		Pre-signalling, see Page 159	
4		Tying start delay, see Page 159	
		Electronic baling pressure adjustment, see Page 160	
7 (4)		Sensitivity direction display, <i>see Page 161</i>	
8		Selection of tying method (for version with "net wrapping and twine tying"), <i>see</i> <i>Page 162</i>	
9 () Ť		Filling correction, see Page 163	
10		Manual operation, see Page 164	
		Correction of start/end position of twine tying (for "net wrapping and twine tying" version), <i>see</i> <i>Page 167</i>	
12		Moisture measurement (for version with "moisture measurement"), <i>see</i> <i>Page 169</i>	
	12-1 % !	Error message for moisture measurement, <i>see Page 169</i>	





Menu	Sub-menu	Designation
	12-2	Correction value for moisture measurement, <i>see Page 170</i>
13 EE		Counter, see Page 172
	13-1	Customer counter, see Page 172
	13-2	Total counter, see Page 174
14		ISOBUS, see Page 175
	14-5	KRONE SmartConnect, see Page 176
	14-6 (TiM)	Configuring TIM software (for "TIM 1.0" version), see Page 177
	14-9	Switching between terminals, see Page 178
15 ***		Settings, see Page 179
	15-1	Sensor test, <i>see Page 180</i>
	15-2	Actuator test, see Page 184
	15-3	Software information, see Page 186
	15-4	Error list, see Page 186

14.2 Recurrent icons

To navigate in the menu level/menus, the following icons appear again and again.

14.3 Selecting a menu Level



Icon	Designation	Explanation
1	Up arrow	Move up to select something.
ł	Down arrow	Move down to select something.
→	Right arrow	Move right to select something.
+	Left arrow	Move left to select something.
	Disk	Save the setting.
FCC	ESC	Leave the menu without saving.
EJU		By pressing the key a little longer, the pre- viously viewed working screen is selected.
DEF	DEF	Reset to factory setting.
	Disk	The mode or value is saved.
÷	Plus	Increase the value.
	Minus	Reduce the value.

14.3 Selecting a menu Level

- ▶ To bring up the menu level from the working screen, press
- ➡ The display indicates the menu level.

Return from the menu pages to the main menu:

• Keep pressing **ESC** until the main menu appears.

For an overview of the menus: see Page 152.

14.4 Selecting a menu

Calling up menu

The menus are selected depending on used terminal (touch sensitive or not touch sensitive).

14

14.5

For version with "Touch-sensitive and not touch-sensitive terminal"

By means of adjacent keys

- \blacktriangleright To select a menu, press the keys next to \Rightarrow or \Leftarrow until the desired menu is selected.
 - ⇒ The selected menu is highlighted in colour.
- ► To call up the menu, press the key next to **OK**
- The menu opens.

INFO

KRONE

For version with "Touch-sensitive terminal", the icons can be pressed directly.

By means of the scroll wheel

- Select the desired menu by means of scroll wheel.
 The selected menu is highlighted in colour.
- ► To call up the menu, press the scroll wheel.
- ➡ The menu opens.

For version with touch-sensitive terminal

By pressing the icons

- ► To call up a menu, press the icon (e.g.] .) in the display.
- ➡ The menu opens.

Leaving the menu

- **ESC** or press the adjacent key.
- ➡ The menu closes.

14.5 Changing value

Values must be entered or changed for the settings in the menus. The values are selected depending on used terminal (touch-sensitive or not touch-sensitive).

For version with "Touch-sensitive" and "Not touch-sensitive terminal"

• Via scroll wheel.



Additionally for "Touch-sensitive terminal" version

- By pressing or
- By tipping the blue value on the display.

If a numerical value is tapped, an input mask opens. For further information on entering values see the supplied terminal operating instructions.

Examples:

By means of the scroll wheel

- Choose the desired value by using the scroll wheel.
 - ⇒ The value is highlighted in colour.
- Press the scroll wheel.
 - ⇒ An input mask opens.
- ► Turn the scroll wheel to increase or reduce the value.
- Press scroll wheel to save the value.
- ➡ The setting is saved and the input mask closes.

Using the value

- Tap on the value.
 - \Rightarrow An input mask opens.
- Increase or reduce the value.
- ► In order to save the value, press **OK**
- The setting is saved and the input mask closes.

14.6 Changing mode

It is possible to select between different modes in individual menus.

- ► To select the next mode, press
- To select the previous mode, press
- To save, press
- An acoustic signal sounds, the set mode is saved and the icon is briefly displayed in the upper line.
- ► To leave the menu, press ESC .



14.7 Tying in the menu level

✓ For The menu level is active, see Page 154.

For the "Net wrapping" version



For the "net wrapping and twine tying" version and selected twine tying



EQG003-043

Depending on the equipment of the machine and the selected tying method, the tying menu items (1), (2) and (3) can look different on menu level.

For the "net wrapping and twine tying" version

Pos.	lcon	Explanation
1		Number of net layers (if net tying type was selected under (3))
		Number of twine layers (if twine tying type was selected under (3))
2 Tying start delay net wrapping (if net tyi		Tying start delay net wrapping (if net tying type was selected under (3))
	8	Tying start delay twine tying (if twine tying type was selected under (3))
3		Selecting type of tying (net or twine)

14.8 Menu 1 "Number of net layers" (net wrapping)



14.8 Menu 1 "Number of net layers" (net wrapping)



EQG003-000

- ✓ For The menu level is active, see Page 154.
- To open the menu, press
- ➡ The display shows the "Number of tying material layers" menu.

Selecting the number of tying material layers

- ▶ Increase or reduce the value, see Page 155.
- In order to save the value, press

14.9 Menu 1 "Number of twine layers" (twine tying)

This menu is used to set

- the number of twine layers to be tied around the round bale at the starting position before the twine is routed to the centre,
- the number of twine layers to be tied between the start position and the end position,
- the number of twine layers to be tied around the round bale at the end position before the twine is cut off.



EQG003-046

- ✓ For The menu level is active, see Page 154.
- ✓ Twine tying is selected in menu 8 "Type of tying", see Page 162.
- ▶ To open the menu, press
- ➡ The display shows the menu "Number of twine layers".

The following values can be set:



Icon	Explanation
	Number of twine layers at the start of twine tying
	Number of twine layers between the start and stop tying cycles
	Number of twine layers at the end of twine tying

Setting the number of twine layers

- ▶ Increase or reduce the value, see Page 155.
- In order to save the value, press



14.10 Menu 3 "Advance signalling"

Pre-signalling is used to warn if the round bale in the bale chamber is near completion. On the terminal you can set the filling for which pre-signalling starts.



EQG003-002

- ✓ For The menu level is active, see Page 154.
- ► To open the menu, press
- The display shows menu "Advance signalling".

Setting advance signalling

- Increase or reduce the value, see Page 155.
- ► In order to save the value, press

14.11 Menu 4 "Tying start delay"

Tying start delay is used to set the period of time which is required between completion of round bale in the bale chamber and triggering the tying cycle. The tying start delay is set in seconds.

旦

Setting range: 0.0-10 s

14.12 Menu 6 "Electronic baling pressure adjustment"





EQG003-003

- ✓ For The menu level is active, see Page 154.
- To open the menu, press
- ➡ The display shows the "Tying start delay" menu.

Setting the tying start delay

- ▶ Increase or reduce the value, see Page 155.
- In order to save the value, press

14.12 Menu 6 "Electronic baling pressure adjustment"



EQG003-016

- ✓ For The menu level is active, see Page 154.
- ► To open the menu, press
- The display shows the menu "Electronic baling pressure adjustment".

Setting the baling pressure

A different baling pressure can be set for the core, the centre and the edge of the round bale, and a diameter for the core. The following values are possible:



Menu 7 "Sensitivity of direction display" 14.13

	Baling pressure	Diameter
Core	(1) 0-100 %	(4) up to 80 cm
Middle	(2) 0-100 %	(5) Is calculated automatically from core and edge.
Edge	(3) 0-100 %	(6) Set bale diameter to be set via the working screen, <i>see Page 145</i> .

- ▶ Increase or reduce the value, see Page 155.
- In order to save the value, press



Setting the same baling pressure for the entire round bale





- ▶ Enter and save the required value (1) for the baling pressure, see Page 155.
- The baling pressure has been set the same for the entire round bale. The bale diameter for the entire round bale is set via the working screen, see Page 145.

Releasing the baling pressure

The baling pressure can be released for maintenance work at the baling belts or in the bale chamber.

- ▶ Press and keep it pressed for several seconds.
- The baling pressure is released and the status is displayed on the key:
- ► To build up the baling pressure, press 🔆 and keep it pressed for several seconds.

14.13 Menu 7 "Sensitivity of direction display"

This menu is used to set the sensitivity of the direction display.

The direction display indicates whether the swath is picked up in the centre by the pick-up and provides information about the required direction of travel. The higher the bar on the display, the more sensitive the direction display is set. The higher the sensitivity of the direction display is set, the stronger the motion indication appears in the form of arrows on the working screen.

14.14 Menu 8 "Select type of tying" (for the "Net wrapping and twine tying" version)



How the bale chamber is optimally filled by the pick-up, see Page 77.



EQG003-017

- ✓ For The menu level is active, see Page 154.
- To open the menu, press
- ➡ The display shows the "Sensitivity of direction display" menu.

Setting the sensitivity of the direction display

- ▶ Increase or reduce the value, see Page 155.
- In order to save the value, press

14.14 Menu 8 "Select type of tying" (for the "Net wrapping and twine tying" version)



EQG003-005

- ✓ For The menu level is active, *see Page 154*.
- To open the menu, press
- ➡ The display shows the "twine tying type selection" menu.

Changing the mode

Select and save the mode, see Page 156.

The following modes can be selected:



Icon	Explanation
	Net wrapping
	Twine tying

14.15 Menu 9 "Filling correction"

If the bale diameter is not reached or is too high, the filling correction can be used to correct the bale diameter within a pre-defined range (bale size -10 to +10 cm).

F	9 💽 🕇 🌑	
OK	10	
FSC	-10	DEF
	0 cm	

EQG003-018

- ✓ For The menu level is active, see Page 154.
- To open the menu, press
 To open the menu, press
- ➡ The display shows menu "Filling correction".

Adjusting the filling correction

- Increase or reduce the value, see Page 155.
- In order to save the value, press

Example

The set nominal bale diameter is 108 cm.

If the actual bale diameter is only 100 cm, which is 8 cm too small, a correction value of +8 cm must be set.

This means:

Correction value = nominal bale diameter - bale diameter

14.16 Menu 10 "Manual operation" (for the "Net wrapping" version)



14.16 Menu 10 "Manual operation" (for the "Net wrapping" version)

+ +	10	
OK		
FSC		FSC

EQG003-006

- ✓ For The menu level is active, see Page 154.
- ► To open the menu, select



➡ The display shows the "Manual operation" menu.

The following status displays may appear on the display:

Icon	Explanation
	Net motor is in feed position.
	Net motor is in the tying position.
	Tying actuator is in end position.
?	The position is not defined.

Use the keys on the sides to operate the following functions:

Icon	Explanation
	Move actuator for wrapping process to feed position
	Move actuator for wrapping process into tying position
	Moving the tying actuator to the end position

Moving the tying actuator

- ► To move the tying actuator into the feed position, press
- To move the tying actuator to the tying position, press
- ▶ Press to move the tying actuator the end position.

14.17 Menu 10 "Manual operation" (for version with "net wrapping and twine tying")



EQG003-115

- ✓ For The menu level is active, see Page 154.
- To open the menu, select
- ➡ The display shows the "Manual operation" menu.

(1) Twine tying

The following status displays may appear on the display:

lcon	Explanation
	Twine arms in feed position.
	Twine arms in start position.
	Twine arms in tying position.
	Twine arms in end position.

14.17 Menu 10 "Manual operation" (for version with "net wrapping and twine tying")



Icon	Explanation
	Twine arms in home position.
	Twine tying in undefined position.
	Twine arms cannot be moved because the tying actuator of the net wrapping is not in the end position.

Use the keys on the sides to operate the following functions:

Icon	Explanation
	Moving the twine arms to feed position
	Move twine arms into start position
	Moving the twine arms to end position
	Moving the twine arms to home position

Moving the twine arms

- Press it to move the twine arms to feed position.
- ▶ Press to move the twine arms to home position.

Moving the twine arms to start/end position

- ► To move the twine arms into the start position, press
- ▶ Press ▶ → to move the twine arms to the end position.

(2) Net tying

The following status displays may appear on the display:



Menu 11 "Correction of start/end position of the twine tying system (for 14.18 "net wrapping and twine tying" version)

Icon	Explanation
0	Net motor is in feed position.
	Net motor is in the tying position.
) *	Tying actuator is in end position.
?	The position is not defined.
	The actuator for the wrapping process cannot be moved be- cause the twine arms are not in home position.

Use the keys on the sides to operate the following functions:

lcon	Explanation
	Move actuator for wrapping process to feed position
	Move actuator for wrapping process into tying position
	Moving the tying actuator to the end position

Moving the tying actuator

- To move the tying actuator into the feed position, press
- To move the tying actuator to the tying position, press
- ss 🧿 🕯
- ► Press to move the tying actuator the end position.

14.18 Menu 11 "Correction of start/end position of the twine tying system (for "net wrapping and twine tying" version)

This menu is used to set

- the position on the outer edges of the round bale at which twine tying shall start (start position),
- the position at which twine tying shall stop in the centre of the round bale (end position).

14.18 Menu 11 "Correction of start/end position of the twine tying system (for "net wrapping and twine tying" version)



+	11			
OK	0-10		10	
FSC	-10 0	-> 4+	10	DEF
		_ ▶]∢+	÷	

EQG003-114

- ✓ For The menu level is active, see Page 154.
- Twine tying is selected in menu 8 "Type of tying", see Page 162. \checkmark
- To open the menu, press ►
- The display shows the "Correcting the twine tying start/end position" menu. ⇒

The following settings are possible:

Icon	Explanation
\bigcirc	Set start position.
->)(+	Values between –10 and 10 can be saved. The distance between the outer edge of the bale and the first twine layer is set here. The optimal start position can change as the crops change. Value towards -10: Tying starts further towards the bale centre Value towards 10: Tying starts further towards the outer edge of the bale
	Setting the end position.
->](+	Values between –10 and 10 can be saved. In doing so, one of the following can be set: either a small stripe without twine ty- ing remains free in the middle of the bale, or twine tying inter- sects in the middle.

- Increase or reduce the value, see Page 155.
- In order to save the value, press ►



(<u>)</u> KRONE

14.19 Menu 12 "Moisture measurement"



EQG003-112

- ✓ For The menu level is active, see Page 154.
- ► To open the menu, select
- ➡ The display shows the "Moisture measurement" menu.

The "Moisture measurement" menu is divided into the following menus:

Menu	Sub-menu	Designation
12		Moisture measurement (for version with "moisture measurement"), <i>see</i> <i>Page 169</i>
	12-1	Error message for moisture measurement, <i>see Page 169</i>
	12-2	Correction value for moisture measurement, <i>see Page 170</i>

14.19.1 Menu 12-1 "Error message for moisture measurement"

The error message 522078-15 "Moisture measurement upper limit" warns if the crops are too moist; see the supplement to operating instructions (software), chapter "Error list". The degree of moisture, i. e. when the error message is to appear, can be selected in this menu.

The error message for the display can also be deactivated or re-activated.

The lower limit value has been permanently set ex works and cannot be changed.



<u>*</u> ! *	+ +	¹²⁻¹	
	OK	100	
			ON
	ESC	0	ESC
		18%	

EQG003-141

- ✓ Menu 12 "Moisture measurement" has been selected.
- ► To open the menu, press
- The display shows the "Error message for moisture measurement" menu.

Setting upper limit value

- ▶ Increase or reduce the value, see Page 155.
- In order to save the value, press

Deactivating/activating error message



14.19.2 Menu 12-2 "Correction value for moisture measurement"

In this menu a correction value can be set for the moisture measurement if the displayed value deviates from the value of an external measuring system.



Menu 12 "Moisture measurement" 14.19

<u>%</u> ! %	+	12-2	
	→ OK	0	
			DEF
	ESC		ESC
		0,0 %	

EQG003-142

- ✓ Menu 12 "Moisture measurement" has been selected.
- To open the menu, press % 12
- ➡ The display shows the "Correction value for moisture measurement" menu.

Determining the moisture

- ▶ Using a calibrated moisture measuring system, determine the moisture of the crops.
- If the measured value matches the value (2) on the display, the moisture measurement has been correctly set.
- If the measured value does not match the value (2) on the display, the correction value (1) must be set.

Setting the correction value (1)

The correction value (1) to be set can be determined as follows:

Value (2) – measured value of the external moisture measuring system=correction value (1) Values between +10 and -10 can be set.

- ▶ Increase or reduce the value, see Page 155.
- In order to save the value, press

14.20 Menu 13 "Counters"



14.20 Menu 13 "Counters"

	8	t		+
		→		⇒
		OK		OK
🛛 🔊 t 🥙 🗍 🖤				
		ESC		ESC
	\$\$			

EQG003-011

- ✓ For The menu level is active, see Page 154.
- ► To open the menu, press
- ➡ The display shows the menu "Counter ".

The "Counter" menu is divided into the following submenus:

Menu	Sub-menu	Designation
13		Counter, see Page 172
	13-1	Customer counter, see Page 172
	13-2	Total counter, see Page 174

14.20.1 Menu 13-1 "Customer counter"

+	13-1	1
	•	● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ●
	1 NAME 01 2 NAME 02	
ESC	3 NAME 03	ESC
	NAME 04	

EQ003-054 / EQ003-228

- ✓ Menu 13 "Counter" is called." *see Page 172*.
- ► To open the menu, press



➡ The display shows menu 13-1 "Customer counter".

M KRONE

The menu displays a customer list. The names shown in blue can be adjusted, see Page 155.

- Navigate through the customer list using 1 or
- ► To activate a customer counter, navigate to the required customer and press **OK**
- The required customer counter is shown as:
- ► To open the detailed view of a customer, navigate to the required customer and press

Detailed view of a customer



EQG003-106

The icons displayed in the menu have the following meaning:

Icon	Explanation
1	Activated customer counter 1 20
Σ⊚	Total of pressed round bales for the respective customer
h	Operating hours counter for the corresponding customer

Use the keys on the sides of the terminal to operate the following functions:

lcon	Explanation
10	Increase number of bales
+0)	Reduce number of bales
	Setting displayed customer counter to zero





Icon	Explanation
1 +	Navigating between the detailed views of the customers
ОК	Activating displayed customer counter
	Returning to the complete overview of all customers

Changing the number of bales

The number of bales can be manually changed in the customer counter. The particular customer counter does not have to be activated for this.

- ► To increase the number of bales, press ↑
- ► To reduce the number of bales, press ↓)

Setting customer counters to zero

► To set the customer counter to zero, hold down for at least 2 seconds.

14.20.2 Menu 13-2 "Total counter"

+	13-2	Σ		
OK		Σ⊚	🕘 h	1
	Σ	0	0	2
ESC	Σ1	0	0	ESC
	Σ2	0	0	

EQG003-013

- ✓ Menu 13 "Counter" is called." see Page 172.
- To open the menu, press
- Σ.
- ➡ The display shows menu 13-2 "Total counter".

The icons that appear in the working screen have the following meaning:



Icon	Explanation
Σ	Total counter (cannot be deleted)
Σ1	Season counter 1 (can be deleted)
Σ2	Season counter 2 (can be deleted)
Σ	Total of pressed round bales
h	Operating hours counter

Use the keys on the sides of the terminal to operate the following functions:

lcon	Explanation
1	Setting season counter 1 to zero
2	Setting season counter 2 to zero

Set season counter 1 or 2 to zero

- To set season counter 1 to zero, press 11
- ► To set season counter 2 to zero, press

14.21 Menu 14 "ISOBUS"



EQG003-014

•

- ✓ The menu level is open, see Page 154.
- ► To open the menu, press
 - The display shows the "ISOBUS" menu.

ISOBUS

Depending on the machine equipment, the "ISOBUS" menu is divided into the following submenus:



Menu	Sub-menu	Designation
14		ISOBUS, see Page 175
(SOBUS		
	14-5	KRONE SmartConnect, see Page 176
	SmartConnect	
	14-6	Configuring TIM software (for "TIM 1.0" version), see
	TIM	Page 177
	14-9	Switching between terminals, see Page 178

14.21.1 Menu 14-5 "KRONE SmartConnect"

The access data for the KRONE SmartConnect (KSC) can be seen in this menu.

smartConnect	← → OK	14-5 WLAN-NAME: 00011501 WLAN-KEY: afbb2bfac5	↑ ↓
	ESC	PRODUCT-CODE: C0060000600011501	ESC

EQG000-064

- ✓ One or more KRONE SmartConnects have been installed.
- ✓ The menu 14 "ISOBUS" has been selected, see Page 175.
- ► To open the menu, press smartConnect
- ➡ The display shows the "SmartConnect" menu.



14.21.2 Menu 14-6 "Configuring TIM software" (for "TIM 1.0" version)



EQG003-015

- ✓ The menu 14 "ISOBUS" has been selected, see Page 175.
- Select (\overline{TIM}) to open the menu.
- ➡ The display shows the "Configuring TIM Software" menu.

The following displays are in the menu:

	TIM function "Stop tractor when the tying cycle starts".
៉	TIM function "Opening and closing tailgate at the end of the tying cycle".
¥ ₽	Control unit number of the tractor which is used to open and close the tailgate.
Brand: Model: Function Instance:	When a tractor has logged into the ISOBUS system, the designa- tions and the type of tractor appear here.

The keys can be used to operate the following functions. If the key is greyed out, the function is not available.

lcon		Explanation
		The tractor is not connected to the machine via TIM. If TIM functions have been selected, the key switches to
		Start registration and authentication of the TIM functions.
	TIM	Start TIM functions (can be selected only when tailgate closed).
	TIM	Stop TIM functions. In doing so, registration and authentic- ation are also disconnected between tractor and machine.
		Pause TIM functions. In doing so, registration and authen- tication are not disconnected between tractor and ma- chine.



Selecting TIM functions

- Select the checkbox each interaction in
- Select and input the control unit number of the tractor, see Page 155.
- ► To start establishing a connection between tractor and machine, press Tim
- Registration and authentication of the TIM functions are started.

Connecting machine and tractor to each other



When the TIM functions have been preselected, the checkboxes disappear and the TIM

status

is indicated on the display. The machine is being registered and authenticated

with the tractor.

The TIM status switches to



➡ The TIM status switches to _____. T



- Confirm the TIM activation on the terminal or on another control panel on the tractor.
- The TIM status switches to
- . The machine automatically takes over control of the

TIM functions on the tractor, see Page 145.

14.21.3 Menu 14-9 "Switching between terminals"

INFO

This menu is only available if several ISOBUS terminals are connected.

 (\bigcirc)



When the user switches terminals for the first time, the configuration of the machine is loaded into the next terminal. The loading process can take a few minutes. The configuration is stored in the memory of the next terminal.

Up to the next call, the machine is no longer available in the previous terminal.

When restarting, the system makes attempts to start the last used terminal. If the last used terminal is no longer available (e.g. because it was dismounted), the restart is delayed as the system searches for a new terminal and loads the specific menus into the terminal. The loading process can take a few minutes.



EQG003-035

- ✓ The menu 14 "ISOBUS" has been selected, see Page 175.
- To change to the next terminal, press

14.22 Menu 15 "Settings"

		•	
	→		•
	OK	0	Κ
2	ESC	ES	30

EQG003-036

- ✓ For The menu level is active, see Page 154.
- To open the menu, select 33 ***
- ➡ The display shows the "Settings" menu.

The "Settings" menu is divided into the following submenus:



Menu	Sub-menu	Designation
15		Settings, see Page 179

	15-1	Sensor test, see Page 180
	B	
	15-2	Actuator test, see Page 184
	15-3	Software information, see Page 186
	15-4	Error list, see Page 186

14.22.1 Menu 15-1 "Sensor test"

Danger of injury in the danger zone of the machine

If the PTO shaft runs during the sensor test, machine parts may start to move unintentionally. Thus there is a risk of serious injuries or death.

\Lambda WARNING

► Turn off PTO shaft.

In the sensor test, the sensors installed on the machine are checked for faults. Furthermore the sensors can be correctly set in the sensor test. There is no guarantee the machine is working correctly until after the sensors have been adjusted.



EQG003-030

- ✓ Menu 15 "Settings" is called, see Page 179.
- ► To open the menu, press
- ➡ The display shows the "Sensor test" menu.

The following keys can be available in the menu:


lcon	Designation
1	Choose previous sensor
ł	Choose next sensor
ESC	Exit menu

Settings for inductive proximity switches (NAMUR):

The minimum and maximum setting value with attenuated sensor (metal in front of the sensor) are shown in the upper part of the bargraph. The current setting value (actual value) is displayed under the bar display.

The distance from the sensor to the metal must be adjusted so that in the attenuated state the bar is in the upper marking. Then check whether the bar is in unattenuated state in the lower marked area.

Possible sensors (depending on the machine configuration)

An overview of the sensors, actuators and control units is in the circuit diagram.

No.	Sensor	Designation		
B01		Speed of bale chamber		
B02		Tying process active		
B06		Rotational speed deflection roll twine left side (for version "Net wrap- ping and twine tying")		
B07		Rotational speed deflection roll twine right side (for version "Net wrapping and twine tying")		
B08		Blade cassette up		
B09	B09 B IO	Filling indicator		
B11		Tailgate lock hook left		
B12		Tailgate lock hook right		
B15	B15 SQ →	Bale ejection		
B61		Tying 1 (passive)		
B63		Position tying mechanism twine (for version "Net and twine tying")		

14.22 Menu 15 "Settings"



No.	Sensor	Designation
B67		Blade pre-selection active
B68	B68 OFF	Blade pre-selection inactive
B69		Blade active
B82	^{B82} ፤⊚ī	Direction indicator
B83		Overload protection baling belts

Possible status displays of the sensors

Icon	Designation		
οΟΚ	Sensor ready for operation		
1	Sensor attenuated (metal in front of the sensor)		
2	Sensor unattenuated (no metal in front of the sensor)		
7 / 4	Cable break or short circuit		
₈ Error	Defective sensor or job computer		
20 🗾 📶	Cable break		
21	Short circuit		

14.22.1.1 Adjusting sensor B08 "Top blade cassette"



VariPack V 190 XC Original operating instructions 150001187_03_en-GB





EQG003-145

The sensor B08 "Blade cassette up" (1) sits on the right machine side in the lower area.

- Remove contamination from the area of the blade cassette (2).
- Adjust the distance between the sensor (1) and the metal such that the black bar in menu 15-1 "Sensor test" is in the upper marking when the sensor is attenuated.
- Check whether the black bar is in the lower marking when the sensor is unattenuated.

14.22.1.2 Adjusting sensor B61 "Tying 1 (passive)"



EQ003-106

- Menu 15-1 "Sensor test" is open. \checkmark
- The sensor B61 "Tying 1 (passive)" has been selected. √

Saving is only possible when the bar is in the lower or upper red rectangle of the bargraph. For details of the positions of the feed rocker arm, see Page 245.

- Approach the end position of the feed rocker arm by clicking on
- Ē When the bar is in the red rectangle, save the position by clicking on
- Approach the feed positions of the feed rocker arm by clicking on
- When the bar is in the red rectangle, save the position by clicking on
- Approach the tying position of the feed rocker arm by clicking on
- Check the tying position on the machine, see Page 245.



14.22.2 Menu 15-2 "Actuator test"



Risk of injury due to non-observance of the safety routines

If the relevant safety routines are not observed, persons may be seriously injured or killed.

▶ The safety routines must be read and observed to avoid accidents, see Page 27.

The actuator test is used to test the actuators installed on the machine. An actuator can only be tested when current is flowing through it. Therefore, in the "Actuator test" menu, the actuator must be controlled manually for a short time in order to determine possible errors in the actuator system.



EQG003-031

- ✓ Menu 15 "Settings" is called, see Page 179.
- ► To open the menu, press
 - \Rightarrow A warning opens which refers to the operating instructions.
- ▶ Observe the safety routine "Run actuator test", see Page 29.
- ► Confirm with **OK**
- ➡ The display shows the "Actuator test" menu.

The following keys can be available in the menu:

Icon	Designation
1	Choose previous sensor
¥	Choose next sensor
ON	Switching on the actuator
OFF	Switch off the actuator
ESC	Exit menu



Possible actuators (depending on how the machine is equipped)

An overview of the sensors, actuators and control units is in the circuit diagram.

No.	Actuator	Designation		
K01		Pick-up		
K03		Raising/lowering blade cassette		
K21		Blade control shaft A active		
E10		Warning beacon (for certain countries)		
E20/ E23/ E34	E20/E23/E34	Maintenance lighting for net roll and side hood right		
E22/ E33	E22/E33	Maintenance lighting side hood left		
M03	M03	Motor tying 3 (for version "Net wrapping and twine tying")		
Q26		Lowering the feed rocker arm		
Q27		Lifting the feed rocker arm		
Q41		Baling pressure		

Possible status displays of the actuators

Icon	Designation
	Actuator ON
² OFF	Actuator OFF
3 ~~/ 4	General actuator error
FUSEL	No supply voltage
₄ ─── ⁴	Possible cause: Fuse defective.



Diagnostics for digital actuators



EQG000-019

Errors are only displayed if the actuator is turned on and a test for the actuator in question is available. The LED on the plug can also be checked directly on the actuator.

- ► Press **ON** to switch the actuator on.
- ▶ Press **OFF** to switch the actuator off.

14.22.3 Menu 15-3 "Software info"

+	15-3	
→	•	
OK	VariPack	
ESC	SW: D2515020105300023 PRODUCT CODE:	ESC
	1050000	

EQG000-016

- ✓ Menu 15 "Settings" is called, see Page 179.
- ► To open the menu, press

➡ The display shows the "Software info" menu.

Display area

Icon	Designation
SW	Overall software version of the machine

14.22.4 Menu 15-4 "Error list"

All active and non-active errors are shown in this menu. The errors are shown with a number indicating how often the error occurred and the time on the operating hours counter when the error last occurred.

Terminal menus 14

Menu 15 "Settings" 14.22



L 1	15-4	
OK	KMC - 520192- 19	
ESC	🕘 1475 min	ESC

EQG000-060

- Menu 15 "Settings" is called, see Page 179. \checkmark
- To open the menu, press ž.
- The display shows menu "Error list". ⇒

Display area



EQ001-085 / EQ001-209

lcon	Designation	Explanation
KMC - 520192 - 19 CAN1 1 x 1 #1475 min	Active error	Cannot be deleted
KMC - 520192-19 CAN1 ↓ x 1 ↓ 1475 min	Non-active error	Can be deleted
(1)	Error number	 Meaning, cause and remedy of error message see Page 244.
(2)	Number	How often the error has occurred.
(3)	Operating hours counter time	 The time on the operating hours counter when the error last occurred.
	Delete individual errors	The selected error is deleted.Only non-active errors can be deleted.
	Delete all errors	All inactive errors are deleted.

Recurring icons see Page 153.

Delete individual errors

Only non-active errors (highlighted grey) can be deleted.

🖊 or

- To select the error to be deleted, press
- ► To delete the error, press

Delete all errors

Only non-active errors (highlighted grey) can be deleted.

► To delete all errors, press



15 Driving and transport



Risk of injury due to non-observance of relevant safety notices

If the relevant safety notices are not observed, persons may get seriously injured or killed.

To avoid accidents, the basic safety instructions must be read and observed, see Page 15.

A WARNING

Risk of injury due to non-observance of safety instructions

If the relevant safety routines are not observed, persons may be seriously injured or killed.

▶ The safety routines must be read and observed to avoid accidents, see Page 27.

MWARNING

Risk of accident from open stop cocks

Machine components could be moved unintentionally when stop cocks are open. This may result in serious accidents.

In order to avoid that functions are triggered by mistake, the stop cock/s must be closed during transport/road travel.



Risk of accident when cornering with a hitched machine

When cornering, the hitched machine swings out further than the tractor. This may result in accidents.

- Consider the larger swivel range.
- Consider people, oncoming traffic and obstacles when turning.

<u> WARNING</u>

Risk of accident caused by non-locked regulating valves of tractor

When regulating valves are not locked, machine components could be activated unintentionally. This may result in serious accidents.

To avoid that functions are triggered by mistake, the regulating valves of the tractor must be in neutral position when performing transport journeys on the road and must be locked.

NOTICE

Dangers from an automatic anti-jack-knife brake system on the tractor

In some cases, the braking behaviour of a machine connected to a tractor with continuously variable transmission that is equipped with an automatic anti-jack-knife brake system can negatively be influenced. If such an automatic anti-jack-knife brake system is activated for a longer period of time, e.g. on long downhill sections, it can overheat, which significantly reduces the braking performance of the machine brakes.

In addition, using an automatic anti-jack-knife brake system can lead to a significantly higher wear on the machine brakes.

15.1 Preparing the machine for road travel



15.1 Preparing the machine for road travel

- ✓ All items listed in chapter "Start-up" have been fulfilled, see Page 60.
- \checkmark The control units on the tractor are in neutral position and locked.
- ✓ The machine has been shut down and secured, see Page 27.
- ✓ All guards are properly closed and locked.
- ✓ The wheel chocks are secured in the supports / holders on the machine, see Page 83.
- ✓ The support jack is in the transport position, see Page 79.
- ✓ Ladders for the tying system have been folded up, see Page 82.
- ✓ The road lighting has been connected, tested and is functioning properly, see Page 63.
- ✓ The pick-up is fully raised in transport position, see Page 84.
- ✓ For "guide wheel support" version (only for certain countries): The guide wheel on the right machine side is removed and mounted at the drawbar, see Page 192.
- \checkmark The bale chamber is empty and the tailgate is closed.
- ✓ Soiling and crop residue have been removed from the machine, in particular from the lighting and identification elements.
- ✓ The tyres have no cuts and breaks.
- ✓ The tyre pressure is correct, see Page 50.
- ✓ With "Parking brake" version: The parking brake is released, see Page 81.
- \checkmark The permitted maximum speed of the machine is known and is maintained.
- ✓ For version with "Operation unit DS 100": The road travel screen has been called up, see Page 109.
- ✓ For the remaining terminals: The road travel screen has been called up, see Page 144.

15.2 Parking the machine

<u> WARNING</u>

Risk of injury due to the unsecured machine rolling away

If the machine is not secured against rolling away when it has been switched off, there is a risk of people being injured by the machine rolling away in an uncontrolled manner.

- Secure the machine against rolling using wheel chocks.
- Before uncoupling the machine from the tractor, completely close the tailgate.
- Shut down and safeguard the machine, see Page 27.
- Bring the support jack in support position, see Page 79.
- On the tractor side, loosen the supporting chain of the universal shaft, disengage the universal shaft, place it on the universal shaft support in case of lower suspension or suspend it from the universal shaft chain in case of upper suspension.
- Loosen the hitching device as specified in the operating instructions of the tractor manufacturer.
- When using a safety chain as an additional safety precaution for trailed implements: Remove the safety chain.
- ▶ Disconnect the road lighting plug, see Page 63.
- ▶ Remove the power supply cable for the terminal.
- Disconnect the hydraulic hose lines and hook them into the support at the machine.
- ▶ Drive the tractor away carefully.
- Fit the safety device which prevents unauthorised use and keep the key in a safe place, see Page 83.



15.3 Securing the universal shaft

If the universal shaft is not connected to the tractor, it must be secured on the drawbar with the universal shaft retaining chain or with the universal shaft bracket.

With top suspension of the drawbar



RPG000-118

- Insert the universal shaft (2) into the universal shaft chain (1).
- Attach the universal shaft chain (1) to the support (3).

With bottom suspension of the drawbar



RPG000-137

 Fold out the universal shaft bracket (1) and place the universal shaft on the universal shaft bracket (1). 15.4 Checking road travel lighting



15.4 Checking road travel lighting



RPG000-073

- Connecting road travel lighting to the vehicle electrical system, see Page 63.
- Check whether the rear lamps (1) are functional.
- Clean the rear lamps (1) and the side reflectors (2).



RPG000-074

• Clean the 2 reflectors (1) and the warning panels (2).

15.5 Dismounting the guide wheels of the pick-up for road travel

For "guide wheel support" version (only for certain countries)

For road travel, you can remove the guide wheel of the pick-up on the right-hand side of the machine to reduce the overall width of the machine to less than 2.55 m (depending on the currently installed tyres). Next, mount it on the drawbar for storage.

Driving and transport 15

KRONE

Preparing the machine for shipment 15.6



RPG000-239

- ▶ Lift the pick-up into the transport position, see Page 84.
- Shut down and safeguard the machine, see Page 27.
- ► To dismount the guide wheel (1), remove the linch pin (2).
- Rotate the holding arm (3) of the guide wheel (1) in the direction of the arrow and remove the guide wheel (1) together with the holding arm (3).
- ► Hold the guide wheel (1) at the handle (3) and pull it out in the direction of the arrow.
- ▶ Use the same procedure to dismount the guide wheel on the right-hand machine side.



RPG001-240

- Insert the holding arm (3) of the guide wheel (1) into the boreholes (2) of the guide wheel support.
- Move the perforated bar (5) so that the perforated bar (5) rests on the support (4).

15.6 Preparing the machine for shipment

🕂 WARNING

Risk of accident due to unsecured machine parts

If the machine is not secured properly for transportation on a lorry or train, the parts may come loose unintentionally due to the airstream. This may result in serious accidents or damage to the machine.

Carry out the following measures to secure moving machine parts.

15.6.1 Checklist for the transport of the machine

- ✓ All guards are properly closed and locked.
- Ladders for the tying system have been folded up, see Page 82.
- ✓ The universal shaft is secured, see Page 191.

15.6 Preparing the machine for shipment



- \checkmark The hydraulic hoses are secured on the machine against dropping.
- ✓ Using a hoist with a minimum lifting capacity, the machine was lifted at the marked suspension points, see Page 194. The minimum load capacity depends on the permissible total weight of the machine, see Page 49.
- ✓ The machine is secured with suitable lashing material at the designated lashing points, see Page 195.
- ✓ The machine was loaded on a lorry or train in the direction of travel.
- \checkmark The operation unit or the terminal is stowed away in a safe and dry place.
- ✓ For "SMV emblem" version: The SMV emblem is covered or removed, see Page 41.

15.6.2 Securing the front hood



RPG001-244

- \checkmark The front hood (1) is closed and locked into place.
- To secure the front hood (1), run a cable tie (3) around the locking bracket (2) and the strut (4) of the net holder.
- ► Tighten the cable tie (3).

15.6.3 Lifting the machine

WARNING Risk of injury due to raised machine There is danger to persons when the machine drops or parts swing without control. Only qualified personnel are allowed to perform this work. Use only permitted hoists and slings with a sufficient load-bearing capacity. For the weights see Page 49. Note the information on the suspension points provided. Make sure the lifting means are properly secured. Never stay under the suspended machine. If work has to be performed under the machine, securely support the machine, see Page 28.

The machine is equipped with 3 suspension points.





RPG000-216

There are 2 suspension points (1) at the top, next to the bale formation conveyor.

Ensure that a load beam (2) is used when the machine is lifted.



RPG000-217

1 suspension point is located in the front area of the drawbar (1).

To lift the machine, a hoist must be used which has a minimum load bearing capacity depending on the permitted total weight of the machine, see type plate on the machine, see Page 44.

- \checkmark The machine has been shut down and secured, see Page 27.
- Close the tailgate.
- Lift the pick-up into the transport position, see Page 84.
- Ensure that all safety devices are locked.
- Ensure that the universal shaft, hydraulic lines and cables have been secured.
- Attach the chains of the hoist to the suspension points on the machine.
- Ensure that the chain hooks have been correctly attached to the suspension points.
- Tension the chains so that the support jack is relieved.
- Move the support jack into transport position, see Page 79.

15.6.4 Lashing the machine

\Lambda WARNING

Danger to life caused by uncontrolled machine movement

If the machine is not properly lashed for transportation by vehicle, the machine may move in an uncontrolled manner and endanger people.

Before transporting the machine, secure it properly to the designated lashing points using suitable lashing material.



The lashing points on the machine are identified with an information label, see Page 34.



RPG000-219

1 2 lashing points at the front



RPG000-220

1 2 lashing points at the rear (one on the left and one on the right machine side)



16 Settings

MWARNING

Risk of injury due to non-observance of relevant safety notices

If the relevant safety notices are not observed, persons may get seriously injured or killed.

To avoid accidents, the basic safety instructions must be read and observed, see Page 15.

A WARNING

Risk of injury due to non-observance of safety instructions

If the relevant safety routines are not observed, persons may be seriously injured or killed.

▶ The safety routines must be read and observed to avoid accidents, see Page 27.

16.1 Setting the baling pressure

For version with "DS 100"

The baling pressure is set on the operation unit, see Page 114.

For the remaining terminals

The baling pressure is set on the terminal via Menu 6 "Electronic baling pressure adjustment", see Page 160.

16.2 Setting the bale diameter

For version with "operation unit DS 100"

The bale diameter is set via the operation unit, see Page 112

For the remaining terminals

The bale diameter is set via the working screen on the terminal, see Page 145.

16.3 Setting net overhang on the wrapping material brake



RPG000-163



The wrapping material brake (2) is located at the front on the left side of the machine.

The wrapping material brake (2) decelerates the yellow net prestretching roll (1) after the net has been cut off. It controls how much net protrudes between the rubber pads after each tying cycle under the spreading roll. The brake force is set using the 3 screws (4).

The net must protrude approx. **10 cm** between the rubber pads, see Page 96.

Default dimension of the 3 springs (3) set by KRONE: X=24 mm

- ✓ The machine has been shut down and secured, see Page 27.
- ✓ The left side hood is open.
- Check the net overhang between the rubber .

If the net overhang is too long, increase the brake force:

• Reduce the dimension X.

If the net overhang is too short, reduce the brake force:

Increase the dimension X.

16.4 Setting rubber cloth on the net wrapping



RPG000-200

If the rubber cloth (1) is worn and is no longer 2-3 cm at full width on the feed roller, it can be set.

- ✓ The machine has been shut down and secured, see Page 27.
- Loosen the screw connections and push the bale cloth in the oblong holes until it is 2-3 cm on the feed roller.
- ▶ If this setting is not adequate, replace the bale cloth (1).

16.5 Adjusting the twine tension at the twine box



RP001-033

KRONE

The twine tension at the outlet eyelets of the twine box (1) is used to adjust the tightness of the tying twine (4) as it runs through the machine. This can change as tying twines and working conditions change. It should be adjusted as loosely as possible so that the tying twine (4) can be pulled as easily as possible when tying is started. All the same, the tying twine (4) should be taut inside the machine so that vibrations or the like will not pull it out of the machine.

At the factory, the springs (2) are adjusted to a distance of X=40 mm.

- ✓ The machine has been shut down and secured, see Page 27.
- ✓ The right-hand side hood is open.

Use the same setting for all 4 screws on the top and bottom twine (4):

- ▶ To increase the twine tension, use the nut (3) to reduce the distance X.
- To reduce the twine tension, use the nut (3) to increase the distance X.

16.6 Adjusting the twine tension at the twine brake



The twine tension on the twine brake (2) is used to adjust the tightness at which the twine (1) is guided to the round bale. This permits the twine to be distributed consistently tight on the round bale during the tying cycle. This twine tension can change as tying twine and working conditions change.

There is one twine brake (2) on the top tying twine on the right side and one twine brake on the bottom tying twine on the left side, which must be adjusted in the same way.

- ✓ The machine has been shut down and secured, see Page 27.
- ✓ The twine is inserted, see Page 101.
- To increase the twine tension, use the nut (3) to increase the tightness of the twine brake (2).
- ▶ To reduce the twine tension, loosen the twine brake (2) at the nut (3).

16.7 Checking/adjusting blades at the twine tying system

<u> WARNING</u>

Risk of injury on the sharp blade of the twine tying system

There is a risk of injury to fingers and hands when adjusting the blade on the twine tying system.

- Wear protective gloves when you adjust the blade on the twine tying system.
- Be particularly careful when you work on the twine tying system in the vicinity of the blade.

16.7 Checking/adjusting blades at the twine tying system





RP001-037

Two blades (5) are installed on the blade support (2).

- Check to ensure that the edges of the blade support (2) and the blade arm (1) are parallel to each other.
- Check also to ensure that the blade support (2) is pushed up to the borehole (3).
- ▶ If this is not the case, loosen the screw connections (4) and move the blade support (2).

(¹) KRONE

16.8 Setting oil quantities for the central chain lubrication unit



RPG000-135

The central chain lubrication system is located on the left side of the machine behind the side hood.

With each revolution of the drive shaft, the oil pump (11) pumps oil from the tank (12) through the outlets (1), (2), (3), (4), (5), and (6) to the oil brushes on the drive chains.

To service the central chain lubrication system, see Page 233.

Setting oil volumes

The oil quantities for the individual brushes of the central chain lubrication system can be increased or reduced at the oil pump (11).

To set the oil quantities, the setting screws (8), (9) or (10) are turned. One complete turn corresponds to a quarter of the maximum oil quantity.

For an overview of the oil brushes on the machine, see Page 234.

- ✓ The machine has been shut down and secured, see Page 27.
- Unscrew the cover (7) on the oil pump.
- ► To increase the oil quantity, turn the required setting screw (8), (9) or (10) clockwise.
- ► To reduce the oil quantity, turn the required setting screw (8), (9) or (10) anti-clockwise.

The setting screws are assigned as follows:

Pos.	Oil lubrication for	setting screw
(1)	Drive no. 1 – baling unit	(8) white
(2)		
(3)	Drive no. 2 – rotor	(9) red
(4)		
(5)	Drive no. 3 – feed roller and starter roller	(10) orange



Pos.	Oil lubrication for	setting screw
(6)	Drive no. 3 – feed roller and starter roller	(10) orange

16.9 Setting the cutting length



The cutting length is determined by the number of blades used. For this purpose, the blade groups are swivelled in or out using the blade control shaft (1).

Cutting length	Number of blades	Blade group A	Blade group B
-	0	off	off
128 mm	8	off	on
128 mm	9	on	off
64 mm	17	on	on

Swivel the required blade groups in or out, see Page 92.

16.10 Setting the bale ejector



RPG000-167

The bale ejector (1) can be set in 3 positions (Position I, II and III).

Position	Explanation
1	Round bales up to 165 cm
П	Round bales up to 190 cm
III	For soft ground

✓ The machine has been shut down and secured, see Page 27.



Make the following setting on both tips of the bale ejector (1) in the same way:

- Dismount the linch pin (2) and the bolt.
- Pull out the extension (3) in the direction of the arrow until the required position (I), (II) or (III) has been reached.
- Mount the bolt and the linch pin (2). Ensure that the linch pin is mounted from the outside.

17.1 Maintenance table



17 Service & maintenance

<u> WARNING</u>

Risk of injury due to non-observance of relevant safety notices

If the relevant safety notices are not observed, persons may get seriously injured or killed.

To avoid accidents, the basic safety instructions must be read and observed, see Page 15.

<u> WARNING</u>

Risk of injury due to non-observance of safety instructions

If the relevant safety routines are not observed, persons may be seriously injured or killed.

▶ The safety routines must be read and observed to avoid accidents, see Page 27.

17.1 Maintenance table

17.1.1 Maintenance – Before the season

Checking oil level	
Main gearbox	see Page 217
Chain lubrication unit	see Page 234
Components	
Adjust drive chains	see Page 231
Tighten screws/nuts on the machine	see Page 212
Retightening wheel nuts	see Page 216
Check tyre pressure	see Page 215
Check the fire extinguishers	see Page 225
Cleaning bushing and drawbar eye	see Page 219
Clean the filter on the central chain lubrication system	see Page 234
Drain condensation water out of the com- pressed air tanks of the compressed air brake	
Checking and adjusting the cleaning rollers	see Page 221
Lubricate the machine according to the lubric- ation chart	see Page 207
Actuate tying cycle and check functions	see Page 79
Check hydraulic hoses	see Page 218
Check the electrical connection cables and, if necessary, have them repaired or changed by a KRONE service partner	
Removing corrosion from net support / holder	see Page 225



17.1.2 Maintenance – After the season

Components	
Clean the machine	see Page 218
Lubricate the machine according to the lubric- ation chart	see Page 207
Lubricate the universal shaft	see Page 211
Grease the threads of the setting screws	
Drain condensation water out of the com- pressed air tanks of the compressed air brake	
Cleaning drive chains	see Page 220
Grease the uncoated piston rods of all hy- draulic cylinders and insert as far as possible	
Lightly coat with oil all those lever joints and bearing positions which cannot be lubricated	
Touch up damaged paint and preserve un- coated areas with rust protection agent	
Check that all moveable components move freely. If required, dismount, clean, grease and remount.	
Park the machine in a weatherproof and dry location which is not in close proximity to corrosive substances	
Protect the tyres against external influences such as oil, grease or direct sunlight	

17.1.3 Maintenance – once after 10 hours

Components		
Retightening wheel nuts	see Page 216	
Tighten the screw connections on the drawbar	see Page 221	
Check tyre pressure	see Page 215	
Have the slack adjuster of the brake system checked	Only by KRONE service partner, see manual for service technicians	
Check the hydraulic hoses for leaks and, if ne- cessary, have them replaced by a KRONE service partner.	see Page 218	
Cleaning bushing and drawbar eye	see Page 219	
Change/replace blades	see Page 226	
Check running behaviour of the baling belts and adjust if required	Only by KRONE service partner, see manual for service technicians	

17.1.4 Maintenance – once after 50 hours

Changing oil

Main gearbox	see Page 217

17.1 Maintenance table



17.1.5 Maintenance – Once after 500 round bales

Components

Checking and adjusting the cleaning rollers see Page 221

17.1.6 Maintenance – every 10 hours, at least daily

Checking oil level		
Main gearbox	see Page 217	
Components		
Clean the machine	see Page 218	
Check the fire extinguishers	see Page 225	
Check function of the brake system		
Cleaning bushing and drawbar eye	see Page 219	

17.1.7 Maintenance – every 50 hours

Components	
Tighten screws/nuts on the machine	see Page 212
Tighten the screw connections on the drawbar	see Page 221
Retightening wheel nuts	see Page 216
Check tyre pressure	see Page 215
Drain condensation water out of the com- pressed air tanks of the compressed air brake	

17.1.8 Maintenance – Every 250 hours

Components	
Check the fire extinguishers	see Page 225

17.1.9 Maintenance – every 500 hours

Changing oil	
Main gearbox	see Page 217

17.1.10 Maintenance – Every 1,000 round bales

Components	
Check running behaviour of the baling belts and adjust if required	Only by KRONE service partner, see manual for service technicians



17.1.11 Maintenance – Every 2 years

Components

components	
Have compressed-air tanks checked by KRONE service partner	
Have pneumatic brake cylinders serviced by KRONE service partner	

17.2 Lubrication chart

NOTICE

Damage to bearing points

When using lubricating greases not approved and when mixing different lubricating greases, the lubricated parts may be damaged.

- Only use approved lubricating greases, *see Page 53*.
- Do not use graphite-containing lubricating greases.
- ▶ Do not mix different lubricating greases.

NOTICE

Environmental damage caused by consumables

If consumables are not stored and disposed of properly, they may escape into the environment. As a result, the environment will be damaged, even by small quantities.

- Store the consumables in suitable containers according to the statutory provisions.
- Dispose of used consumables according to statutory provisions.

The information on maintenance intervals is based on average load of the machine. In case of an increased load and under extreme working conditions, the time periods must be reduced. The types of lubrication are marked by means of icons in the lubrication chart, refer to table.

Type of lubrication	Lubricant	Comment
Grease	Multi-purpose grease	 Apply two strokes of lubricating grease from the grease gun per grease nipple.
		 Remove excess lubricating grease at the grease nipple.

17.2 Lubrication chart



Left side of machine



RPG000-169







17.2 Lubrication chart



Right side of machine







Use a different lubricating grease for this lubrication point, *see Page 53*.

17.3 Lubricating the universal shaft



RP000-176

- ✓ The machine has been shut down and secured, see Page 27.
- Observe operating instructions of the universal shaft manufacturer.
- Clean the universal shaft.
- Lubricate the universal shaft with multi-purpose grease at the intervals indicated in the table below.

For a list of the lubricating greases to be used, see Page 52.

The following table provides information about the lubricant quantity and the lubrication interval per lubrication point.

17.4 Tightening torques



Pos.	Lubricant quantity	Lubrication interval
(1)	18 g	50 hours
(2)	30 g	
(3)	20 g	
(4)	6 g	

17.4 Tightening torques

Deviating tightening torques

All screw connections must in general be tightened with the listed tightening torques following. Deviations from the tables are marked accordingly.

Metric thread screws with control thread

INFO

The table does not apply to countersunk screws with hexagon socket in case the countersunk screw is tightened via hexagon socket.



DV000-001

X Thread size

Strength class on screw head

X	Strength class			
	5.6	8.8	10.9	12.9
	Tightening torque	e (Nm)		
M4		3.0	4.4	5.1
M5		5.9	8.7	10
M6		10	15	18
M8		25	36	43
M10	29	49	72	84
M12	42	85	125	145
M14		135	200	235
M16		210	310	365
M20		425	610	710
M22		571	832	972

1



Tightening torques 17.4

X	Strength class			
	5.6	8.8	10.9	12.9
	Tightening torque (Nm)			
M24		730	1,050	1,220
M27		1,100	1,550	1,800
M30		1,450	2,100	2,450

Metric thread screws with fine thread



DV000-001

X Thread size

Strength class on screw head

X	Strength class				
	5.6	8.8	10.9	12.9	
	Tightening torque	e (Nm)			
M12 x 1.5		88	130	152	
M14 x 1.5		145	213	249	
M16 x 1.5		222	327	382	
M18 x 1.5		368	525	614	
M20 x 1.5		465	662	775	
M24 x 2		787	1,121	1,312	
M27 x 2		1,148	1,635	1,914	
M30 x 1.5		800	2,100	2,650	

1

Metric thread screws with countersunk head and hexagon socket

INFO

The table applies only to countersunk screws with hexagon socket and metric thread tightened via hexagon socket.





- DV000-000
- X Thread size

Strength class on screw head

X	Strength class			
	5.6	8.8	10.9	12.9
	Tightening torque	e (Nm)	_	
M4		2.5	3.5	4.1
M5		4.7	7	8
M6		8	12	15
M8		20	29	35
M10	23	39	58	67
M12	34	68	100	116
M14		108	160	188
M16		168	248	292
M20		340	488	568

1

Locking screws on the gearboxes

INFO

The tightening torques only apply to assembly of locking screws, viewing glasses, ventilation and breather filters and bleed valves in gearboxes with cast housings or aluminium or steel housings. The term "locking screw" includes the drain plug, the inspection screw as well as the ventilation and breather filters.

This table applies only to locking screws with external hexagon in connection with copper seal ring and for bleed valves made of brass with shaped seal ring.

Thread	ad Locking screw and sight glass with copper ring ¹ Ventilation/breather filter made of steel Steel and cast Aluminium Maximum tightening torque (Nm) (±10%		Bleed valve made of b Ventilation/breather fi brass	orass Iter made of
			Steel and cast	Aluminium
			6)	
M10x1			8	
M12x1.5			14	
G1/4"			14	
M14x1.5			16	

() KRONE

Thread

E	Checking/maintaining tyres	17.5
Locking screw and sight glass with	Bleed valve made of brass	
copper ring'	Ventilation/breather filter made of	

	copper ring.		Ventilation/breather filter made of		
	Ventilation/breather filter made of steel		brass		
	Steel and cast	Aluminium	Steel and cast	Aluminium	
	Maximum tighten	ing torque (Nm) (±10	%)		
M16x1.5	45	40	24	24	
M18x1.5	50	45	30	30	
M20x1.5			32		
G1/2"			32		
M22x1.5			35		
M24x1.5			60		
G3/4"			60		
M33x2			80		
G1"			80		
M42x1.5			100		
G1 1/4"			100		

¹ Always replace copper rings.

17.5 Checking/maintaining tyres

✓ The machine has been shut down and secured, see Page 27.

Inspect the tyres visually

- Visually inspect tyres for cuts or breaks.
- If there are cuts or breaks in the tyres, have the tyres repaired or replaced by a KRONE service partner.

Maintenance intervals for visual inspection of the tyres, see Page 204.

Checking/adapting the tyre pressure

- Check the tyre pressure, see Page 50.
- ➡ If the tyre pressure is too high, deflate air.
- ➡ If the tyre pressure is too low, increase the tyre pressure.

Check the maintenance intervals for tyre pressure, see Page 204.



Retighten wheel nuts



DVG000-002

Retighten the wheel nuts crosswise (as shown) with a torque wrench, tightening torque see Page 216.

Maintanance intervals, see Page 204.

Tightening torque: wheel nuts

Thread	Key size	Amount of bolts per hub	Maximum tightening torque	
			black	galvanised
M12x1.5	19 mm	4/5 units	95 Nm	95 Nm
M14x1.5	22 mm	5 units	125 Nm	125 Nm
M18x1.5	24 mm	6 units	290 Nm	320 Nm
M20x1.5	27 mm	8 units	380 Nm	420 Nm
M20x1.5	30 mm	8 units	380 Nm	420 Nm
M22x1.5	32 mm	8/10 units	510 Nm	560 Nm
M22x2	32 mm	10 units	460 Nm	505 Nm
M KRONE

17.6 Servicing the main gearbox



RPG000-089

The main gearbox (1) is located behind the drawbar in the front area of the machine. The locking screw (2) for draining the oil is located on the underside of the main gearbox (1). The locking screw of the inspection and filling hole (3) is located on the main gearbox (1).

Maintenance intervals: see Page 204

Amount and type specifications of the oil: see Page 52

- ✓ The machine is horizontal on stable and level ground.
- ✓ The machine has been shut down and secured, see Page 27.
- ✓ The drawbar height has been set correctly, see Page 56.

Checking oil level

NOTE! Risk of machine damage due to improperly performed oil level check, oil and filter element change! Follow the safety routine "Oil level check. Changing oil and filter elements safely", see Page 28.

- ▶ Remove the locking screw from the inspection and filling hole (3).
 - \Rightarrow The oil must reach the inspection and filling hole (3).

If the oil reaches the inspection and filling hole (3):

Screw the locking screw into the inspection and filling hole (3), tightening torque see Page 214.

If the oil does not reach the inspection and filling hole (3):

- Top up with fresh oil via the inspection and filling hole (3) up to the inspection and filling hole (3).
- Screw the locking screw into the inspection and filling hole (3), tightening torque see Page 214.

17.7 Checking hydraulic hoses



Changing the oil

✓ A suitable container is available for escaping oil.

NOTE! Risk of machine damage due to improperly performed oil level check, oil and filter element change! Follow the safety routine "Oil level check. Changing oil and filter elements safely", *see Page 28*.

- Remove the locking screw from the inspection and filling hole (3).
- Remove the locking screw (2) from the oil drain.
- Collect the oil in a container.
- Screw in the locking screw (2), see Page 214.
- ▶ Pour in fresh oil via the inspection and filling hole (3) up to the inspection and filling hole (3).
- Screw the locking screw into the inspection and filling hole (3), tightening torque see Page 214.

17.7 Checking hydraulic hoses

Hydraulic hoses are subject to natural aging. This limits their service life. The recommended service life is 6 years, including a maximum storage time of 2 years. The date of manufacture is printed on the hydraulic hoses. When checking hydraulic hoses, the state-specific conditions (e.g., BGVU) must be observed.

Performing a visual inspection

Visually inspect all hydraulic hoses for damage and leaks and have them replaced by an authorised specialist if necessary.

17.8 Cleaning the machine





NOTICE

Machine damaged by water from a high-pressure cleaner

Bearings and electric or electronic components can be damaged if you aim the water jet of a high-pressure cleaner directly at them during cleaning.

- Never direct the water jet of a high-pressure cleaner at bearings, electric/electronic components or safety labels.
- ► Replace missing, damaged and unrecognisable safety labels.
- ✓ The machine has been shut down and secured, see Page 27.
- After each use, clean the following areas on the machine, preferably with compressed air:
- the complete area around the tying,
- the drive wheels and the upper compression roller in the front bale chamber.
- the lower drive roller
- the deflection roller of the baling belts
- Also after each use, clean all moving parts on the brake linkage and brake lever with compressed air, e.g. piston rod, brake lever and slack adjuster. This can prevent mechanical blockages.
- ▶ Remove crop build-up from the drive chains using compressed air.
- Ensure that the drive chains are sufficiently wetted with engine oil after cleaning.
- ▶ If necessary, repeat the cleaning several times a day.
- After the machine has been cleaned with water, lubricate all manually lubricated lubrication points, see Page 207.

17.9 Clean the bushing and the drawbar eye



RPG000-189

The drawbar eye must always be coupled horizontally in the towing hitch. The wear limit of the socket (1) in the drawbar eye (2) is **X=43 mm**. If the dimension X is exceeded, the drawbar eye (1) must be replaced by a KRONE service partner.

To minimize wear, clean the bushing (1) and the drawbar eye (2) several times a day and coat with grease.

17.10 Cleaning drive chains



17.10 Cleaning drive chains

At the end of the season the machine drive chains must be cleaned.

- ✓ The machine has been shut down and secured, see Page 27.
- Clean the drive chains with compressed air.
- Wet the cleaned drive chains with engine oil.
- Start up the machine to distribute the engine oil on all contact surfaces.

The drive chains must always be adequately wetted with engine oil.

During operation, this is done by the chain lubrication unit, see Page 233.

- Shut down and safeguard the machine, see Page 27.
- Check the drive chains and sprocket wheels for wear.
- Check that the drive chains are centred on the sprocket wheels.
- Check that the drive chains have been properly adjusted, see Page 231.

17.11 Relieving baling belts



RPG000-147

Using the lever (1), you can move the tensioning rocker arms to a position where the tension of the baling belts is relieved for maintenance work or troubleshooting on the deflection rolls. The baling belts can then be pushed sideways to allow access to the deflection rolls.

- \checkmark The tailgate is closed.
- ✓ The left side hood is open.
- ► To move the tensioning rockers into position, move the lever (1) in the direction of the arrow and engage it behind the support / holder (2).
- ► To open the tailgate fully, actuate the control unit on the tractor (red, 1+).
- ▶ To close the tailgate to approx. halfway, actuate the control unit on the tractor (red, 1+).
- The baling belts are relieved and can be moved.
- ▶ To secure the tailgate, close the stop cock, see Page 80.
- Switch off the tractor, remove the ignition key and take it with you.

(¹) KRONE

17.12 Checking the screw connections on the drawbar



RPG000-088

- ✓ The machine has been shut down and secured, see Page 27.
- Check that the screw connections (1) and (2) have been tightened to the correct tightening torque.
- ► Tighten the screw connections (1) on the drawbar to the tightening torque **210 Nm**.
- Tighten the screw connections (2) on the drawbar eye to the tightening torque **730 Nm**.
 Maintenance interval, see Page 204.

17.13 Checking and adjusting the cleaning rollers

For "Cleaning rollers" version



RP001-274

Here, the left side of the machine is shown as an example.

- 1 cleaning roller
- 2 Drive shaft

- 3 Deflection shaft
- 4 cleaning roller

The 2 cleaning rollers (1) and (4) in the bale chamber ensure that crops are removed from the drive shaft (2) and the deflection shaft (3) at the bottom of the tailgate during operation. They must be checked and adjusted if there are too much crops wrapped around them.

Maintenance interval: see Page 204



17.13.1 Cleaning roller on the drive shaft

Checking the cleaning roller



RP001-273

The distance between the cleaning roller (1) and the drive shaft (2) must be X=3 ... 4 mm.

- ▶ Relieve the baling belts, see Page 220.
- Open the tailgate completely and secure it with the stop cock, see Page 80.
- Shut down and safeguard the machine, see Page 27.
- Check the distance between the cleaning roller (1) and the drive shaft (2).

Adjusting the cleaning roller



RP001-272

- ✓ The machine has been shut down and secured, see Page 27.
- Loosen the screw connections (4) of the setting sheet (2) and move the sheet in the oblong holes (3). This moves the cleaning roller too.
 - ⇒ The distance between the cleaning roller and the drive shaft increases as the setting sheet (2) is moved upwards.
- ► Tighten the screw connection (4).

(^M) KRONE

Service & maintenance 17

Checking and adjusting the cleaning rollers 17.13



RP001-277

✓ The machine has been shut down and secured, see Page 27.

Adjust the cleaning roller on the right side of the machine to the same distance:

- Loosen the chain (6) and remove it from the sprocket wheel (5).
- ▶ Dismount first the grinding block (7), then the sprocket wheel (5).
- Loosen the screw connections (4) of the setting sheet (2) and move the sheet in the oblong holes (3). This moves the cleaning roller too.
 - ⇒ The distance between the cleaning roller and the drive shaft increases as the setting sheet (2) is moved upwards.
- Check the distance X between the cleaning roller and the drive shaft again.
- ➡ The distance is correct when it is X=3 ... 4 mm.
- Readjust the cleaning roller if the distance is not **X=3 ... 4 mm**.
- ▶ Tighten the screw connection (4).
- Mount first the sprocket wheel (5), then the grinding block (7).
- Mount the chain (6) and adjust it if necessary, see Page 231.



17.13.2 Cleaning roller on the bottom deflection shaft in the tailgate

Checking the cleaning roller



RP001-275

The distance between the cleaning roller (2) and the deflection shaft (1) must be **X=3** ... 4 mm.

- Relieve the baling belts, see Page 220.
- Open the tailgate completely and secure it with the stop cock, see Page 80.
- Shut down and safeguard the machine, see Page 27.
- Check the distance between the cleaning roller (2) and the deflection shaft (1).

Adjusting the cleaning roller



RP001-276

Make the following setting on the right and left sides of the machine in the same way:

- ✓ The machine has been shut down and secured, see Page 27.
- Loosen the screw connection (1) of the cleaning roller.
- Move the cleaning roller in the oblong hole to move it towards the deflection shaft.
- Check the distance between the cleaning roller and the deflection shaft again.
- ➡ The distance is correct when it is X=3 ... 4 mm.
- Readjust the cleaning roller if the distance is not **X=3 ... 4 mm**.
- ▶ Tighten the screw connection (1) of the cleaning roller.

Tightening torques: see Page 212.



17.14 Checking the fire extinguisher

For "support for fire extinguisher" version



BPG000-034

- ✓ The machine has been shut down and secured, see Page 27.
- Ensure that the fire extinguisher (1) is mounted on the machine.
- Ensure that access to and view of the fire extinguisher (1) are not obstructed.
- ▶ Ensure that the fire extinguisher (1) is filled by weighing the fire extinguisher (1).
- Ensure that the seal on the extinguishing head and the security seal are neither defective nor missing.
- Ensure that the operating instructions on the type plate of the fire extinguisher (1) are legible and face outwards.
- Check the fire extinguisher for visible material damage, corrosion, leakage, a clogged hose and/or nozzle.
- Ensure that the pressure gauge pointer indicates the green area.

17.15 Removing corrosion from net support / holder



RPG000-157

▶ Before starting the new season, remove corrosion from the net support / holder (1).



17.16 Releasing the cam clutch on the universal shaft

If the cam clutch was actuated during the baling process on the universal shaft due to an overload, proceed as follows:

- Switch off the PTO shaft.
- Switch on the PTO shaft at a lower idle speed until the cam clutch has engaged.
- ▶ Shift up the PTO shaft to rated speed.

17.17 Briefly deactivating cutting unit and pick-up

When performing maintenance work, e.g. when changing blades, the cutting unit and the pickup can be mechanically deactivated for a short time.



RPG000-162

- ✓ The machine has been shut down and secured, see Page 27.
- ✓ The right side hood is open.
- To deactivate the cutting unit and the pick-up, move the lever (1) in the direction of the arrow.
- Before restarting the machine, activate the cutting unit and the pick-up and move the lever (1) against the direction of the arrow.

17.18 Changing the blades

Moving blades to maintenance position

For "Operation unit DS 100" version: To preselect the blade cassette, press the

key, see Page 107.

M KRONE

- \Rightarrow The indicator lamp below the key lights up.
- For the other terminals To preselect the blade cassette, press the 😿 key on the

terminal, see Page 137.

- \Rightarrow The key changes to 1
- ► To lower the blade cassette, actuate the control unit on the tractor (yellow, 3-).
- The blades and blade cassette are in maintenance position: The blades have been swivelled out and the blade cassette has been lowered.
- ▶ Unlock the blade retaining shaft, see Page 228.

Removing the blades

MWARNING

Risk of injury due to sharp blades which have been pre-tensioned with spring force

When performing maintenance on the blade cassette, there is a risk of injury to fingers and hands due to sharp blades.

- ▶ When working on the blade cassette, work particularly carefully and prudently.
- ▶ When working on the blade cassette, always wear protective gloves.
- Never press the blades manually into working position. Instead, use a suitable auxiliary tool.
- Before working on the blade cassette, shut down and safeguard the machine, see Page 27.



RPG000-251

- ✓ The pick-up is fully raised in transport position, see Page 84.
- \checkmark The tailgate is open and secured by the stop cock on the tailgate.
- ✓ The machine has been shut down and secured, see Page 27.
- Remove the blades (1).
- ▶ Insert a new or a ground blade (1).
- Ensure that the blade (1) is correctly positioned on the blade control shaft and is centred in the slot (2).
- ▶ After inserting all blades (1), check that all blades (1) are in alignment.



INFO

If the cutting unit is not switched on for a prolonged period, the blades can be replaced with dummy blades in order to avoid soiling the blade cassette slots and wearing the blades.

The dummy blades can be ordered by quoting the following order number 20 469 670*.

17.19 Unlocking/locking blade retaining shaft

NOTICE

Damage to machine from unlocked blade retaining shaft

If the blade retaining shaft is not locked before commissioning, the blades can become loose during travel. This may damage the machine.

Ensure that the blade retaining shaft is locked before putting the machine back into service.

If work has to be carried out on the blades of the cutting unit, the blade retaining shaft must be unlocked beforehand. After work, the blade retaining shaft must be locked again.



RPG000-156

Unlocking

▶ Move the handle (1) downwards according to the sheet stamping (2) and engage.

Locking

- ▶ Move the handle (1) upwards according to the sheet stamping (2) and engage.
- After locking the blade retaining shaft (3), the blades selected beforehand swivel independently upwards into the working position.



17.20 Checking and moving the blade retaining shaft

Checking the blade retaining shaft



The area on the blade retaining shaft (2), in which the blades (1) are located, wears during use.

The blade retaining shaft (2) is factory-set in position (I). If the area, in which the blades (1) are located, is worn by 1 mm in position (I), the blade retaining shaft (2) can be moved once into position (II). The blade retaining shaft (2) does not have to be replaced until the area, in which the blades (1) are located, even in position (II), is worn by 1 mm.

Moving the blade retaining shaft



RPG000-161

✓ The blades have been removed, see Page 226.

WARNING! Risk of injury from spring under tension! Proceed with special care when moving the blade retaining shaft.

- Knock out the roll pin (1) on both sides of the machine.
- Move the blade retaining shaft (2) by 8 mm.
- Knock the roll pin (1) into the opening (3) on both sides of the machine.

17.21 Grinding the blades

INFO

KRONE recommend the KRONE blade grinding machine for grinding the blades.

Contact your KRONE dealer. For further information, please refer to the operating instructions of the blade grinding machine.



Correctly ground, sharp blades reduce fuel consumption and the wear on the cutting components. They also guarantee good cutting quality and ideal crop throughput.

The sharpness of the blades must be checked at least once a day. With crops with a high level of contamination/foreign bodies, checks must be performed several times a day.

Grinding blades without blade grinding machine



- 1 Smooth blade side 2 Serrated blade
- ✓ The blade has been removed from the blade cassette, see Page 226.

WARNING! Danger of cuts from sharp blades! Wear suitable protective gloves.

- Remove any coarse dirt deposited on the blade.
- Clamp the blade in a suitable vice.

WARNING! Danger of injury from flying sparks! During the grinding process, always wear protective gloves, hearing protection and safety glasses.

NOTE! During grinding, be sure not to heat the blade excessively and not to cut any notches as this will reduce the lifetime of the blade. Frequent grinding with pauses in between is better for the blade lifetime than excessively long grinding.

- Grind the cutting edge (1) maintaining an angle of (α =10 degrees ±1 degree)...
- Use suitable tools to touch up serrated blades (2).

17.22 Checking/lubricating the safety rolls of the single blade locking device



RPG000-252

The single blade locking device prevents the blades from being damaged when coming into contact with foreign objects. To allow the single blade locking device to function properly, ensure that the safety rolls on the blade levers (1) rotate smoothly.

Check whether the safety rolls run smoothly whenever you change a blade.

- ✓ The blades are in maintenance position, see Page 226.
- ✓ The machine has been shut down and secured, see Page 27.
- The safety rolls on the blade levers (1) can be reached from below the machine.
- Rotate the safety rolls by hand to check their smooth movement.
- If the safety rolls do not rotate smoothly:
- ► Lubricate the safety rolls with oil.

17.23 Adjust drive chains

M WARNING

Risk of injury due to moving drive chains

When working on drive chains, there is a risk of injury due to entanglement of loose long hair or loose clothing.

- ▶ When working on the drive chains, wear protective equipment, see Page 20.
- ▶ Before working on any drive chains, shut down and safeguard the machine, see Page 27.

The drive chains on the machine are numbered consecutively. A number is stamped on a sheet on each chain.

Number	Drive chain	Location on the machine
1	Baling unit drive	Right side of machine
2	Rotor drive	Right side of machine
3	Feed roller and starter roller drive	Left side of machine

17.23.1 Drive chain of the baling unit (no. 1)



RPG000-172

The drive chain (1) of the baling unit is located on the right side of the machine. If the lower edge of the spring (2) is inside the notch (6), the drive chain (1) has been correctly set.

- ✓ The machine has been shut down and secured, see Page 27.
- \checkmark The right side hood is open.

Setting drive chain

Using the nut (3) and counter nut (4), set the spring (2) so that the lower edge of the spring (2) is inside the notch (6).

17.23 Adjust drive chains



Dismounting the drive chain

To dismount the drive chain (1), relieve the drive chain (1) as follows:

- ▶ Loosen the counter nut (4) and the nut (3) and screw downwards as far as possible.
- Screw the nut (5) downwards as far as possible.
 - \Rightarrow The spring is contracted.
- Remove the drive chain (1).

Mounting the drive chain

- Put on the drive chain (1).
- Screw the nut (5) all the way upwards again.
- Using the nut (3) and counter nut (4), set the spring (2) so that the lower edge of the spring (2) is inside the notch (6).

INFO

The drive chain is supplied with oil via the central chain lubrication system, see Page 201.

17.23.2 Drive chain of the rotor (no. 2)



RPG000-171

The drive chain (1) of the rotor is located on the right side of the machine. The dimension X of the tensioned spring length (2) must be **X=370 mm** when the pick-up is raised.

- ✓ The machine has been shut down and secured, see Page 27.
- ✓ The pick-up is fully raised in transport position, see Page 84.
- ✓ The right side hood is open.
- ► To tension the drive chain (1), use the nut (3) to set the dimension **X=370 mm**.
- ► Lock the nut (3).

INFO

The drive chain is supplied with oil via the central chain lubrication system, see Page 201.



17.23.3 Drive chain of the feed roller and the starter roller (no. 3)



RPG000-173

The drive chain (1) of the feed roller and the starter roller is located on the left side of the machine. If the spring (2) has been tensioned to the dimension of the sheet (4), the drive chain (1) has been correctly set. In doing so, the lower edge of the spring (2) must be sealed by the lower edge of the sheet (4).

- ✓ The machine has been shut down and secured, see Page 27.
- ✓ The left side hood is open.
- To tension the drive chain (1), use the nut (3) to set the spring (2) to the dimension of the sheet (4).

INFO

The drive chain is supplied with oil via the central chain lubrication system, see Page 201.

17.24 Servicing chain lubrication unit

NOTICE

Damage to the machine due to the use of incorrect and contaminated lubricants

Unauthorised or contaminated lubricants in the central chain lubrication unit will cause malfunctions in the central chain lubrication unit and damage the bearing positions.

- ▶ When working on the central chain lubrication unit, use clean and suitable tools.
- Use authorised lubricants only.
- Ensure that dirt or dirty lubricant cannot get into the central chain lubrication unit.

17.24.1 Checking oil level, topping up oil and cleaning filter



RPG000-134



- 1 Reservoir
- 2 Cover

- 3 Filter
- 4 Oil pump

Checking oil level and topping up oil

- ✓ The machine has been shut down and secured, see Page 27.
- Read off the oil level on the reservoir (1).
- If the oil level is too low, remove the cover (2) and top up the oil via the opening. For a list of oils, see Page 52.
- Mount the cover (2).

Cleaning the filter

- ✓ The machine has been shut down and secured, see Page 27.
- ✓ The reservoir (1) is mostly empty.
- Remove the cover (2).
- Remove the filter (3) from the reservoir (1).
- ► Clean the filter (3).
- Mount a clean filter (3).
- ► Fill the reservoir (1) with oil.
- Mount the cover (2).

17.24.2 Distribution of the oil brushes on the machine

The oil brushes are located on the 3 drive chains which are identified on the machine by numbers.



Right side of machine



RPG000-175

- 1 Drive chain no. 1 baling unit
- 2 Drive chain no. 2 rotor



Left side of machine

RPG000-176

1 Drive chain no. 3 - feed roller and starter roller



17.25 Servicing the hydraulic system

WARNING Hydraulic hoses are subject to ageing Hydraulic hoses may wear depending on pressure, heat load and the effect of UV rays. People can be seriously injured or killed by damaged hydraulic hoses. The date of manufacture appears on the hydraulic hoses. This way the age can be ascertained quickly. Replacement of the hydraulic hoses is recommended after a lifetime of six years. Use original spare parts when replacing hoses.

NOTICE

Damage to the machine due to soiling of the hydraulic system

If foreign objects or liquids get into the hydraulic system, the hydraulic system may be severely damaged.

- Clean hydraulic connections and components before removal.
- Seal open hydraulic connections with protective caps.
- Ensure that foreign objects or liquids do not get into the hydraulic system.

NOTICE

Storing and disposing of oils and used oil filters

If oil and used oil filters are not stored and disposed of properly, the environment may be damaged.

Store or dispose of used oil and oil filters according to statutory provisions.

17.25.1 Before working on the hydraulic system

The following steps must be performed before working on the hydraulic system to completely de-pressurise the hydraulic system:

- Close the tailgate.
- ▶ Reduce the baling pressure via the terminal in the menu "Electronic baling pressure

setting" , see Page 161.

Shut down and safeguard the machine, see Page 27.

17.25.2 Checking hydraulic hoses

Hydraulic hoses are subject to natural aging. This limits their service life. The recommended service life is 6 years, including a maximum storage time of 2 years. The date of manufacture is printed on the hydraulic hoses. When checking hydraulic hoses, the state-specific conditions (e.g., BGVU) must be observed.

Performing a visual inspection

 Visually inspect all hydraulic hoses for damage and leaks and have them replaced by an authorised specialist if necessary.



18 Malfunction, cause and remedy

A WARNING

Risk of injury due to non-observance of relevant safety notices

If the relevant safety notices are not observed, persons may get seriously injured or killed.

To avoid accidents, the basic safety instructions must be read and observed, see Page 15.

<u> WARNING</u>

Risk of injury due to non-observance of safety instructions

If the relevant safety routines are not observed, persons may be seriously injured or killed.

▶ The safety routines must be read and observed to avoid accidents, see Page 27.

18.1 Disturbances at the pick-up or during picking up of crops

Malfunction: The pick-up cannot be lowered.

Possible cause	Remedy
There was no switchover to pick-up on the terminal.	 Pre-select pick-up on the terminal by pressing the key.
The hydraulic hose has not been inserted in the tractor.	Correctly connect the hydraulic hose for the pick-up, see Page 62.
The working height of the pick-up is set too high that the pick-up cannot be lowered.	Set the working height of the pick-up, see Page 85.

Malfunction: There are crop blockages in the intake area.

CAUTION! Machine damage due to crop blockages! Immediately stop, switch off PTO shaft and remove the crop blockages.

Possible cause	Remedy
The swaths are uneven or too large.	Divide the swaths.
The tractor driver is driving too fast.	 Reduce the driving speed.
The machine height has not been set correctly with respect to the tractor.	Set the machine correctly using the drawbar from the KRONE service partner, see Page 56.
The crop press roller unit has been set too low.	► Set the crop press roller unit higher, see Page 87.



To remove the crop blockages, see Page 105.

Malfunction: Crops are conveyed upwards by the baling belts.

Possible cause	Remedy
The drop shaft in front of the bale chamber is blocked.	Remove the crops from the drop shaft.
The crops have a dry, long, reedy and/or smooth quality.	At the start of the baling process, reduce the rotational speed and the baling pressure.
	In addition, quickly pick up the swath at the start.
	From a bale diameter of approx. 80 cm the rotational speed and the baling pressure can be increased again.
The density of the bale core has been set too solid.	Adjust the density of the bale core via the terminal, see Page 160.

Malfunction: The baling belts have become entangled.

Possible cause	Remedy
The baling belts have become entangled or stacked on top of each other and are no longer next to each other.	 Sort the baling belts, <i>see Page 250</i>. During the next baling process, fill the bale chamber more evenly, <i>see Page 77</i>.

Disturbance: The cam clutch releases. There is a blockage in the system.

Possible cause	Remedy
Crops accumulate between	► Reduce the baling pressure in the bale core, see Page 160.
the feed rollers.	Start the baling process at reduced rotational speed.
	Pick up crops swiftly and increase the crop intake.

18.2 Disturbances during or after the baling process

Malfunction: The baling belts are turning more slowly than they should. Slippage is occurring.

Possible cause	Remedy
The baling pressure is too high.	Reduce the baling pressure, see Page 197.
The rotational speed is too high.	 Reduce the rotatonal speed.
The crops consist of very heavy grass without structure (e.g. clover grass).	Drive with few or no blades. To swivel out blade groups, see Page 92.
The crops consist of very heavy grass without structure (e.g. clover grass).	▶ Reduce the baling pressure of the bale core, see Page 160.
	If this is not adequate, also reduce the baling pressure in the middle and along the edge of the round bale.

Malfunction: The direction display during the baling process reacts too sensitively.

Possible cause	Remedy
The sensitivity of the direction display has been set too high on the terminal.	For version with "operation unit DS 100":Set the sensitivity of the direction display on the operation unit, see Page 113.
	For the remaining terminals: Set the sensitivity of the direction display on the terminal, see Page 161.



Disturbances during or after the baling process 18.2

Malfunction: The baling density is too low.

Possible cause	Remedy
The baling pressure is too low.	Increase the baling pressure, see Page 197.
There is a fault in the tension- ing hydraulics.	 Contact the KRONE service partner.

Malfunction: The round bale does not roll, or only slowly, out of the bale chamber.

Possible cause	Remedy
The sides have been filled too	► Make narrower swaths, see Page 77.
high.	Do not drive too far to the side.
The baling pressure is too high.	► Reduce the baling pressure, <i>see Page 197</i> .
The tensioning hydraulics are faulty.	 Have the tensioning hydraulics checked by a KRONE service partner.

Disturbance: The round bale does not roll far enough out of the bale chamber. The tailgate damages the wrapping and tying material when it closes.

Possible cause	Remedy
The tailgate was closed early.	 Ensure that the tailgate is closed only after the round bale has been ejected.
The bale ejector is not set correctly to the size of the round bale.	Adjusting the bale ejector, see Page 202.

Malfunction: The machine is running unevenly and the baling process in the bale chamber is difficult to start.

Possible cause	Remedy
The density of the bale core is too high.	Reduce the density of the bale core, see Page 160.

Malfunction: The tailgate cannot be completely closed.

Possible cause	Remedy
The stop cock for the tailgate is closed.	▶ Open the stop cock, <i>see Page 80</i> .
There are crops between the front housing and the tailgate.	► Remove the crops.

Malfunction: The tailgate cannot be opened.

Possible cause	Remedy
The hydraulic hose line for "Opening/closing tailgate" has not been correctly connected.	 Connect the hydraulic hose line for "Opening/closing tailgate", see Page 62.
The stop cock for the tailgate is closed.	► Open the stop cock, <i>see Page 80</i>
The pressure limiting valve for the tensioning hydraulics is not depressurising.	Checking the light-emitting diode on the pressure limiting valve, see Page 249.



Malfunction: The round bale is conically shaped.

Possible cause	Remedy
The bale chamber is filled on one side.	► Fill the bale chamber evenly, see Page 77.
Net wrapping: The number of net layers is too low.	 Increase the number of net layers via the terminal, see Page 158.
The wrapping material is torn.	Use only wrapping material of the designated quality. KRONE recommends one of the "KRONE excellent" products, see label on the machine with the number 27 016 326 *.

Malfunction: The round bale is barrel-shaped. This causes the wrapping material to tear open in the middle.

Possible cause	Remedy
The bale chamber is filled un- evenly.	Drive over the swath on alternate sides, see Page 77.
The number of layers of wrap- ping material is too low.	 Increase the number of layers. KRONE recommends 4 net layers for net wrapping. Net wrapping: see Page 158. Twine tying: see Page 158

18.3 Disturbances at the tying unit or during the tying cycle

Malfunction: The net is not transported after tying starts.

With this malfunction an error message is displayed on the terminal.

Possible cause	Remedy
The net roll is empty.	► Change the net roll, see Page 94.
The net roll has the wrong di- mensions.	 Only use net rolls with the prescribed dimensions, see Page 51.
The net roll has not been cor- rectly inserted into the roll support / holder.	Insert the net roll according to the description, see Page 94.
The net has not been correctly inserted.	Insert the net according to the description, see Page 96.
The ratchet brake is not re- leasing.	Check mechanical components of the ratchet brake. The ratchet must unhook when the net is being fed, see Page 245.
The net overhang is not ap- prox. 10 cm and is therefore too short.	Set the net overhang on the wrapping material brake, see Page 197.
The lower rubber cloth does not adequately touch the lower feed roller. The rubber cloth must be 2-3 cm at full width on the feed roller.	If the rubber cloth is no longer 2-3 cm at full width on the feed roller, adjust the rubber cloth, see Page 198.
	If the actuator for wrapping process was not completely extended, check the position in the sensor test and save again, see Page 183.
	Check again whether the adjusted rubber cloth is 2-3 cm on the feed roller.
	► If the rubber cloth is heavily worn, replace the rubber cloth.



Malfunction: The net is not, or not cleanly, cut.

CAUTION! Risk of injury on sharp parts! Always wear suitable protective gloves when you remove contamination at the cutting unit.

Possible cause	Remedy
The cutting unit is blunt.	Remove deposits from the cutting unit.
	 If required, have the cutting unit replaced by a KRONE service partner.
The cutting unit is not actuated.	Remove deposits from the cutting unit.
The actuator for wrapping pro- cess is defective.	 Check the actuator for wrapping process.
The ratchet on the wrapping material brake is jamming.	 Check the ratchet on the wrapping material brake, see Page 245.

Disturbance: The net stops during activated tying. The net tears after tying starts or during the tying cycle.

With this malfunction an error message is displayed on the terminal.

CAUTION! Risk of injury on sharp parts! Always wear suitable protective gloves when you remove contamination at the cutting unit.

Possible cause	Remedy
The cutting unit is not en-	Remove deposits from the cutting unit.
gaged.	► Check the positions of the feed rocker arm, see Page 245.

Malfunction: The net is damaged during the tying process.

Possible cause	Remedy
There are deposits or minor damage on the machine com- ponents, the sharp edges of which are damaging the pet	 Check and clean the components along the net path. Remove sharp edges from along the net path. If the malfunction persists, contact the KRONE service.
when are damaging the net.	partner.

Disturbance: The net does not, or not completely, cover one or both of the outer edges.

Possible cause	Remedy
The net is not correctly braked during the tying cycle.	Check the positions of the feed rocker arm and remove any deposits, see Page 245.
The net roll has not been centred on the machine.	Correctly insert the net roll and centre it on the machine, see Page 94.





18.4 Malfunctions on the chain lubrication unit

Malfunction: The oil consumption is too low.

Possible cause	Remedy
The oil quantities have been set too low. Too little oil comes from the brushes on the central chain lubrication unit, <i>see Page 234</i> .	Set the oil quantities on the affected drive chains higher, see Page 201.
The oil is too thick.	► Use recommended oil, see Page 52.
The central chain lubrication system is contaminated.	Clean the entire central chain lubrication system.

Malfunction: The oil consumption is too high.

Possible cause	Remedy
The oil quantities are set too high. Too much oil comes from the brushes on the cent- ral chain lubrication unit, <i>see</i> <i>Page 234</i> .	Set the oil quantities on the affected drive chains lower, see Page 201.
The oil is too thin.	► Use recommended oil, see Page 52.

Malfunction: The oil pump is dry.

Possible cause	Remedy
There is no pressure. The oil pump is not conveying.	 Have the oil pump dismounted and cleaned or replaced by a KRONE service partner.
There is no pressure. The system has no oil.	Check the oil level and top up, see Page 233.
The system is blocked by deposits.	 Clean the entire central chain lubrication system.

Malfunction: The oil pump is not pressed for the complete stroke.

Possible cause	Remedy
The oil is too thick.	► Use recommended oil, see Page 52.

18.5 Faults of the electrics/electronics

18.5.1 Error Messages

WARNING
Risk of injury to persons and damage to machines if error messages are ignored
If error messages are ignored and the fault is not rectified, there is a risk of injury to persons and/or severe damage to the machine.
Eliminate the disturbance when an error message is displayed; see Chapter "Error list" in the supplement to the operating instructions (software).
If the fault cannot be rectified, contact KRONE service partner.



Ф <i>кrone</i>	
KMC - 521202- 5	$\boldsymbol{\times}$
B11	

EQG000-034

The display shows an error message when a disturbance occurs on the machine. At the same time, an audible signal sounds (continuous horn signal). For a list of the error messages see Chapter "Error list" in the supplement to the operating instructions (software).

Configuration of an error message

The error message is configured according to the following sample: e.g. error message



520192	19	CAN1 4
SPN (Suspect Parameter Number) = error number	FMI = type of error, <i>see</i> <i>Page 243</i>	Icon

Acknowledging error message

- Note down the error message.
- Briefly press on
- The acoustic signal stops and the error display is no longer indicated. The error message is displayed again if the fault occurs again.
- ▶ To acknowledge the error message until the operating terminal is next started, press and

hold down the Key for 5 seconds.

Eliminate the fault. See Chapter "Error list" in the supplement to the operating instructions "Error messages".

Acknowledged and still pending error messages can be displayed again via the "Error list" menu or the status line.

18.5.1.1 Possible error types (FMI)

There are different types of errors which are shown under the term FMI (Failure Mode Identification) with an appropriate code.

18.5 Faults of the electrics/electronics



FMI	Meaning
0	The upper limit value was greatly exceeded.
1	The lower limit value was far below the required one.
2	The data is not permitted.
3	There is an overvoltage or a short circuit to supply voltage.
4	There is an undervoltage or a short circuit to ground.
5	A cable is broken or amperage is too low.
6	There is a short circuit to ground or amperage is too low.
7	The mechanics do not respond or the expected result was not achieved.
8	The frequency is not permitted.
9	There is an abnormal update rate.
10	There is an abnormal rate of change.
11	The error cause is unknown.
12	There is an internal error.
13	The values of the calibration are outside the value range.
14	Particular instructions are required.
15	The upper limit value has been reached.
16	The upper limit value has been exceeded.
17	The lower limit value has been reached.
18	The lower limit value has not been reached.
19	There is a CAN communication failure.
20	The data deviates upwards.
21	The data deviates downwards.
31	The condition has been fulfilled.

18.5.2 Remedying sensor/actuator error

Components must be repaired or replaced by a qualified specialist workshop only.

Before contacting the dealer, collect the following information about the error message:

- Note the error number and the respective FMI (see Page 243) that are shown on the display.
- Shut down and safeguard the machine, see Page 27.
- Check sensor/actuator externally for damage.
- ➡ If the sensor/actuator is damaged, replace the sensor/actuator.
- ➡ If the sensor/actuator is not damaged, continue with the next test step.
- Check connector cable and plug connection for damage and tightness.
- If the connector cable/plug connection is damaged, replace the connector cable/plug connection.
- ➡ If the sensor/actuator is not damaged, continue with the next test step.
- Perform an actuator test in case of an actuator error to identify the actuator status, see Page 184.
- ▶ If a sensor is defective, run a sensor test to identify the sensor status, see Page 180.

WKRONE

The more information the dealer has, the easier it is to eliminate the cause of the error.

18.6 Checking the ratchet on the wrapping material brake



RPG000-195

This net wrapping ratchet (1) is located on the left side of the machine.

Depending on the position of the feed rocker arm, the ratchet (1) is either engaged (Position (I)) or not engaged (Position (II)).

For an overview of the positions of the feed rocker arm, see Page 245.

Position	Explanation
(1)	Ratchet engaged
	Final position
(11)	Ratchet not engaged
	Feed position
	Tying position

- ▶ Approach the individual positions of the feed rocker arm, see Page 245.
- Check whether the ratchet (1) is in the correct position (I) or (II).

If the ratchet (1) blocks:

- ✓ The machine has been shut down and secured, see Page 27.
- ► Remove deposits from the tying unit.

18.7 Checking positions of the feed rocker arm

The feed rocker arm can be moved into the end position, feed position and tying position by manual operation of the terminal, *see Page 164*.

The positions of the feed rocker arm can be checked on the left side of the machine.



Final position



RP000-994

The end position is the basic position in which the tying unit is always located when no tying cycle is running. The cylinder (1) has been completely retracted.

▶ In Menu 10 "Manual operation" move the feed rocker arm into the end position by pressing



Check whether the cylinder (1) has been completely retracted and the area (2) looks the same as the one illustrated.



Feed position



RP000-995

The cylinder (1) has been completely extended in the feed position.

▶ In Menu 10 "Manual operation" move the feed rocker arm into the feed position by pressing



 Check whether the cylinder (1) has been completely extended and the area (2) looks as the same as the one illustrated.

18.8 Setting the tailgate lock



Tying position



RP000-996

The cylinder (1) has been partly extended in the tying position.

▶ In Menu 10 "Manual operation" move the feed rocker arm into the tying position by pressing



Check whether the cylinder (1) has been partly extended and the area (2) looks as the same as the one illustrated.

18.8 Setting the tailgate lock



RPG000-068

If the tailgate no longer closes fully, the tailgate lock must be set on the spring (2).

Make the following setting on the right and left sides of the machine in the same way:

- ✓ The machine has been shut down and secured, see Page 27.
- Check dimension X on the eyelet bolt (3).
 - \Rightarrow If the dimension is **X=105 mm**, the setting is correct.

DKRONE

- ⇒ If the dimension X is not **X=105 mm**, the tailgate lock must be set.
- To set the tailgate lock, release or tighten the nuts (1) until the dimension **X=105 mm**.

18.9 Checking the pressure limiting valve



RPG000-174

The pressure limiting valve is located behind the side hood on the left side of the machine.

The light-emitting diode (2) indicates whether the pressure limiting valve of the tailgate is energised. If the pressure limiting valve is not energised, the tailgate cannot be opened.

- Check whether the light-emitting diode (2) is lit or not lit.
- If the light-emitting diode (2) is lit, the pressure limiting valve is energised. -

If the light-emitting diode (2) is not lit:

Check whether the terminal is switched on.

If the terminal is switched on and the light-emitting diode is not lit, there is an electrical fault.

Check the machine electronics and, if required, have them repaired by the KRONE service partner.

Checking hydraulic oil pressure in the clamping system

- The tailgate is closed.
- Pull the plug (1) off the pressure limiting valve.
- Open the tailgate, see Page 104.
- If the clamping cylinders extend maximum **30 mm** and the tailgate opens only approx. one quarter, the hydraulic oil pressure is correct.
- If the clamping cylinders extend more than 30 mm, there is no hydraulic oil in the clamping system or the pressure limiting valve is defective.
- If the pressure limiting valve is defective, contact a KRONE service partner.

18.10 Filling the accumulator

After the tying mechanism has been actuated 3 times, the accumulator of the machine is empty and must be filled again.

- Close the stop cock of the tailgate, see Page 80.
- Fill the accumulator from the tractor.





18.11 Cleaning deflection rolls and baling belts

If crops have accumulated between the deflection rolls, the latter must be cleaned. While cleaning the deflection rolls, manually sort the baling belts again and place them next to each other.

For this purpose, a lever on the right-hand side of the machine is first actuated to move the tensioning rocker arms to a position at which the tension of the baling belts is released, *see Page 220*.



RPG000-148

- ✓ The stop cock of the tailgate is closed.
- ✓ The machine has been shut down and secured, see Page 27.
- Remove crops from the deflection rolls.
- Move the baling belts (3) in the bale chamber so that all baling belts (3) are next to each other but not touching, as illustrated.
- ▶ Move the lever (1) against the direction of the arrow and push back.
- ► To be able to open the tailgate, open the stop cock, see Page 80.
- Switch on the tractor.
- ► To open the tailgate fully and then to close it, actuate the control unit on the tractor (red, 1+).
 - \Rightarrow The baling belts are tensioned and the machine is ready for operation.

18.12 Car jack contact points

WARNING Risk of injury due to raised machineThere is danger to persons when the machine drops or parts swing without control. Only qualified personnel are allowed to perform this work. Use only permitted hoists and slings with a sufficient load-bearing capacity. For the weights see Page 49. Note the information on the suspension points provided. Make sure the lifting means are properly secured. Never stay under the suspended machine.

 If work has to be performed under the machine, securely support the machine, see Page 28.

The car jack contact points are located on the left and right on the single axle or tandem axle and a marked with a sticker.



Example image of a single axle:



RPG000-177

- 1 Car jack contact point at rear left
- 2 Car jack contact point at rear right



19 Waste disposal

After the service life of the machine has expired, the individual components of the machine must be disposed of properly. The currently applicable country-specific waste disposal guidelines and the relevant laws must be observed.

Metal parts

- All metal parts must be taken to a metal recycling centre.
- Before scrapping, remove operating fluids and lubricants (e.g. gear oil, oil from the hydraulic system) from the components.
- The operating fluids and lubricants must be taken separately to an environmentally friendly disposal point or recycling centre.

Operating fluids and lubricants

• Operating fluids and lubricants (e.g. diesel fuel, coolant, gearbox oil, oil from hydraulic system) must be taken to a waste oil disposal point.

Synthetic materials

• All synthetic materials must be taken to a recycling centre for synthetic materials.

Rubber

• All rubber parts (e.g. hoses, tyres) must be taken to a rubber recycling centre.

Electronic components

• All electronic components must be taken to a disposal point for electronic scrap.
WKRONE

20 Appendix

20.1 Hydraulic diagram

Legend for the following hydraulic diagram

1 Version with cutting unit

List of the actuators and icons for the following hydraulic diagram

A list of the sensors, actuators and control units is in the circuit diagram.

lcon	Actuator	Explanation
\rightarrow	Q41	Baling pressure
	_	Tailgate on the bale chamber
JIII &	Q26	Lowering the feed rocker arm
	Q27	Lifting the feed rocker arm
1 I	K01	Pick-up
\$ <u>_</u>	K03	Raising/lowering blade cassette
	К03	Lifting/lowering the feeder rotor floor
	K21	Blade control shaft A active

>>>

150 102 670 02 [▶ 254]





(^M) KRONE

21 Index

Α

Accessing the working screen 110, 143
Acknowledging error message 243
Activating TIM functions 147
Activating/deactivating the bearing pressure relief for the pick-up
Actuator test (terminal) 184
Actuator test for digital and analogue actuators 123
Additional equipment and spare parts 16
Adjust drive chains 231
Adjusting bale diameter 145
Adjusting sensor B08 "Top blade cassette" 182
Adjusting sensor B61 "Tying 1 (passive)" 183
Adjusting the drawbar height 56
Adjusting the length of the universal shaft 58
Adjusting the twine tension at the twine box 198
Adjusting the twine tension at the twine brake . 199
Airborne noise emission 49
Ambient temperature 50
Appendix 253
Applicable documents 9
Automatic call of the Road travel screen 144
Auxiliary assignment of a joystick 149
Auxiliary functions (AUX) 148

В

B08 upper blade cassette 182
Bale dimensions 50
Baling belts have become entangled 238
Baling pressure adjustment, electronic (terminal)
Basic safety instructions 15
Before working on the hydraulic system 236
Behavior in the case of voltage flashover of overhead lines
Behaviour in dangerous situations and in case of accidents
Briefly deactivating cutting unit and pick-up 226
Bringing the pick-up to transport/working position 84

С

Calibrating sensors 121
Call road travel screen 109
Car jack contact points 250
Carrying out oil level check and oil and filter element changes safely
Central chain lubrication system
Setting oil volumes on the oil pump 201
Changing mode 156
Changing the blades 226
Changing value 155
Checking and adjusting the cleaning rollers 221
Checking and moving the blade retaining shaft 229
Checking hydraulic hoses 218, 236
Checking hydraulic oil pressure in the clamping system
Checking oil level, topping up oil and cleaning filter 233
Checking positions of the feed rocker arm 245
Checking road travel lighting
Checking the fire extinguisher 225
Checking the pressure limiting valve 249
Checking the ratchet on the wrapping material brake
Checking the screw connections on the drawbar
Checking/adjusting blades at the twine tying
system 199
Checking/lubricating the safety rolls of the single blade locking device
Checking/maintaining tyres 215
Checklist for initial operation 54
Checklist for the transport of the machine 193
Children in danger 16
Clean the bushing and the drawbar eye 219
Cleaning deflection rolls and baling belts 250
Cleaning drive chains 220
Cleaning roller on the bottom deflection shaft in the tailgate
Cleaning roller on the drive shaft 222
Cleaning the drawbar eye 219
Cleaning the machine 218
Commissioning

Completing the baling process, starting tying cycle and ejecting round bales
Configuring TIM software (terminal) 177
Connecting foreign ISOBUS terminal 71
Connecting hydraulic brake (export) 63
Connecting hydraulic hoses 62
Connecting joystick 72
Connecting KRONE terminal DS 500 67
Connecting machine to tractor 60
Connecting spools of twine with each other 100
Connecting the camera to the KRONE ISOBUS terminal CCI 800 or CCI 1200
Connecting the KRONE DS 100 operation unit 65
Connecting the KRONE ISOBUS terminal (CCI 800, CCI 1200) 69
Connecting the machine 16
Connecting the road lighting 63
Consumables 22, 52
Contact 2
Contact data of your dealer 2
Contamination of hydraulic system and/or fuel system 22
Conversion table 12
Conversion table 12 Correction value moisture measurement (Terminal)
Conversion table
Conversion table
Conversion table 12 Correction value moisture measurement (Terminal) 170 Counter 172 Crop blockage at the right-hand and left-hand end of the pick-up 105 Crop blockage in the baling element 106
Conversion table 12 Correction value moisture measurement (Terminal) 170 Counter 172 Crop blockage at the right-hand and left-hand end of the pick-up 105 Crop blockage in the baling element 106 Crop blockage in the pick-up 105
Conversion table 12 Correction value moisture measurement (Terminal) 170 Counter 172 Crop blockage at the right-hand and left-hand end of the pick-up 105 Crop blockage in the baling element 106 Crop blockage under the cutting rotor 105
Conversion table 12 Correction value moisture measurement (Terminal) 170 Counter 172 Crop blockage at the right-hand and left-hand end of the pick-up 105 Crop blockage in the baling element 106 Crop blockage in the pick-up 105 Crop blockage in the pick-up 105 Crop blockage in the pick-up 105 Crop blockage under the cutting rotor 105 Crop collection without using guide wheels 87
Conversion table 12 Correction value moisture measurement (Terminal) 170 Counter 172 Crop blockage at the right-hand and left-hand end of the pick-up 105 Crop blockage in the baling element 106 Crop blockage in the pick-up 105 Crop blockage under the cutting rotor 105 Crop collection without using guide wheels 87 Crop press roller unit 87
Conversion table 12 Correction value moisture measurement (Terminal) 170 Counter 172 Crop blockage at the right-hand and left-hand end of the pick-up 105 Crop blockage in the baling element 106 Crop blockage in the pick-up 105 Crop blockage under the cutting rotor 105 Crop collection without using guide wheels 87 Crop press roller unit 87 Removing baffle sheet 88
Conversion table 12 Correction value moisture measurement (Terminal) 170 Counter 172 Crop blockage at the right-hand and left-hand end of the pick-up 105 Crop blockage in the baling element 106 Crop blockage in the pick-up 105 Crop blockage in the pick-up 105 Crop blockage under the cutting rotor 105 Crop collection without using guide wheels 87 Crop press roller unit 87 Removing baffle sheet 88 Cross references 10
Conversion table 12 Correction value moisture measurement (Terminal) 170 Counter 172 Crop blockage at the right-hand and left-hand end of the pick-up 105 Crop blockage in the baling element 106 Crop blockage in the pick-up 105 Crop blockage under the cutting rotor 105 Crop collection without using guide wheels 87 Crop press roller unit 87 Removing baffle sheet 88 Cross references 10 Customer counter 172
Conversion table 12 Correction value moisture measurement (Terminal) 170 Counter 172 Crop blockage at the right-hand and left-hand end of the pick-up 105 Crop blockage in the baling element 106 Crop blockage in the pick-up 105 Crop blockage under the cutting rotor 105 Crop collection without using guide wheels 87 Crop press roller unit 87 Removing baffle sheet 88 Cross references 10 Cutting the net 98
Conversion table 12 Correction value moisture measurement (Terminal) 170 Counter 172 Crop blockage at the right-hand and left-hand end 105 Crop blockage in the baling element 106 Crop blockage in the baling element 105 Crop blockage in the pick-up 105 Crop blockage under the cutting rotor 105 Crop collection without using guide wheels 87 Crop press roller unit 87 Removing baffle sheet 88 Cross references 10 Customer counter 172 Cutting the net 98 Cutting unit 89

D

Damaged compressor unit 25
Damaged hydraulic hoses 25
Danger associated with welding work 26
Danger resulting from damage to the machine 17
Danger when cornering with a machine hitched and due to the overall width
Danger when driving on road and field 21
Danger zone between tractor and machine 19
Danger zone due to trailing machine parts 19
Danger zone PTO shaft 19
Danger zone universal shaft 19
Danger zone when drive is switched on 19
Danger zones 18
Dangers arising from environment 23
Dangers during road travel 21
Dangers if the machine is not prepared properly for road travel
Dangers in connection with certain activities: Working on the machine
Dangers in connection with certain activities:
working on wheels and tyres
Dangers when operating the machine on slopes 22
Dangers when operating the machine on slopes 22 Data memory
Dangers when operating the machine on slopes 22 Data memory
Dangers when operating the machine on slopes 22Data memoryDeclaration of conformity265Delete all errors188
Dangers when operating the machine on slopes 22Data memoryDeclaration of conformity265Delete all errors188Delete individual errors
Dangers when operating the machine on slopes 22Data memory42Declaration of conformity265Delete all errors188Delete individual errors188Design DS 500129
Dangers when operating the machine on slopes 22Data memoryDeclaration of conformity265Delete all errors188Delete individual errors188Design DS 500129Design of display133
Dangers when operating the machine on slopes 22Data memoryDeclaration of conformity265Delete all errors188Delete individual errors188Design DS 500129Design of display133Design of the KRONE machine application
Working on wheels and tyres26Dangers when operating the machine on slopes 22Data memory42Declaration of conformity265Delete all errors188Delete individual errors188Design DS 500129Design of display133Design of the KRONE machine application133Diagnostics for digital actuators186
Working on wheels and tyres26Dangers when operating the machine on slopes 22Data memory42Declaration of conformity265Delete all errors188Delete individual errors188Design DS 500129Design of display133Design of the KRONE machine application133Diagnostics for digital actuators186Dimensions49
Working on wheels and tyres26Dangers when operating the machine on slopes 22Data memory42Declaration of conformity265Delete all errors188Delete individual errors188Design DS 500129Design of display133Design of the KRONE machine application133Diagnostics for digital actuators186Dimensions49Direction display110, 142
Working on wheels and tyres26Dangers when operating the machine on slopes 22Data memory42Declaration of conformity265Delete all errors188Delete individual errors188Design DS 500129Design of display133Design of the KRONE machine application133Diagnostics for digital actuators186Dimensions49Direction display sensitivity (terminal)161
Working on wheels and tyres26Dangers when operating the machine on slopes 22Data memory42Declaration of conformity265Delete all errors188Delete individual errors188Design DS 500129Design of display133Design of the KRONE machine application133Diagnostics for digital actuators186Dimensions49Direction display sensitivity (terminal)161Directories and references9
Working on wheels and tyres26Dangers when operating the machine on slopes 22Data memory42Declaration of conformity265Delete all errors188Delete individual errors188Design DS 500129Design of display133Design of the KRONE machine application133Diagnostics for digital actuators186Dimensions49Direction display sensitivity (terminal)161Directories and references9Dismounting the guide wheels of the pick-up for road travel192
Working on wheels and tyres26Dangers when operating the machine on slopes 22Data memory42Declaration of conformity265Delete all errors188Delete individual errors188Design DS 500129Design of display133Design of the KRONE machine application133Diagnostics for digital actuators186Dimensions49Direction display sensitivity (terminal)161Directories and references9Dismounting the guide wheels of the pick-up for road travel192Displaying the customer counter119
Working on wheels and tyres26Dangers when operating the machine on slopes 22Data memory42Declaration of conformity265Delete all errors188Delete individual errors188Design DS 500129Design of display133Design of the KRONE machine application133Diagnostics for digital actuators186Dimensions49Direction display sensitivity (terminal)161Directories and references9Dismounting the guide wheels of the pick-up for road travel192Displaying the customer counter119Displays on the information bar141
working on wheels and tyres26Dangers when operating the machine on slopes 22Data memory42Declaration of conformity265Delete all errors188Delete individual errors188Design DS 500129Design of display133Design of the KRONE machine application133Diagnostics for digital actuators186Dimensions49Direction display sensitivity (terminal)161Directories and references9Dismounting the guide wheels of the pick-up for road travel192Displaying the customer counter119Displays on the information bar141Displays on the working screen139
Working on wheels and tyres26Dangers when operating the machine on slopes 22Data memory42Declaration of conformity265Delete all errors188Delete individual errors188Design DS 500129Design of display133Design of the KRONE machine application133Diagnostics for digital actuators186Dimensions49Direction display sensitivity (terminal)161Directories and references9Dismounting the guide wheels of the pick-up for road travel192Displaying the customer counter119Displays on the information bar141Displays on the working screen139Distribution of the oil brushes on the machine234

Net tears	241
The net does not reach the outside edge 241	s
Disturbances at the pick-up or during picking up crops	o of 237
Disturbances at the tying unit or during the tying cycle	9 240
Disturbances during or after the baling process	238
Drive chain of the baling unit (no. 1)	231
Drive chain of the feed roller and the starter roll (no. 3)	er 233
Drive chain of the rotor (no. 2)	232
Driving and transport	189
DS 100	
Accessing the working screen	110
Actuator test	123
Call road travel screen mode	109
Direction display	110
Displaying the customer counter	119
Number of net layers	117
Sensor test for digital sensors	120
Setting advance signaling	113
Setting the bale diameter	112
Setting the baling pressure	114
Setting the core, centre and edge of the round bale	115
Setting the sensitivity of direction display 113	
Setting the tying start delay	118
Start tying	111
Switching the operation unit on/off	109
Switching the working lights on/off	112



Ε

Ejecting round bales 79
Electronic baling pressure adjustment (terminal)
Ensuring functionality of safety devices 20
Environmental protection and disposal 23
Error list (Terminal) 186
Error message moisture measurement (Terminal)
Error messages 125, 242

F

Faults of the electrics/electronics	242
Figures	10
Filling correction (terminal)	163
Filling the accumulator	249
Filling the bale chamber	77
Fire hazard	22, 23
Fitting wheel chocks	83
Floating pick-up	87
For "Cleaning rollers" version	221
Foreign ISOBUS terminal	135
Function description cutting unit	48
Function description net wrapping	46
Function description of twine tying	47

G

Grinding blades without blade grinding machine	e
	230
Grinding the blades	229

Н

Hot liquids	. 24
Hot surfaces	. 25
How to use this document	9
Hydraulic diagram	253

I

Icons in figures 1	11
Icons in the text 1	10
Identification plate 4	14
Importance of operating instructions 1	15
Information for enquiries and orders	2
Information labels on the machine 3	34
Information on direction 1	10
Information on This Document	9
Initial operation 5	54
Inserting the net 9	96
Inserting the net roll	94
Inserting tying twine 10)1
Intended use 1	14
ISOBUS settings (terminal) 17	75

J

Jobs on the machine	<u>)</u>	17
---------------------	----------	----

Κ

Keys	137
KRONE ISOBUS terminal (CCI 800, CCI 1200)	
	131
KRONE operation unit DS 100	107
KRONE SmartConnect (Terminal)	176
KRONE Terminal DS 500	128

L

Lashing points on the machine	195
Lashing the machine	195
Life-threatening electric shock from overhead lin	1es . 23
Lifting the machine	194
Lifting/lowering blade cassette	. 89
Liquids under high pressure	. 24
Location and meaning of the information labels	. 35
Locking screws on the gearboxes	214
Lower pick-up	. 84
Lubricating greases	. 53
Lubricating the universal shaft	211
Lubrication chart	207

Μ

Machine description	43
Machine overview	43
Maintenance – After the season 2	205
Maintenance – Before the season 2	204
Maintenance – Every 1,000 round bales 2	206
Maintenance – every 10 hours, at least daily 2	206
Maintenance – Every 2 years 2	207
Maintenance – Every 250 hours 2	206
Maintenance – every 50 hours 2	206
Maintenance – every 500 hours 2	206
Maintenance – once after 10 hours 2	205
Maintenance – once after 50 hours 2	205
Maintenance – Once after 500 round bales 2	206
Maintenance and repair work	25
Maintenance table 2	204
Malfunction	
Baling density too low 2	239
Central chain lubrication system: Oil consumption too high 2	242

Ce co	entral chain lubrication system: Oil nsumption too high	242
Ce co	entral chain lubrication system: Oil nsumption too low	242
Ce dry	entral chain lubrication system: Oil pum /	ip 242
Ce	entral chain lubrication: Oil pump not mpletely pressed	242
Cr	op blockages	237
Cr 23	ops conveyed upwards by the baling b 8	elts
Dir	rection display reacts too sensitively	238
Ma	achine is running unevenly	239
Ne	et not cut cleanly	241
Ne	et not transported	240
Pic	ck-up	237
Ro	ound bale conical	240
Ro chi	ound bale does not roll out of the bale amber	239
Ro ma	ound bale is barrel-shaped, wrapping aterial tears	240
Та	ilgate cannot be opened	239
Та	ilgate does not close	239
Malfuncti	on, cause and remedy	237

Malfunctions on the chain lubrication unit 242
Manual operation (net wrapping and twine tying), Terminal 165
Manual operation (net wrapping, terminal) 164
Manual operation of the tying system 125
Means of representation 10
Menu 1 "Number of twine layers" (twine tying). 158
Menu 10 "Manual operation" (for the "Net wrapping" version) 164
Menu 10 "Manual operation" (for version with "net wrapping and twine tying") 165
Menu 11 "Correction of start/end position of the twine tying system (for "net wrapping and twine tying" version)
Menu 12 "Moisture measurement" 169
Menu 12-1 "Error message for moisture measurement"
Menu 12-2 "Correction value for moisture measurement"
Menu 13 "Counters" 172
Menu 13-1 "Customer counter" 172
Menu 13-2 "Total counter" 174
Menu 14 "ISOBUS" 175
Menu 14-5 "KRONE SmartConnect" 176
Menu 14-6 "Configuring TIM software" (for "TIM 1.0" version)
Menu 14-9 "Switching between terminals" 178
Menu 15 "Settings" 179
Menu 15-1 "Sensor test" 180
Menu 15-2 "Actuator test" 184
Menu 15-3 "Software info" 186
Menu 15-4 "Error list" 186
Menu 3 "Advance signalling" 159
Menu 4 "Tying start delay" 159
Menu 6 "Electronic baling pressure adjustment"
Menu 8 "Select type of tying" (for the "Net wrapping and twine tying" version) 162
Menu structure 152
Menu 1 "Number of net layers" (net wrapping). 158
Menu 7 "Sensitivity of direction display" 161
Menu 9 "Filling correction" 163
Metric thread screws with control thread 212

13
13
45
69
al) 70
) 69
84
55
64
57
61
59

Ν

net chute
net motor position
Setting sensor 183
Net wrapping
Layers 158
Setting rubber cloth 198
Net wrapping and tying material 51
Noise may damage your health 24
Notes with information and recommendations 12
Number of net layers 158
Number of twine layers (twine tying, terminal) . 158

0

Oils	52
Only perform work when the machine is at	
standstill	25
Open/close tailgate 1	04
Operating machine via joystick 1	48
Operating the support jack	79
Operating TIM 1.0 (Tractor Implement	
Management)	145
	40
Operation	76
Operation only after proper commissioning	17
Operational safety: Technically sound condition	17
Overload protections on the machine	44
Overview 1	07

Ρ

Parking the machine 190
Parking the machine safely 22
Passengers 17
Pausing TIM functions 148
Performing a visual inspection 218, 236
Personal protective equipment 20
Personnel qualification of the operating personnel 15
Personnel qualification of the technicians 16
Pick-up 84
Setting the working height 85
Pick-up, floating 87
Position and meaning of safety labels 30
Possible error types (FMI) 243
Preparation before baling 76
Preparing the machine for road travel 190
Preparing the machine for shipment 193
Pre-signalling (terminal) 159

R

S

Safety 1	14
Safety chain	50
Safety equipment	39
Safety labels on the machine 2	29
Safety markings on the machine 2	21
Safety routines 2	27
Scope of delivery 5	54
Scope of the document 1	10
Securing raised machine and machine parts against lowering	28
Securing the front hood 19	94
Securing the universal shaft 19	91
Selecting a menu 15	54
Selecting a menu Level 15	54
Selecting type of tying (net wrapping and twine tying, terminal)	52
Selection type of tying (net wrapping and twine tying, terminal)	52
Sensitivity of direction display (Terminal) 16	61
Sensor test 18	30
Sensor test (terminal) 18	30
Sensor test for digital and analogue sensors 12	20
Service & maintenance 20)4
Service life of the machine 1	15
Servicing chain lubrication unit 23	33
Servicing the hydraulic system 23	36
Servicing the main gearbox 21	17
Setting advance signaling 11	13
Setting B61 sensor tying 1 (passive) 18	33
Setting net overhang on the wrapping material brake	97
Setting oil quantities for the central chain Iubrication unit	01
Setting rubber cloth on the net wrapping 19	98
Setting the bale diameter 112, 19	97
Setting the bale ejector 20)2
Setting the baling pressure 114, 19	97
Setting the core, centre and edge of the round ba	le 15
Setting the crop press roller unit	37
Setting the cutting length 20)2

Setting the number of net layers 117
Setting the pick-up working height 85
Setting the sensitivity of the direction display 113
Setting the tailgate lock 248
Setting the tying start delay 118
Setting units on the terminal 134
Setting user preferences 126
Settings 197
Settings (terminal) 179
Shutting down and safeguarding the machine 27
Significance of the document 9
SmartConnect (Terminal) 176
SMV emblem 41
Software info (Terminal) 186
Sorting baling belts 250
Sources of danger on the machine 24
Start tying 111
Starting tying 79
Status line
Storing blades on the blade support
Structural modifications on the machine 16
Support jack 79
Switching between terminals 179
Switching between the terminals 179
Switching terminal on/off 128, 132
Switching the operation unit on/off 109
Switching the working lights on/off 112
Switching warning beacon on/off 112
Swivelling blade groups in/out
Swivelling in/out blades 90
Swivelling the twine box to and fro 104

Т

Targe	t group of this document	9
Techn	iical data	. 49
Techn	ical limit values	. 18
Techn travel)	ically permitted maximum speed (road)	. 49
Techn	nically sound state of the machine	. 17
Term	"machine"	. 10
Termi	nal	
	Actuator test	184
	Baling pressure adjustment, electronic	160
	Configuring TIM software	177
	Correction twine tying start/end position	167
	Correction value for moisture measurements 170	ent.
	Counter	172
	Direction display sensitivity	161
	Error list	186
	Error message for moisture measuremen 169	ıt
	Filling correction	163
	ISOBUS settings	175
	Manual operation (net wrapping and twin tying)	e 165
	Manual operation (net wrapping)	164
	Moisture measurement	169
	Moisture measurement correction value	170
	Moisture measurement error message	169
	Number of net layers	158
	Number of twine layers	158
	Pre-signalling	159
	Select menu level	154
	Selecting type of tying (net wrapping and twine tying)	162
	Sensor test	180
	Setting units	134
	Settings	179
	SmartConnect	176
	Software info	186
	Switching between terminals	179
	.	470
	Switching between the terminals	179

Tying in the menu level 157
Tying start delay 160
Terminal machine functions 136
Terminal menus 152
The cam clutch is released 238
Tightening torque: wheel nuts 216
Tightening torques 212
TIM
Keys on the working screen 146
Mode of operation 146
TIM displays and keys on the working screen 146
Total counter 174
Touchable display 128, 131
Tractor requirements – hydraulics 51
Twine tying 100
Twine tying start/end position (terminal) 167
Twine wrapping and tying material 50
Tying
Ladders 82
Tying in the menu level 157
Tying start delay (terminal) 160
Type plate 44
Tyres 50

U

Universal shaft 57
Adjusting the length of the 58
Unlocking/locking blade retaining shaft 228
Unsuitable consumables 22
Upper blade cassette
Adjusting the sensor 182
Using ladders for the tying system 82
Using pivoted wrapping and tying material supply
Using the stop cock of the tailgate 80
Using the storage container for wrapping material 98

V

Validity	9
Varying functions to KRONE ISOBUS terminal	135



W

Warning signs	11
Warnings of property damage/environmental damage	12
Waste disposal 2	52
Weights	49
Working at or on heights of the machine	26



22 Declaration of conformity



EC Declaration of Conformity CE

We

KRONE Agriculture SE

Heinrich-Krone-Straße 10, D-48480 Spelle

hereby declare, as manufacturer of the product named below, under our sole responsibility, that the

Machine:Round balerSeries:RP201-21

to which this declaration refers is in compliance with the following relevant provisions of:

- EC Directive 2006/42/EC (Machinery)
- EU Directive 2014/30/EU (EMC) The harmonised standard EN ISO 14982:2009 has been applied in accordance with the directive.

The signing Managing Director is authorised to compile the technical documents.

A

Jan Horstmann

(Managing Director, Design & Development)

Spelle, 04/08/2021

Year of manufacture:

Machine no.:



Maschinenfabrik Bernard Krone GmbH & Co. KG

- Heinrich-Krone-Straße 10D-48480 Spelle
- Postfach 11 63D-48478 Spelle
- # +49 (0) 59 77 / 935-0
- 📇 +49 (0) 59 77 / 935-339
- www.landmaschinen.krone.de