

Precision Seed Drills

MAXIMA 2
Foldable telescopic frame





DEAR OWNER

In buying a Kuhn machine you have chosen wisely. Into it have gone years of thought, research and improvement. You will find, as have thousands of owners all over the world, that you have the best that engineering skill and actual field testing can produce. You have purchased a dependable machine, but only through proper care and operation can you expect to receive the performance and long service built into it.

This manual contains all the necessary information for you to receive full efficiency from your machine. The performance you get from this machine is largely dependent on how well you read and understand this manual and apply this knowledge. Please **DO NOT ASSUME YOU KNOW HOW TO OPERATE AND MAINTAIN YOUR MACHINE** before reading this manual carefully. **KEEP THIS MANUAL AVAILABLE FOR REFERENCE.** Pass it on to the next owner if you re-sell the machine.

Your KUHN dealer can offer a complete line of genuine KUHN service parts. These parts are manufactured and carefully inspected in the same factory that builds the machine to assure high quality and accurate fitting of any necessary replacements.

■ About improvements

We are continually striving to improve our products. It therefore reserves the right to make improvements or changes when it becomes practical to do so, without incurring any obligations to make changes or additions to the equipment sold previously.

■ Designated use of the machine

The **MAXIMA 2** precision seed drill must only be used for work for which it has been designed:

- Precision drilling.
- Mineral fertilizer placement (depending upon equipment).
- Application of microgranules in combination with drilling (depending upon equipment).

■ Document illustrations

The illustrations in this manual may be based on one type of machine only. However, all instructions apply to all machines covered in this manual.

CONTENTS

- **Dear Owner** 1
- **Contents** 2
- **Identification of the machine** 5
 - Front view (Basic machine) 5
 - Rear view (Basic machine)..... 5
 - Model identification plate..... 6
 - Optional equipment 7
- **Safety** 12
 - Description of symbols used in this document 12
 - Safety instructions..... 13
 - Location and description of safety decals on the machine..... 23
 - Road safety equipment and recommendations 26
- **Machine specifications**..... 27
 - Description and glossary 27
 - General technical specifications 28
 - Technical specifications per model 29
 - Sound levels..... 31
- **Putting into service**..... 32
 - Description of control elements 32
 - Control box description 32
 - Coupling and uncoupling..... 36
- **Instructions for transport**..... 51
 - Putting the machine into transport position 51
 - Conformity with the road regulations 53




- **Instructions for work**.....54
 - Putting the machine into work position 54
 - Adjustments in working position 56
 - Machine use 85
- **Optional equipment**.....94
 - Clod clearer 98
 - Spring assisted clod clearer 99
 - Star shaped trash remover 101
 - Furrow opening disk 103
 - Covering scraper 104
 - Composite intermediate axial press wheel 105
 - Stainless steel intermediate axial press wheel 107
 - Furrow closing disks 110
 - Standard V-shaped roller 111
 - HD V roller 115
 - "OTIFLEX" 370 x 165 roller 120
 - "OTIFLEX" 500 x 175 roller 122
 - Microgranulator 124
 - Fertilizer unit 139
 - Low flow kit for the fertilizer unit 154
 - Filling auger 155
 - Distribution disks 157
 - Belt and pulley units..... 158
 - Rear PTO output stub..... 158
 - Hydraulic blower drive 159
 - Vacuometer 161
 - HECTOR 3000 electronic control box 161




| | |
|--|------------|
| Passage control box kit KMS208..... | 161 |
| Sowing control box kit KMS412 | 162 |
| Electronic disengagement kit..... | 162 |
| 65 x 400 depth control wheels | 162 |
| 45 mm (1.8 ") spacer and 5 mm (0.2") levelling pad | 163 |
| 82 mm (3.2") spacer and 5 mm (0.2") levelling pad | 163 |
| Mechanical hectare counter..... | 163 |
| ■ Maintenance and storage | 165 |
| Frequency chart | 165 |
| Cleaning the machine..... | 167 |
| Lubrication | 168 |
| Maintenance | 171 |
| Storage..... | 179 |
| ■ Trouble shooting guide | 181 |
| ■ Limited warranty | 184 |

IDENTIFICATION OF THE MACHINE

1. Front view (Basic machine)




2. Rear view (Basic machine)



3. Model identification plate

Please write below the type and serial number of the machine. This information is to be indicated to the dealer for all spare parts orders.



Type: **MAXIMA 2**

Serial no.:



4. Optional equipment

Tick box corresponding to the equipment fitted on your machine:

■ Sowing component

- Kit no. 1676801:** Clod clearer with disk coulter for * 1 gauge wheels.
- Kit no. 1676802:** Clod clearer with disk coulter for * 1 gauge wheels.
- Kit no. 1676803:** Spring assisted clod clearer.
- Kit no. 1676783:** Star shaped trash remover.
- Kit no. 1676775:** Opener disc solo.
- Kit no. 1676761:** Covering scraper.
- Kit no. 1676762:** Composite intermediate axial press wheel.
- Kit no. 1676766:** Stainless steel intermediate axial press wheel.
- Kit no. 1676790:** Furrow closing disks.
- Kit no. 1677235:** Standard Rubber V roller 25 mm (1").
- Kit no. 1677234:** Standard Rubber V roller 50 mm (2").
- Kit no. 1677237:** Standard smooth steel V roller.
- Kit no. 1677236:** Standard notched steel V roller.
- Kit no. 1677241:** HD Rubber V roller 25 mm (1").
- Kit no. 1677240:** HD Rubber V roller 50 mm (2").
- Kit no. 1677239:** HD smooth steel V roller.
- Kit no. 1677238:** HD notched steel V roller.
- Kit no. 1676757:** $\varnothing 370 \times 165$ mm (1'2" x 6.4") OTIFLEX roller and covering scrapers.
- Kit no. 1676859:** $\varnothing 370 \times 165$ mm (1'2" x 6.4") OTIFLEX roller and furrow closing disks.
- Kit no. 1676758:** $\varnothing 500 \times 175$ mm (1'7" x 6.9") OTIFLEX roller and covering scrapers.
- Kit no. 1676863:** $\varnothing 500 \times 175$ mm (1'7" x 6.9") OTIFLEX roller and furrow closing disks.

■ Microgranulator

For the following models:

- M2M08RT000A003

First equipment microgranulator

- Kit no. 1677163:** Insecticide microgranulator 8 rows, 100 L (26 US gal) hopper with front blower and fitting on air duct.
- Kit no. 1677164:** Slug pellet microgranulator 8 rows, 100 L (26 US gal) hopper with front blower and fitting on air duct.
- Kit no. 1677165:** Herbicide microgranulator 8 rows, 190 (50 US gal) hopper with front blower and fitting on air duct.

Second equipment microgranulator

- Kit no. 1677139:** Insecticide microgranulator 8 rows with 100 L (26 US gal) hopper and fitting on air duct.
- Kit no. 1677140:** Slug pellet microgranulator 8 rows with 100 L (26 US gal) hopper and fitting on air duct.
- Kit no. 1677292:** Herbicide microgranulator 8 rows with 190 L (50 US gal) hopper and fitting on air duct.

For the following models:

- M2M08RT000AG03

First equipment microgranulator

- Kit no. 1677145:** Insecticide microgranulator 8 rows with 100 L (26 US gal) hopper and fitting in high position.
- Kit no. 1677146:** Anti-slug pellet microgranulator 8 rows with 100 L (26 US gal) hopper and fitting in high position.
- Kit no. 1677147:** Herbicide microgranulator 8 rows with 190 L (50 US gal) hopper and fitting in high position.

Second equipment microgranulator

- Kit no. 1677145:** Insecticide microgranulator 8 rows with 100 L (26 US gal) hopper and fitting in high position.
- Kit no. 1677146:** Anti-slug pellet microgranulator 8 rows with 100 L (26 US gal) hopper and fitting in high position.
- Kit no. 1677147:** Herbicide microgranulator 8 rows with 190 L (50 US gal) hopper and fitting in high position.

- Kit no. 1677228:** Low flow kit for the fertilizer unit.
- Kit no. 1677227:** Loading screw for fertilizer unit fitted with a 1350 L (356 US gal) hopper.

■ Fertilizer unit

For the following models:

- M2M08RT000AG03

- Kit no. 1677058:** Fertilizer 8 rows with 1350 L (356 US gal) hopper and applicators with standard Suffolk coulters.
- Kit no. 1677059:** Fertilizer 8 rows with 1350 L (356 US gal) hopper and applicators with non-stop Suffolk coulters.
- Kit no. 1677060:** Fertilizer 8 rows with 1350 L (356 US gal) hopper and applicators with non-top disk coulters.

- Kit no. 1677227:** Loading screw for fertilizer equipped with 1350 L (356 US gal) hoppers.

■ Distribution disks

SP = Disk without agitator blades.

AP = Disk with agitator blades.

- Kit no. N1503620:** Distribution disk 12 holes of diameter 1.5 mm (0.06") **AP**.
- Kit no. N04343B0:** Distribution disk 12 holes of diameter 2.5 mm (0.1") **AP**.
- Kit no. N1502090:** Distribution disk 12 holes of diameter 3.5 mm (0.14") **AP**.
- Kit no. N04286B0:** Distribution disk 18 holes of diameter 1.5 mm (0.06") **SP**.
- Kit no. N00846B0:** Distribution disk 18 holes of diameter 2.5 mm (0.1") **AP**.
- Kit no. N04318B0:** Distribution disk 18 holes of diameter 3 mm (0.12") **AP**.
- Kit no. N00847B0:** Distribution disk 18 holes of diameter 3.5 mm (0.14") **AP**.
- Kit no. N00856B0:** Distribution disk 22 holes of diameter 2.1 mm (0.08") **SP**.
- Kit no. N1503810:** Distribution disk 22 holes of diameter 2.1 mm (0.08") **AP**.
- Kit no. N04341B0:** Distribution disk 22 holes of diameter 2.5 mm (0.1") **AP**.
- Kit no. N03840B0:** Distribution disk 22 holes of diameter 3.5 mm (0.14") **AP**.
- Kit no. N00851B0:** Distribution disk 22 holes of diameter 4.5 mm (0.18") **AP**.
- Kit no. N02511B0:** Distribution disk 22 holes of diameter 5 mm (0.2") **AP**.
- Kit no. N00852B0:** Distribution disk 22 holes of diameter 5.5 mm (0.22") **AP**.
- Kit no. N1503140:** Distribution disk 27 holes of diameter 2.5 mm (0.1") **AP**.
- Kit no. N1500670:** Distribution disk 27 holes of diameter 3 mm (0.12") **SP**.
- Kit no. N03823B0:** Distribution disk 27 holes of diameter 3.5 mm (0.14") **AP**.
- Kit no. N00843B0:** Distribution disk 27 holes of diameter 4.5 mm (0.18") **AP**.
- Kit no. N00905B0:** Distribution disk 27 holes of diameter 5 mm (0.2") **AP**.
- Kit no. N00844B0:** Distribution disk 27 holes of diameter 5.5 mm (0.22") **AP**.
- Kit no. N1500340:** Distribution disk 30 holes of diameter 7 mm (0.28") **AP**.
- Kit no. N00845B0:** Distribution disk 31 holes of diameter 2.1 mm (0.08") **SP**.
- Kit no. N00855B0:** Distribution disk 33 holes of diameter 3.5 mm (0.14") **AP**.
- Kit no. N04107B0:** Distribution disk 33 holes of diameter 4.5 mm (0.18") **AP**.
- Kit no. N04282B0:** Distribution disk 33 holes of diameter 5.5 mm (0.22") **AP**.

- Kit no. N1503380:** Distribution disk 35 holes of diameter 3.5 mm (0.14") **AP.**
- Kit no. N1503390:** Distribution disk 35 holes of diameter 4.5 mm (0.18") **AP.**
- Kit no. N1503400:** Distribution disk 35 holes of diameter 5 mm (0.2") **AP.**
- Kit no. N1503410:** Distribution disk 35 holes of diameter 5.5 mm (0.22") **AP.**
- Kit no. K3601440:** Distribution disk 48 holes of diameter 1.25 mm (0.05") **SP.**
- Kit no. N02951B0:** Distribution disk 48 holes of diameter 2.5 mm (0.1") **AP.**
- Kit no. N00848B0:** Distribution disk 48 holes of diameter 3.5 mm (0.14") **AP.**
- Kit no. N04305B0:** Distribution disk 48 holes of diameter 4.5 mm (0.18") **AP.**
- Kit no. N1503130:** Distribution disk 48 holes of diameter 5.5 mm (0.22") **AP.**
- Kit no. N1500061:** Distribution disk 54 holes of diameter 3 mm (0.12") **SP.**
- Kit no. N1500681:** Distribution disk 54 holes of diameter 4.5 mm (0.18") **AP.**
- Kit no. N1500691:** Distribution disk 54 holes of diameter 5.5 mm (0.22") **AP.**
- Kit no. N1500431:** Distribution disk 70 holes of diameter 1.25 mm (0.05") **SP.**
- Kit no. N02851B0:** Distribution disk 70 holes of diameter 2.5 mm (0.1") **AP.**
- Kit no. N04342B0:** Distribution disk 70 holes of diameter 3.5 mm (0.14") **AP.**
- Kit no. N00850B0:** Distribution disk 70 holes of diameter 4.5 mm (0.18") **AP.**
- Kit no. N1502170:** Distribution disk 80 holes of diameter 2.5 mm (0.1") **AP.**
- Kit no. N1501591:** Distribution disk 80 holes of diameter 3.5 mm (0.14") **AP.**
- Kit no. N1501051:** Distribution disk 100 holes of diameter 0.8 mm (0.03") **SP.**
- Kit no. N00849B0:** Distribution disk 100 holes of diameter 1.25 mm (0.05") **SP.**
- Kit no. N1500701:** Distribution disk 100 holes of diameter 1.75 mm (0.07") **AP.**
- Kit no. N04293B0:** Distribution disk 100 holes of diameter 3.5 mm (0.14") **AP.**

■ Blower

- Kit no. 1677287:** 470 min⁻¹ pulley and belt unit
- Kit no. 1676731:** 870 min⁻¹ pulley and belt unit
- Kit no. 1676738:** 1000 min⁻¹ pulley and belt unit
- Kit no. 1676730:** Rear PTO output stub.
- Kit no. 1676545:** Hydraulic blower drive.



Kit no. 1676546: Hydraulic hose extension.

Kit no. 1677223: Vacuumeter.

■ **Control units**

Kit no. 1676822: HECTOR 3000 electronic unit.

Kit no. 1676659: Passage control box kit KMS208.

Kit no. 1676428B: Sowing control box kit KMS412.

Kit no. 1677299: Electronic disengagement kit.

■ **Sundry**

Kit no. 1676520: 65 x 400 depth control wheels.

Kit no. 1677293: 45 mm (1.8") spacer and 5 mm (0.2 ") levelling pad.


Kit no. 1676792: 82 mm (3.2") spacer and 5 mm (0.2 ") levelling pad.

Kit no. 1676821: Mechanical hectare counter.


SAFETY

1. Description of symbols used in this document


This symbol indicates a potentially hazardous situation that if not avoided, could result in serious bodily injury.



This symbol is used to identify special instructions or procedures which, if not followed strictly, could result in machinery damage.



This symbol is used to communicate technical information of particular interest.



2. Safety instructions

■ Introduction

The machine must only be operated, maintained and repaired by competent persons who are familiar with machines' specifications and operation and aware of safety regulations for preventing accidents.

The operator must imperatively respect safety instructions in this manual and in the warnings posted on the machine. The operator is also obliged to respect current legislation concerning accident prevention, work safety and public traffic circulation.

Designated use of the machine also means following operation, maintenance and repair recommendations given by the manufacturer, and using only genuine spare parts, equipment and accessories, as recommended by the manufacturer.

The manufacturer is not held liable for any damage resulting from machine applications other than those specified by the manufacturer. Any use other than the designated operation is at the risk and responsibility of the operator.

The manufacturer is not held liable for any damage or accident resulting from machine modifications carried out by the operator himself or by a third party without previous written agreement from the manufacturer.

■ Read and follow the safety instructions

Before using the machine, carefully read all the safety instructions in this manual and the warnings placed on the machine.

Before starting work, the operator must be familiar with all machine controls, handling devices and their functions. It is too late to learn once work has been started!


Never let anyone operate the machine who is not trained to do so.

Should you have any difficulties in understanding certain parts in this manual, please contact your KUHN dealer.



■ Precautions to be taken before carrying out any operations on the machine

Before leaving the tractor or before adjusting, maintaining or repairing the machine, disengage the PTO drive, turn off the engine, remove ignition key and wait until all moving parts have come to a complete stop and apply park brake.



599004000

■ Precautions to take before using the machine

Do not wear loose clothing which could become caught up in moving parts.

Wear the appropriate protective clothing for the work in hand (gloves, shoes, goggles, helmet, ear-protectors, etc.).

Ensure that all operating controls (ropes, cables, rods, etc) are placed so as they cannot be operated unintentionally and cause damage or injury.

Before operating the machine, check tightness of nuts and bolts, particularly on fixing elements (tines, forks, blades, knives, etc). Retighten if necessary.

Before operating the machine, ensure that all the safety guards are firmly in place and in good condition. Immediately replace any worn or damaged guard.



■ Precautions when driving

Tractor handling, stability, performance and braking efficiency are all affected by weight distribution, trailed or mounted implements, additional ballast and driving conditions. It is therefore of the great importance that the operator exercises caution in every given situation.


Groundspeed must be adapted to ground conditions as well as to roads and paths. Always avoid abrupt changes of direction.

Be particularly cautious when turning corners, paying attention to machine overhang, length, height and weight.

Never use a narrow track tractor on very uneven or steeply sloping ground.

Never leave the tractor seat while the machine is operating.

Carrying people or animals on the machine when working or in transport is strictly forbidden.



■ Precautions when driving on public roads

Dimensions


Depending on the dimensions of the machine, contact the relevant authorities to ensure that it can be legally transported on public roads.

If the machine is over the maximum legal size, follow the local regulations for special transportation of oversize equipment.

Gross weight and weight per axle

Check that the tractor's authorized gross weight as well as its lift capacity and maximum weight per axle are not exceeded.

The front axle load (1) must never, under any circumstances, be less than 20% of the tractor's unladen weight. If necessary, add ballast weights to the front or to the rear to preserve the steering and braking efficiency.



Transport position

Before transporting the machine on public roads, place the machine into its transport position, according to the instructions in this manual.

Lightings and signallings

Before transporting the machine on public roads, ensure that all legally required lightings and signallings are in place.

Ensure that lightings and signallings are clean and in good working order. Replace any missing or broken equipment.



Always obey current regulations for driving on roads.

■ Maximum speed

Always keep to the legal speed limit for driving a tractor-machine assembly on public roads.

■ Precautions when coupling

Before attaching the machine, make sure that it cannot accidentally start moving (chock the wheels) and that the parking stand is in the right position.

The machine must only be attached to the hitch points provided for this purpose.

Never stand between the tractor and the machine when operating the three point linkage.

Do not stand between the tractor and the machine without ensuring that the parking brake is applied.



■ Hydraulic circuit

Beware : The hydraulic circuit is under pressure.

Maximum pressure at work: 200 bar (2857 psi).

Before connecting hoses to the tractor hydraulics, ensure that tractor and machine circuits are not under pressure. Before disconnecting a hose, depressurize the hydraulic circuit.

To avoid making incorrect connections, mark hydraulic couplers and corresponding hoses with colors.

WARNING! Functions could be reversed (for example: lift/lower) and cause accidents.

Regularly check the hydraulic hoses. In case of normal wear, replace the hydraulic hoses every 5 years.

Damaged or worn hoses must immediately be replaced.

When replacing the hydraulic hoses, make sure to use hoses with the specifications and quality recommended by the manufacturer of the machine.

To locate a leak, use appropriate means.

Protect body and hands from liquid under pressure.

Any liquid under pressure (particularly oil from hydraulics) can penetrate the skin and cause severe injury. If injured, see a doctor immediately, there could be danger of infection.

Before any adjustments, maintenance or repairs are carried out, lower the machine on the ground, depressurize the hydraulics, turn off the engine, remove ignition key and wait until all moving parts have come to a complete stop.



■ PTO shaft

Use only PTO shafts supplied with the machine or recommended by the manufacturer.

The protective shield of the tractor PTO stub, the PTO shaft guards and the protective covering of the machine input shaft must always be in place and in good condition.

Make sure that the PTO shaft guards are secured with the safety chains provided.

Any worn or damaged guards must be replaced immediately. A worn guard or an unprotected PTO shaft can cause a serious or even a lethal accident.

Do not wear loose clothing that could be caught in the rotating PTO shaft.

Before attaching or removing a PTO shaft, or before doing any work on the machine, disengage the PTO drive, turn off the engine, remove ignition key and wait for all moving parts have come to a complete stop.

If the primary PTO shaft is equipped with a slip clutch or a free wheel, these must be fitted on the machine side.

Ensure that the PTO shaft is always correctly fitted and locked into place.

Before connecting the PTO shaft, ensure that the PTO speed (rotational frequency) and directions of rotation are in line with manufacturer's recommendations.

Before engaging the PTO drive, make sure all people and animals are clear from the machine. Never engage the PTO drive when the tractor engine is stopped.

When uncoupling the machine, rest the PTO shaft on the support specially provided, and replace protective cover on the PTO stub of the tractor.

Read and follow the instructions in the operator's manual provided with the PTO shaft.



■ Precautions during manoeuvres

When moving the machine from the transport position to the working position and vice versa, make sure that nobody is within the machine pivoting area.

■ Remote controlled components

Danger of crushing and shearing can exist when components are operated by hydraulic or pneumatic controls. Keep away from these danger zones.

■ Safety decals

Safety warning decals to respect, are placed in pictorial form on various parts of the machine. They are there to warn you of potential dangers and to tell you how to avoid accidents.

Always keep the safety decals clean and readable, and replace them when they are worn, damaged, missing or illegible.

■ Waste disposal

Respect the environment! Never spill pollutants (oil, grease, filters etc.) on the ground neither pour them down the drain or discard them in any other place where they could pollute the environment. Never throw away or burn a tire. Always take waste to specialized recycling or waste disposal centers.



■ Precautions for maintenance and repair work

Before leaving the tractor or before adjusting, maintaining or repairing the machine, disengage the PTO drive, turn off the engine, remove ignition key and wait until all moving parts have come to a complete stop and apply park brake.

Rest the machine on the ground, release the pressure from the hydraulic circuit and leave the machine to cool down.

Make sure that the parts of the machine that need to be lifted for maintenance or repair work are firmly propped up.

Before any work is done on the electric circuit or before any electric welding is carried out on the attached machine, disconnect the machine from the tractor electrical circuit. Also disconnect alternator and battery terminals.

Repairs on elements under pressure or tension (springs, pressure accumulators, etc.) must only be carried out by competent persons with regulation equipment.

Wear the appropriate protective clothing for the work in hand (gloves, shoes, goggles, helmet, ear-protectors, etc.).

Do not solder, weld or use a blow torch near fluids under pressure or inflammable products.

For your own safety and for correct machine operation, only use original manufacturer parts.

It is strongly recommended to have your machine checked by your Kuhn dealer after each season, especially tools and their attaching hardware.



■ Projection of stones and foreign objects

For driver safety, always use a tractor equipped with a cab. Never start the machine when there are people nearby. Even when the machine is used in accordance with its purpose, objects may be projected. Stones and other foreign objects projected by the moving parts can travel a considerable distance. Keep all persons and animals away from the danger zone.



■ Precautions for machine use

Before use, check the condition of the fasteners in accordance with the instructions contained in this manual.

Keep all persons and animals away from the danger zone. Check that nobody is within the side marker operating area on headlands.

Stay a safe distance from the machine when the cutting tools are in movement.

Never work in reverse.

Stay away from the machine until all moving parts have come to a complete standstill.

Check the entire machine for any damage before resuming work.

Never engage the tractor PTO drive when the machine is in transport position.

If the machine hits an obstacle, disengage the PTO drive, stop the tractor engine, remove the ignition key and wait for all moving parts to come to a complete standstill. Check the entire machine for any damage before resuming work.

■ Precautions to take with crop protection products

Keep crop protection products away from children.

Do not clean outlets, spreaders, tubes or other small parts by blowing with the mouth. When using crop protection products, never smoke or eat.

All precautions must be taken to prevent hopper from overflowing and products from flowing outside the treatment area.

Booms and tanks are to be drained in all cases over the areas under cultivation in accordance with regulatory provisions.

Keep machine control and handling devices clean and make sure to wash your hands prior to using these devices.

Rinse and pierce packagings to prevent them from being reused.

Find out about and comply with the instructions on the use of crop protection products with regards to their possible harmfulness for insects and wildlife, especially for pollinating insects.

Consulting and respecting the rules given in the operating instructions, the safety files and in the advice documents is the basis of behaving responsibly.

Store crop protection products in a place with a leakproof floor enabling to recover product leaks.

■ Body protection

Wear waterproof clothing whenever there is a risk of splashing from or contact with crop protection products, even in diluted form. Wear specific protective clothing (suit, gloves, boots, glasses, mask) when handling phytosanitary products).

Wear gloves that are resistant to the various components contained in the products (ultranitrile gloves). Neoprene gloves are required in the presence of ketone in the formulations.

Strictly avoid certain materials such as latex or PVC. A watertightness indicator is insufficient.

Replace gloves as soon as they present signs of wear.

Store the gloves in a place well away from the products.



Use special protection suits resistant to the products.



Wear a respiratory protection when preparing the spray mixture or spraying certain products.

Check that the respiratory protections are fitted with filters.

Change cartridges every 40h during intensive use periods.

Replace respiratory protection at least once per year.



Anti-dust masks do not protect sufficiently against phytosanitary products.

■ Toxic substances

It is recommended to have a first-aid kit within reach.

Avoid all skin, eyes and mouth contact with products such as fuels, oils, solvents, antifreeze and cleaning products. Most of them contain harmful substances.

In case of an incident, seek medical advice.



Follow to the letter all instructions given on the safety decals of toxic substance containers.

■ Compatibility of phytosanitary products and microgranulators

There are no known contraindications of incompatibility between solid phytosanitary products and the material used in the microgranulator assembly.

3. Location and description of safety decals on the machine

■ Location of safety decals



■ Description of safety decals


Operating instructions (1)

The operators' manual contains all the information necessary for using the machine safely. It is imperative to read and comply with all instructions.



Working on the machine (2)

Before leaving the tractor or before adjusting, maintaining or repairing the machine, disengage the PTO drive, turn off the engine, remove ignition key and wait until all moving parts have come to a complete stop and apply park brake.



Body crushing (3)

The side markers must always be locked for transport.




Risk of falling (4)

Do not ride on the machine when it is moving. There is a risk of falling.



Manoeuvring area (5)

Stay a safe distance from the machine. Crushing hazard.




4. Road safety equipment and recommendations

The road safety equipment is mounted in the factory or by your authorized Kuhn dealer according to current safety regulations. Always keep to the legal speed limit for driving a tractor-machine assembly on public roads.

Whatever the speed, we recommend, for everyone's safety, not to exceed a speed of 25 km/h.


The front safety device comprises:

- 2 signalling panels (1).
- 2 white lights (2).



The rear safety device comprises:

- 2 signalling panels (1).
- 2 red lights (2).
- 2 red reflectors (3).




■ Instructions specific to France

To conform with the current road regulations, the machine must be fitted with specific signalling panels when driving on public roads.




Kit no. 1626691



MACHINE SPECIFICATIONS

1. Description and glossary



- | | |
|----------------------|-------------------------------------|
| 1 : Coupling device | 2 : Three-point hitch coupler |
| 3 : Blower | 4 : Vacuum turbine |
| 5 : Drive wheel | 6 : Sowing component |
| 7 : Side marker | 8 : Seeding unit hopper |
| 9 : Control hatch | 10 : Distribution disc |
| 11 : Selector | 12 : Sowing depth adjustment handle |
| 13 : Gauge wheel | 14 : Press wheel |
| 15 : Pressure spring | |




2. General technical specifications

| Maxima 2 Foldable telescopic frame | |
|---|---------------------------------------|
| Attachment type | Category 2 linkage |
| PTO speed | 540 min ⁻¹ |
| Unit hopper capacity | 52 L (3 US gal) |
| Minimum PTO power requirement | |
| - When starting the PTO | 8.2 kW (11 hp) (approximately) |
| - At work | 4.4 kW (6 hp) (approximately) |
| Torque | |
| - When starting the PTO | From 12 to 15 daN m (88 - 110 lbf ft) |
| - At work | From 8 to 9 daN m (59 - 66 lbf ft) |
| Tyre pressure | |
| - 26 x 12 | 2.7 bar (39 psi) |

3. Technical specifications per model


■ M2M08RT000A003



M2M08RT000A003

| | |
|------------------------------------|--------------------------------------|
| Distance between sowing components | 70 - 75 - 80 cm (2'4" - 2'6" - 2'8") |
| Number of rows | 8 |
| Width in transport position | 3000 mm (9'10") |
| Length in transport position | 2400 mm (7'10") |
| Height in transport position | 3400 mm (11'2") |
| Weight | 2400 kg (5291 lb) |

■ M2M08RT000AG03



M2M08RT000AG03

| | |
|------------------------------------|--------------------------------------|
| Distance between sowing components | 70 - 75 - 80 cm (2'4" - 2'6" - 2'8") |
| Number of rows | 8 |
| Width in transport position | 3000 mm (9'10") |
| Length in transport position | 2400 mm (7'10") |
| Height in transport position | 3400 mm (11'2") |
| Weight | 2945 kg (6493 lb) |

4. Sound levels

Sound levels have been measured in accordance with the measuring methods as defined in:

NF EN 1553 "Agricultural machinery - Self-propelled, mounted, semi-mounted and trailed - Common safety recommendations"

Weighted equivalent continuous acoustic pressure level at the driver's seat (closed cabin) L (A) eq:

Tractor only: **69.4 dB(A)**

Tractor + machine: **70.1 dB(A)**

PUTTING INTO SERVICE

1. Description of control elements

The machine can be fitted with several control boxes to monitor all functions.



2. Control box description

The KMS412 control box enables monitoring the seed population.



The KMS208 control box enables controlling the seed passage.



The KMD112 disengagement control box can only function in combination with control boxes KMS208 or KMS412.

The KMD112 disengagement control box allows electrical disengagement of one or several rows at any time.



The HECTOR 3000 electronic control box is used to::

- Count the area sown (daily and total counter).
- Indicate forward speed.




The functioning and setting of the control boxes are indicated in the complementary instructions supplied.

■ Positioning and parking


Fitting the control boxes

The control boxes must be easy to access from the tractor cab.




Control boxes KMS412/KMS208 and KMD112:

- Drilling of 2 holes diameter 11 mm (1).
- 100 mm Hole to hole distance (2).
- Fit holder (3) using screws, washers and nuts (4).
- Position control box (5) using screws (6).



Control box HECTOR 3000:

The attachment is ensured by magnet (1).




Removing the control boxes

The control boxes must be stored in a dry place free of dust.

■ 3 pin plug

The box is energized by the tractor's 3-pin socket(DIN 9680, ISO 12369) or the battery power cable supplied.

| Pin | Wire color | Function |
|-------------|------------|-----------|
| 15 / 30 (1) | Brown | + 12 Volt |
| 31 (2) | Blue | Earth |
| 82 (3) | - | - |



■ Description of the connection



Never connect battery charger or perform welding tasks without having previously disconnected the control box.

The control boxes are connected to:

- A tractor 3-pin socket.
- A supplied battery power cable.



To use the machine with another tractor, a second tractor-side power harness can be ordered under p/n 83233001.



Do not connect the wiring harness to the starter connections.


Check that the connectors are in a good condition and clean.

If the tractor is not fitted with a battery isolation switch
Connect the wiring harness directly to the battery terminals respecting the polarities.

If the tractor is fitted with a battery isolation switch:

Connect the wiring harness to the battery isolation switch output.

The wiring harness is fitted with a 15 Amp ATO type fuse: Part no. 82333017(2).




3. Coupling and uncoupling

■ Description of coupling elements

The machine is equipped with:

- 1 PTO shaft 1 3/8" - 6 splines.
- 1 3-pin socket.
- 1 7-pin plug for the signalling equipment.
- 2 hydraulic hoses to supply the side marker cylinders.
- 2 hydraulic hoses to supply the unfolding/folding cylinders.
- 2 hydraulic hoses that pressurize the seeding unit extension/retraction cylinder.



When optional equipment is used, follow specific procedures mentioned in the related section:

- Filling auger.
- Hydraulic blower drive.

■ Preparing the tractor

The machine adapts to tractors fitted with a 3 point linkage category 2.

The tractor must be equipped with 3 double acting valves.



When optional equipment is used, follow specific procedures mentioned in the related section:

- Filling auger.
- Hydraulic blower drive.

The tractor PTO stub must rotate at a speed of 540 min^{-1} .

Belt and pulley assemblies are available to adapt the blower speed to the tractor PTO speed.




- 470 min^{-1} pulley and belt unit: **Kit no. 1677287**
- 870 min^{-1} pulley and belt unit: **Kit no. 1676731**
- 1000 min^{-1} pulley and belt unit: **Kit no. 1676738**



The front axle load (1) must never, under any circumstances, be less than 20% of the tractor's unladen weight.




The tractor must be fitted with lower link stabilizers.




Lateral adjustment of the lower linkage arms

Balance the play on either sides of the lift linkage and lock lower link stabilizers.



Parallelism of lower linkage arms


Adjust tractor lift rods so that lower linkage arms are at equal height from ground.



Placing the tractor lift linkage in floating position

Adjust turn buckles (1) in order to obtain floating position of the lower link arms.

This position enables free machine adaptation to the ground contours.




Tyres

If compatible with the seed drill configuration, we recommended fitting the tractor with dual wheels or extra-wide wheels in order to reduce the ground pressure.



Make sure that the seed drill never interferes with the tractor wheels.




Tractor tire pressure

To ensure that tractor can be driven safely and that machine gives the desired finish, each tyre must be inflated to the correct pressure for the load supported.


- Slightly lift the machine from the ground.
- Measure the load on each wheel (or the load of one axle divided by 2) using a weight indicator or a scale.
- Refer to the tyre manufacturer's pressure chart.
- Adjust the tyre pressure to the measured loads.

The tyre pressure must be identical on each side of the tractor.




■ Coupling the machine

- Lower the tractor three-point linkage.
- Position ball joints of tractor lower links in line with holes of machine lower yokes.
- Insert pins (1) and lock using lynch pins (2).




- Attach top link with hitch pin.
- Use tractor and machine attachment holes to adjust the top link position.
- Raise machine using the tractor lift linkage until parking stands no longer rest on the ground.



To obtain optimum PTO shaft angles and tractor lift capacity, the top link must be parallel to the lower links or slightly pointing downwards towards the tractor.

- Raise parking stands:
 - Remove lynch pin (1).
 - Raise parking stand (2).
 - Insert and lock lynch pin (1).
 - Repeat procedure on the other parking stand.



■ Electrical connection

- Connect 7-pin plug to the tractor.
- Connect control box wiring harness to the tractor 3-pin socket.



After making the connections, check that there is no risk of the cables being caught during operation.

■ Hydraulic connections

Connect hydraulic hoses (A) and (B) to a double acting outlet.


Hoses (A) and (B) supply the side marker folding/unfolding cylinders.

Connect hydraulic hoses (C) and (D) to a double acting outlet.

Hoses (C) and (D) pressurize the machine unfolding/folding cylinders.

Connect hydraulic hoses (E) and (F) to a double acting outlet.

Hoses (E) and (F) pressurize the seeding unit extension/retraction cylinder.



When optional equipment is used, follow specific procedures mentioned in the related section:




- Filling auger.
- Hydraulic blower drive.

■ Adjusting the machine

Adjusting the vertical setting

Adjust the top link length so that the machine is horizontal with regards to the ground.

This setting can be checked with the seed drill level gauge.



Check setting over the first few metres sown.

Adjusting the scrapers of the side gauge wheels

The scrapers remove soil build-up on the rubber tread of the side gauge wheels.

- Loosen bolts (1).
- Adjusting scrapers (2):


Lateral adjustment

Adjust scraper to obtain play (X) of approximately 3 mm (0.12 ") between scraper (2) and the inside rubber tread of gauge wheel (3).

Lengthways adjustment

Adjust scraper (2) as close as possible to the gauge wheel, without touching it. Rotate gauge wheel once to check that it is not in contact.

- Tighten screws (1).




In certain wet conditions with plant debris, it may be necessary to remove the scrapers to continue working without risking stopping the gauge wheels from turning.


Setting the seed row spacing

Adjusting the telescopic sowing units:

- Raise machine using tractor lift.
- Remove split pin (1).
- Remove pin (2).
- Activate hydraulic hose that control the extension/retraction cylinder of the outer seeding units until each cylinder rod (3) is in line with the hole corresponding to the required setting.




Refer to pictorial fitted on the machine to determine which hole is adequate.




- Insert pin (2).
- Reinstall split pin (1).

- Check that lengths of tie-rods (1), (2) and spacer (3) correspond to those indicated in the chart:



| Seed drill configuration | Tie-rod (1) | | Tie-rod (2) | | Spacer (3) | |
|--------------------------|-------------|-------------|-------------|-------------|------------|-------------|
| | Length | Part number | Length | Part number | Length | Part number |
| 6 rows at 70 cm (2'3") | 843 mm | N01720A0 | 386 mm | N01721A0 | 259.5 mm | N01722B0 |
| 6 rows at 72.5 cm (2'4") | | | | | | |
| 6 rows at 75 cm (2'5") | | | | | | |
| 6 rows at 77.5 cm (2'6") | | | | | | |
| 6 rows at 80 cm (2'7") | | | | | | |


- Adjust position of nut (1) to obtain required spacing between the two outer sowing units.



Proceed the same way on the other side.


Adjusting the central sowing units:

- Loosen U-bolts (1).
- Adjust position of the two central sowing units in order to obtain a spacing (E) equal to half the spacing required between rows with regards to the frame centre.
- Tighten U-bolts (1).



Adjusting the seeding units of the foldable parts:


- Loosen U-bolts (1).
- Adjust position of the seeding units to obtain required spacing E between rows.
- Tighten U-bolts (1).




Check frame connections after each modification of the row spacing.

Adjusting the stops:

- When extending the outer sowing units, nut (1) must not come into contact with guide (2) before extension/retraction cylinders have reached their travel end. Loosen nut (1) if necessary.



- Check that there is no interference when retracting the sowing units. If necessary, adjust stops (1) and (2) to increase spacing between sowing units once retracted.




Adjusting the frame connections



Check frame connections after each modification of the row spacing.


After operating the hydraulic valve that controls the seeding unit extension, check that foldable part is connected to the seed drill main frame.

- (a): Incorrect connection.
- (b): Correct connection.




Frame adjustment:

- Remove the 2 pins (1).
- Loosen the 2 screws (2).
- Carry out adjustment to obtain the connection between the foldable part and seed drill main frame.
- Tighten the 2 bolts (2).
- Insert and lock pins (1).
- Proceed the same way on the other side.




Adjust folding stops

- Operate hydraulic valve that controls extension unfolding/folding to fold the machine.
- Loosen nuts (1).
- Adjust screw (2) so that it is in contact with stop (3).
- Tighten nuts (1).
- Proceed the same way on the other side.




Adjusting the frame alignment

- Loosen the 2 counter-nuts (1).
- Tighten or loosen the 2 nuts (2) so that the foldable part is level in relation to the ground.
- Tighten the 2 counter nuts (1).
- Proceed the same way on the other side.



- Unscrew the 2 nuts (1).
- Tighten or loosen screw (2) so that foldable part is in line with the main frame.
- Tighten the 2 nuts (1).
- Proceed the same way on the other side.



■ Primary PTO shaft




Make sure that the PTO shaft is correctly adjusted, to avoid premature wear and tear.

Separate the two half PTO shafts and connect them to the machine's input shaft and to the tractor PTO stub.


Check the length of the PTO shaft:


- When the PTO shaft is in its maximum overlap position (retracted), tubes should not butt against the yokes.
- As a safety measure, a clearance (L) of at least 25 mm (1") must be maintained.
- When the PTO shaft is in its maximum extended position, the tube overlap must be more than 250 mm (10").




If this is not the case:

- Mark length (H) to cut when the transmission is the maximum overlap position.
- Shorten the guard tubes and the transmission tubes by the same length.
- Bevel and clean the tubes.
- Grease the inside of the outer tube.




 *Check that there is still a minimum overlap of 250 mm (10") when the machine is in working position and the tractor in line with the machine.*

Never operate the PTO shaft at an angle X exceeding 30°.






To avoid serious accidents, the PTO drive shaft guards must be properly in place and fixed with the chains provided.



On machine side, hook drive guard chain to ring (1).




Immediately replace any worn or damaged guard.

■ Uncoupling the machine




Park the machine on an even fairly level ground.


- Lower parking stands:
 - Remove lynch pin (1).
 - Lower parking stand (2).
 - Insert and lock lynch pin (1).
 - Repeat procedure on the other parking stand.



- Lower the tractor three-point linkage to rest the machine on the ground.
- Uncouple and place PTO shaft in support (1).
- Disconnect and store hydraulic hoses in holder (2).
- Disconnect and store signalling electric plug on holder (2).
- Disconnect and store control boxes in a dry and clean place.
- Detach the top link from the machine end.



- Remove lynch pins (2).
- Remove the 2 pins (1).
- Lower the tractor three-point linkage.



INSTRUCTIONS FOR TRANSPORT



Before placing the machine into transport position:

Wait until the rotating parts have come to a complete stop.

1. Putting the machine into transport position

From the working position:

- Disengage tractor PTO.
- Raise machine using tractor lift.




Do no never activate seed drill unfolding without having raised the two markers.

- Operate hydraulic valve that controls side marker unfolding/folding to fold the side markers.




Never activate seed drill folding without having retracted the outer units.


- Activate hydraulic hose that control the extension/retraction cylinder of the outer seeding units until seeding units are fully retracted.
- Switch hydraulic hose in neutral position.




- Unlock foldable extensions using valve (1).



- Operate hydraulic valve that controls the foldable extension unfolding/folding cylinders.



- Lock foldable extensions using valve (1).




The foldable extensions must always be locked when the machine is in transport position.

The machine is in transport position.



Never engage the tractor PTO drive when the machine is in transport position.



2. Conformity with the road regulations



Before driving the machine on public roads, ensure that the machine complies with current highway code regulations.


Check that the light boards are clean and that the lighting equipment functions before transporting the machine on public roads.



Immediately replace any worn or damaged signalling panels or lights.



Check that foldable extension valve is in locked position.



During transport, adapt the travel speed to suit the road conditions.

INSTRUCTIONS FOR WORK

Before placing the machine in working position:





- Check that nobody is within the machine pivoting area.
- If there is someone, make sure the person moves away.


1. Putting the machine into work position

From the transport position:


- Unlock foldable extensions using valve (1).
- Operate hydraulic valve that controls the foldable extension unfolding/folding cylinders.



- Lock foldable extensions using valve (1).



- Activate hydraulic hose pressurizing the extension/retraction cylinder of the outer seeding units in order to fully extend the seeding units.
- Switch hydraulic hose in neutral position.




- Operate hydraulic valve that controls side marker unfolding/folding to unfold side markers.
- Lower the machine using the tractor lift linkage.

The machine is in working position.

2. Adjustments in working position


■ Adjusting the seeding unit ground pressure

The seeding unit ground pressure is modified by changing the position of springs (1).




Coupling device (a):

By moving one spring (1) rearwards, the seeding unit ground pressure is increased by 20 kg (44 lb).



Coupling device (b):

By moving 2 springs (1) rearwards, the seeding unit ground pressure is increased by 40 kg (88 lb).




When the 2 springs (1) are positioned in configuration (b), check that the frame is sufficiently ballasted.

The drive wheels must not slip. If necessary ballast the frame.



When the machine is fitted with electronic seeding unit disengagement system (1), never position springs (2) in configuration (c). There is a risk of interference.




■ Adjusting the sowing depth

Handle (1) enables adjusting the sowing depth.



The sowing depth can be adjusted from 0 to 8.5 cm (0" - 3.34") (approximately).



Adjustment:

Refer to the decal applied on the machine to determine handle (1) setting position.



Settings are only indicated for your information.

The seeding unit setting must be adjusted according to the sowing conditions (Soil preparation and nature).

| | cm | inch |
|----|-----|------|
| AA | 0,0 | 0,0 |
| AB | 1.0 | 0.4 |
| BB | 1.5 | 0.6 |
| BC | 2.0 | 0.8 |
| CC | 2.5 | 1.0 |
| CD | 3.2 | 1.3 |
| DD | 4.0 | 1.6 |
| DE | 4.5 | 1.8 |
| EE | 5.0 | 2.0 |
| EF | 5.5 | 2.2 |
| FF | 6,2 | 2.4 |
| FG | 7.0 | 2.7 |
| GG | 7.5 | 2.9 |
| GH | 8,0 | 3.1 |
| HH | 8,5 | 3.3 |

N00898E0


Example:

To adjust the sowing depth at 4.5 cm (1.77"), place adjustment handle in position **D-E**.

- Repeat procedure on each seeding unit.



The marking enables identical setting of each seeding unit.



■ **Adjusting the markers**

The side markers are designed to provide marking in the tractor center or wheel track.

Marking to the tractor wheel

Calculating the distance (M):

- M: distance between the marker disk and the outer seeding unit.
- N: Number of rows.
- E: distance between rows.
- V: Tractor wheel track.

$$M = \frac{E \times (N + 1) - V}{2}$$


Example:

N = 8 rows

E = 750 mm (2.5")

V = 1800 mm (5'11")

$$M = \frac{750 \times (8 + 1) - 1800}{2} = 2475 \text{ mm (8'10")}$$



Marking in line with the tractor

Calculating the distance (M):

- M: distance between the marker disk and the outer seeding unit.
- N: Number of rows.
- E: distance between rows.


$$M = \frac{E \times (N + 1)}{2}$$

Example:

N = 8 rows


E = 750 mm (2.5")

$$M = \frac{750 \times (8 + 1)}{2} = 3375 \text{ mm (11')}$$



Adjusting the length (M)

- Unscrew the 2 bolts (1).
- Move side marker extension (2) to obtain required length M.
- Check that spacer (3) located between the rigid arm and the pivoting arm is fully inside the rigid arm.



The spacer prevents deterioration of the moving arm when tightening the screws.

- Tighten bolts (1).


Repeat procedure on the second side marker.



You are recommended to check this setting in the field, by inspecting several runs.

Angle adjustment


- Unscrew the 2 bolts (1).
- Pivot arm (2) to adjust the disc angle with regards to the soil type.
- Tighten bolts (1).



Repeat procedure on the second side marker.

Adjustment of the bottom stop

- Loosen the 2 counter-nuts (1).
- Adjust length of screws (2).
- Tighten the 2 counter nuts (1).



Repeat procedure on the second side marker.

■ Selection of disks



Never drill out disks in order to increase the diameter of the intake holes, otherwise serious deterioration of sowing accuracy may result.

For Maize seeds

In general, use disks with holes of diameter 5 mm (0.2 ") for maximum versatility (Standard supplied).

Maize seeds with very angular or pointed shapes can be sown with a disk with 4.5 mm (0.17 ") diameter holes to improve seed placement in the row.

For sowing very large maize seeds, we recommend using a disk with 5.5 mm (0.21 ") diameter holes.

For sowing very small sweet corn seeds, we recommend using a disk with 3.5 mm (0.14 ") diameter holes.

For Sunflower seeds

Successful sunflower sowing depends on two factors:

- The adaptation of the disk hole diameter to the seed size.
- The selector adjustment.

Indications on the seed bags do not mention the seed size.




We recommend to possess 2 disk models (holes diameter 2.5 mm (0.1 ") and 3.5 mm (0.14 ")) if the seed size to be purchased cannot be specified.

Fine and medium Sunflower

For sowing fine or medium sunflower seeds, we recommend using a disk with 2.5 mm (0.1 ") diameter holes.



For sowing fine or medium sunflower seeds, using a disk with 3.5 mm (0.14 ") diameter holes does not enable fine tuning of the selection (Too many misses or doubles).



Coarse Sunflower

For sowing large sunflower seeds, we recommend using a disk with 3.5 mm (0.14 ") diameter holes.



For sowing large sunflower seeds, using a disk with 2.5 mm (0.1 ") diameter holes does not enable fine tuning of the selection (Correct positioning but with too much misses).




Table of recommended distribution disks

| Type of seeds | Number of holes | Hole diameter (mm) | Min/max spacing (cm) |
|-----------------|-----------------|--------------------|----------------------|
| Maize | 27 | 5.0 | from 8 to 24.1 |
| Maize | 27 | 4.5 | from 8 to 24.1 |
| Maize | 27 | 5.5 | from 8 to 24.1 |
| Maize | 22 | 5.0 | from 9.8 to 29.5 |
| Maize | 22 | 4.5 | from 9.8 to 29.5 |
| Maize | 22 | 5.5 | from 9.8 to 29.5 |
| Sunflower | 18 | 2.5 | from 12 to 36.1 |
| Sunflower | 18 | 3.5 | from 16 to 36.1 |
| Bean | 48 | 3.5 | from 4.5 to 13.5 |
| Bean | 48 | 2.5 | from 1.5 to 13.5 |
| Sorghum | 70 | 2.5 | from 3.1 to 9.3 |
| Beet | 31 | 2.1 | from 7 to 21 |
| Beet | 22 | 2.1 | from 9.8 to 29.5 |
| Soy | 70 | 4.5 | from 3.1 to 6.3 |
| Delinted cotton | 33 | 3.5 | from 6.5 to 19.7 |

■ Fitting distribution disks

Before changing a disk, empty the seeding unit hopper.



Mark disks prior to removing them in order to determine their respective position. A disk must always be fitted on the same sowing unit.

- Open hood (1).
- Install distribution disk (2) on drive shaft (3).




When disks are fitted with agitator blades, position disks with agitator blades pointing inwards.



Check that the distribution disk is properly positioned on the drive shaft.

- Close hood (1).



■ Selecting and fitting seed ejectors

When the machine is used with disks with only one row of holes, the ejector **BNB0083** (1) must be fitted.



This ejector must always be fitted whatever the seed variety.

When disks are not fitted with agitator blades, install spacer **BNB0048** (1).





The agitator blades fitted on the disk enable preventing seed bridging in the casing.



Spacer **BNB0048** stops small seeds from flowing freely through the groove.

When the disks are fitted with agitator blades, spacer **BNB0048** (1) must be removed.



■ Adjusting the number of plants per hectare

Number of plants per hectare according to spacing between seeds and between rows

| Seed row spacing (cm) | Spacing between seeds (cm) | | | | | | | | | | | | | | |
|-----------------------|----------------------------|--------|--------|--------|-------|-------|-------|-------|-------|-------|-------|--|--|--|--|
| | 25 | 30 | 35 | 40 | 45 | 50 | 55 | 60 | 70 | 75 | 80 | | | | |
| 2,5 | 160000 | 121210 | 105260 | 100000 | 88890 | 80000 | 72730 | 66700 | 57140 | 53330 | 50000 | | | | |
| 5 | 80000 | 60606 | 52630 | 50000 | 44450 | 40000 | 36350 | 33350 | 28700 | 26650 | 25000 | | | | |
| 6 | 66667 | 50542 | 43666 | 41667 | 37075 | 33333 | 30342 | 27792 | 23603 | 22206 | 20633 | | | | |
| 7 | 57143 | 43263 | 37592 | 35143 | 31764 | 28514 | 25975 | 23810 | 20401 | 19046 | 17671 | | | | |
| 8 | 50000 | 37878 | 32898 | 31250 | 27781 | 25000 | 22781 | 20844 | 17853 | 16656 | 15625 | | | | |
| 9 | 44444 | 33659 | 29289 | 27778 | 24517 | 22222 | 20328 | 18514 | 15872 | 14813 | 13889 | | | | |
| 10 | 40000 | 30326 | 26319 | 25000 | 22225 | 20000 | 18165 | 16675 | 14260 | 13325 | 12500 | | | | |
| 11 | 35333 | 27577 | 23927 | 22723 | 20223 | 18181 | 16526 | 15153 | 12864 | 12106 | 11386 | | | | |
| 12 | 33333 | 25251 | 21992 | 20833 | 18588 | 16667 | 15151 | 13896 | 11902 | 11104 | 10417 | | | | |
| 13 | 30769 | 23036 | 20242 | 19208 | 17042 | 15345 | 13850 | 12612 | 10585 | 10208 | 9614 | | | | |
| 14 | 28571 | 21646 | 18764 | 17671 | 15872 | 14287 | 12875 | 11954 | 10206 | 9532 | 8926 | | | | |
| 15 | 26667 | 20307 | 17543 | 16667 | 14815 | 13333 | 12121 | 11117 | 9523 | 8883 | 8333 | | | | |
| 16 | 25000 | 18939 | 16446 | 15625 | 13889 | 12500 | 11354 | 10472 | 8928 | 8328 | 7812 | | | | |
| 17 | 23529 | 17820 | 15479 | 14769 | 13072 | 11767 | 10656 | 9604 | 8109 | 7626 | 7162 | | | | |
| 18 | 22222 | 16834 | 14619 | 13889 | 12356 | 11111 | 10104 | 9287 | 7881 | 7409 | 6944 | | | | |
| 19 | 21026 | 15947 | 13850 | 13159 | 11695 | 10463 | 9597 | 8774 | 7514 | 7071 | 6678 | | | | |
| 20 | 20000 | 15153 | 13175 | 12500 | 11113 | 10000 | 9093 | 8338 | 7142 | 6663 | 6250 | | | | |
| 21 | 19376 | 14228 | 12510 | 11904 | 10521 | 9528 | 8663 | 7869 | 6704 | 6348 | 5974 | | | | |
| 22 | 18181 | 13779 | 11961 | 11366 | 10101 | 9090 | 8268 | 7576 | 6492 | 6002 | 5618 | | | | |
| 23 | 17381 | 13170 | 11441 | 10856 | 9620 | 8697 | 7904 | 7267 | 6219 | 5797 | 5438 | | | | |
| 24 | 16667 | 12620 | 10946 | 10417 | 9294 | 8393 | 7670 | 7048 | 5981 | 5552 | 5208 | | | | |
| 25 | 16000 | 12121 | 10526 | 10000 | 8890 | 8000 | 7273 | 6670 | 5714 | 5333 | 5000 | | | | |
| 30 | 13333 | 10108 | 8717 | 8333 | 7407 | 6667 | 6008 | 5558 | 4761 | 4442 | 4167 | | | | |
| 35 | 11428 | 8679 | 7516 | 7142 | 6343 | 5714 | 5190 | 4762 | 4014 | 3853 | 3614 | | | | |
| 40 | 10000 | 7576 | 6578 | 6250 | 5556 | 5000 | 4546 | 4169 | 3573 | 3331 | 3129 | | | | |
| 45 | 8889 | 6759 | 5847 | 5556 | 4933 | 4444 | 4046 | 3739 | 3144 | 2928 | 2776 | | | | |
| 50 | 8000 | 6065 | 5263 | 5000 | 4444 | 4000 | 3635 | 3335 | 2870 | 2665 | 2500 | | | | |



Distribution output charts

| Metering output table - Disc 18 Holes - | | | | | | | | | | | | | | | | | | | | |
|--|------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|------|------|------|------|------|------|------|
| No. holes: | 20-SPEED-GEARBOX | | | | | | | | | | | | | | | | | | | |
| Gearbox position | A1 | A2 | A3 | A4 | B1 | B2 | B3 | B4 | C1 | C2 | C3 | C4 | D1 | D2 | D3 | D4 | E1 | E2 | E3 | E4 |
| Seed spacing (mm) | 120 | 128 | 135 | 143 | 152 | 162 | 171 | 181 | 190 | 202 | 214 | 226 | 240 | 255 | 270 | 285 | 304 | 323 | 342 | 361 |
| No. Seeds / m | 8,3 | 7,8 | 7,4 | 7,0 | 6,6 | 6,2 | 5,8 | 5,5 | 5,3 | 5,0 | 4,7 | 4,4 | 4,2 | 3,9 | 3,7 | 3,5 | 3,3 | 3,1 | 2,9 | 2,8 |
| Spacing in cm = 40 | 208,3 | 195,3 | 185,2 | 174,8 | 164,5 | 154,3 | 146,2 | 138,1 | 131,6 | 123,8 | 116,8 | 110,6 | 104,2 | 98,0 | 92,6 | 87,7 | 82,2 | 77,4 | 73,1 | 69,3 |
| Spacing in cm = 45 | 185,2 | 173,6 | 164,6 | 155,4 | 146,2 | 137,2 | 130,0 | 122,8 | 117,0 | 110,0 | 103,8 | 98,3 | 92,6 | 87,1 | 82,3 | 78,0 | 73,1 | 68,8 | 65,0 | 61,6 |
| Spacing in cm = 50 | 166,7 | 156,3 | 148,1 | 139,9 | 131,6 | 123,5 | 117,0 | 110,5 | 105,3 | 99,0 | 93,5 | 88,5 | 83,3 | 78,4 | 74,1 | 70,2 | 65,8 | 61,9 | 58,5 | 55,4 |
| Spacing in cm = 55 | 151,5 | 142,0 | 134,7 | 127,1 | 119,6 | 112,2 | 106,3 | 100,5 | 95,7 | 90,0 | 85,0 | 80,5 | 75,8 | 71,3 | 67,3 | 63,8 | 59,8 | 56,3 | 53,2 | 50,4 |
| Spacing in cm = 60 | 138,9 | 130,2 | 123,5 | 116,6 | 109,6 | 102,9 | 97,5 | 92,1 | 87,7 | 82,5 | 77,9 | 73,7 | 69,4 | 65,4 | 61,7 | 58,5 | 54,8 | 51,6 | 48,7 | 46,2 |
| Spacing in cm = 65 | 128,2 | 120,2 | 114,0 | 107,6 | 101,2 | 95,0 | 90,0 | 85,0 | 81,0 | 76,2 | 71,9 | 68,1 | 64,1 | 60,3 | 57,0 | 54,0 | 50,6 | 47,6 | 45,0 | 42,6 |
| Spacing in cm = 70 | 119,0 | 111,6 | 105,8 | 99,9 | 94,0 | 88,2 | 83,5 | 78,9 | 75,2 | 70,7 | 66,8 | 63,2 | 59,5 | 56,0 | 52,9 | 50,1 | 47,0 | 44,2 | 41,8 | 39,6 |
| Spacing in cm = 75 | 111,1 | 104,2 | 98,8 | 93,2 | 87,7 | 82,3 | 78,0 | 73,7 | 70,2 | 66,0 | 62,3 | 59,0 | 55,6 | 52,3 | 49,4 | 46,8 | 43,9 | 41,3 | 39,0 | 36,9 |
| Spacing in cm = 80 | 104,2 | 97,7 | 92,6 | 87,4 | 82,2 | 77,2 | 73,1 | 69,1 | 65,8 | 61,9 | 58,4 | 55,3 | 52,1 | 49,0 | 46,3 | 43,9 | 41,1 | 38,7 | 36,5 | 34,6 |
| Thousands of seeds per hectare | | | | | | | | | | | | | | | | | | | | |
| The quantities indicated are given by way of illustration only. They equate to 64.4 revolutions of the wheel shaft per 100 metres of travel | | | | | | | | | | | | | | | | | | | | |

| Metering output table - Disc 22 Holes - | | | | | | | | | | | | | | | | | | | | |
|---|------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|------|------|------|
| No. holes: | 20-SPEED-GEARBOX | | | | | | | | | | | | | | | | | | | |
| Gearbox position | A1 | A2 | A3 | A4 | B1 | B2 | B3 | B4 | C1 | C2 | C3 | C4 | D1 | D2 | D3 | D4 | E1 | E2 | E3 | E4 |
| Seed spacing (mm) | 98 | 104 | 111 | 117 | 124 | 132 | 140 | 148 | 156 | 165 | 175 | 185 | 196 | 209 | 221 | 233 | 249 | 264 | 280 | 295 |
| No. Seeds / m | 10,2 | 9,6 | 9,0 | 8,5 | 8,1 | 7,6 | 7,1 | 6,8 | 6,4 | 6,1 | 5,7 | 5,4 | 5,1 | 4,8 | 4,5 | 4,3 | 4,0 | 3,8 | 3,6 | 3,4 |
| Spacing in cm = 40 | 255,1 | 240,4 | 225,2 | 213,7 | 201,6 | 189,4 | 178,6 | 168,9 | 160,3 | 151,5 | 142,9 | 135,1 | 127,6 | 119,6 | 113,1 | 107,3 | 100,4 | 94,7 | 89,3 | 84,7 |
| Spacing in cm = 45 | 226,8 | 213,7 | 200,2 | 189,9 | 179,2 | 168,4 | 158,7 | 150,2 | 142,5 | 134,7 | 127,0 | 120,1 | 113,4 | 106,3 | 100,6 | 95,4 | 89,2 | 84,2 | 79,4 | 75,3 |
| Spacing in cm = 50 | 204,1 | 192,3 | 180,2 | 170,9 | 161,3 | 151,5 | 142,9 | 135,1 | 128,2 | 121,2 | 114,3 | 108,1 | 102,0 | 95,7 | 90,5 | 85,8 | 80,3 | 75,8 | 71,4 | 67,8 |
| Spacing in cm = 55 | 185,5 | 174,8 | 163,8 | 155,4 | 146,6 | 137,7 | 129,9 | 122,9 | 116,6 | 110,2 | 103,9 | 98,3 | 92,8 | 87,0 | 82,3 | 78,0 | 73,0 | 68,9 | 64,9 | 61,6 |
| Spacing in cm = 60 | 170,1 | 160,3 | 150,2 | 142,5 | 134,4 | 126,3 | 119,0 | 112,6 | 106,8 | 101,0 | 95,2 | 90,1 | 85,0 | 79,7 | 75,4 | 71,5 | 66,9 | 63,1 | 59,5 | 56,5 |
| Spacing in cm = 65 | 157,0 | 147,9 | 138,6 | 131,5 | 124,1 | 116,6 | 109,9 | 104,0 | 98,6 | 93,2 | 87,9 | 83,2 | 78,5 | 73,6 | 69,6 | 66,0 | 61,8 | 58,3 | 54,9 | 52,2 |
| Spacing in cm = 70 | 145,8 | 137,4 | 128,7 | 122,1 | 115,2 | 108,2 | 102,0 | 96,5 | 91,6 | 86,6 | 81,6 | 77,2 | 72,9 | 68,4 | 64,6 | 61,3 | 57,4 | 54,1 | 51,0 | 48,4 |
| Spacing in cm = 75 | 136,1 | 128,2 | 120,1 | 114,0 | 107,5 | 101,0 | 95,2 | 90,1 | 85,5 | 80,8 | 76,2 | 72,1 | 68,0 | 63,8 | 60,3 | 57,2 | 53,5 | 50,5 | 47,6 | 45,2 |
| Spacing in cm = 80 | 127,6 | 120,2 | 112,6 | 106,8 | 100,8 | 94,7 | 89,3 | 84,5 | 80,1 | 75,8 | 71,4 | 67,6 | 63,8 | 59,8 | 56,6 | 53,6 | 50,2 | 47,3 | 44,6 | 42,4 |
| Thousands of seeds per hectare | | | | | | | | | | | | | | | | | | | | |
| The quantities indicated are given by way of illustration only. They equate to 64.4 revolutions of the wheel shaft per 100 metres of travel. | | | | | | | | | | | | | | | | | | | | |

| Metering output table - Disc 27 Holes - | | | | | | | | | | | | | | | | | | | | |
|---|------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| No. holes: 27 | 20-SPEED-GEARBOX | | | | | | | | | | | | | | | | | | | |
| Gearbox position | A1 | A2 | A3 | A4 | B1 | B2 | B3 | B4 | C1 | C2 | C3 | C4 | D1 | D2 | D3 | D4 | E1 | E2 | E3 | E4 |
| Seed spacing (mm) | 80 | 85 | 90 | 95 | 101 | 108 | 114 | 120 | 127 | 135 | 143 | 150 | 160 | 170 | 180 | 190 | 203 | 215 | 228 | 241 |
| No. Seeds / m | 12,5 | 11,8 | 11,1 | 10,5 | 9,9 | 9,3 | 8,8 | 8,3 | 7,9 | 7,4 | 7,0 | 6,7 | 6,3 | 5,9 | 5,6 | 5,3 | 4,9 | 4,7 | 4,4 | 4,1 |
| Spacing in cm = 40 | 312,5 | 294,1 | 277,8 | 263,2 | 247,5 | 231,5 | 219,3 | 208,3 | 196,9 | 185,2 | 174,8 | 166,7 | 156,3 | 147,1 | 138,9 | 131,6 | 123,2 | 116,3 | 109,6 | 103,7 |
| Spacing in cm = 45 | 277,8 | 261,4 | 246,9 | 233,9 | 220,0 | 205,8 | 194,9 | 185,2 | 175,0 | 164,6 | 155,4 | 148,1 | 138,9 | 130,7 | 123,5 | 117,0 | 109,5 | 103,4 | 97,5 | 92,2 |
| Spacing in cm = 50 | 250,0 | 235,3 | 222,2 | 210,5 | 198,0 | 185,2 | 175,4 | 166,7 | 157,5 | 148,1 | 139,9 | 133,3 | 125,0 | 117,6 | 111,1 | 105,3 | 98,5 | 93,0 | 87,7 | 83,0 |
| Spacing in cm = 55 | 227,3 | 213,9 | 202,0 | 191,4 | 180,0 | 168,4 | 159,5 | 151,5 | 143,2 | 134,7 | 127,1 | 121,2 | 113,6 | 107,0 | 101,0 | 95,7 | 89,6 | 84,6 | 79,7 | 75,4 |
| Spacing in cm = 60 | 208,3 | 196,1 | 185,2 | 175,4 | 165,0 | 154,3 | 146,2 | 138,9 | 131,2 | 123,5 | 116,6 | 111,1 | 104,2 | 98,0 | 92,6 | 87,7 | 82,1 | 77,5 | 73,1 | 69,2 |
| Spacing in cm = 65 | 192,3 | 181,0 | 170,9 | 161,9 | 152,3 | 142,5 | 135,0 | 128,2 | 121,1 | 114,0 | 107,6 | 102,6 | 96,2 | 90,5 | 85,5 | 81,0 | 75,8 | 71,6 | 67,5 | 63,8 |
| Spacing in cm = 70 | 178,6 | 168,1 | 158,7 | 150,4 | 141,4 | 132,3 | 125,3 | 119,0 | 112,5 | 105,8 | 99,9 | 95,2 | 89,3 | 84,0 | 79,4 | 75,2 | 70,4 | 66,4 | 62,7 | 59,3 |
| Spacing in cm = 75 | 166,7 | 156,9 | 148,1 | 140,4 | 132,0 | 123,5 | 117,0 | 111,1 | 105,0 | 98,8 | 93,2 | 88,9 | 83,3 | 78,4 | 74,1 | 70,2 | 65,7 | 62,0 | 58,5 | 55,3 |
| Spacing in cm = 80 | 156,3 | 147,1 | 138,9 | 131,6 | 123,8 | 115,7 | 109,6 | 104,2 | 98,4 | 92,6 | 87,4 | 83,3 | 78,1 | 73,5 | 69,4 | 65,8 | 61,6 | 58,1 | 54,8 | 51,9 |
| Thousands of seeds per hectare | | | | | | | | | | | | | | | | | | | | |
| The quantities indicated are given by way of illustration only. They equate to 64.4 revolutions of the wheel shaft per 100 metres of travel. | | | | | | | | | | | | | | | | | | | | |

| Metering output table - Disc 31 Holes - | | | | | | | | | | | | | | | | | | | | |
|---|------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| No. holes: 31 | 20-SPEED-GEARBOX | | | | | | | | | | | | | | | | | | | |
| Gearbox position | A1 | A2 | A3 | A4 | B1 | B2 | B3 | B4 | C1 | C2 | C3 | C4 | D1 | D2 | D3 | D4 | E1 | E2 | E3 | E4 |
| Seed spacing (mm) | 70 | 74 | 78 | 83 | 88 | 94 | 99 | 105 | 110 | 117 | 124 | 131 | 139 | 148 | 157 | 166 | 177 | 188 | 199 | 210 |
| No. Seeds / m | 14,3 | 13,5 | 12,8 | 12,0 | 11,4 | 10,6 | 10,1 | 9,5 | 9,1 | 8,5 | 8,1 | 7,6 | 7,2 | 6,8 | 6,4 | 6,0 | 5,6 | 5,3 | 5,0 | 4,8 |
| Spacing in cm = 40 | 357,1 | 337,8 | 320,5 | 301,2 | 284,1 | 266,0 | 252,5 | 238,1 | 227,3 | 213,7 | 201,6 | 190,8 | 179,9 | 168,9 | 159,2 | 150,6 | 141,2 | 133,0 | 125,6 | 119,0 |
| Spacing in cm = 45 | 317,5 | 300,3 | 284,9 | 267,7 | 252,5 | 236,4 | 224,5 | 211,6 | 202,0 | 189,9 | 179,2 | 169,6 | 159,9 | 150,2 | 141,5 | 133,9 | 125,5 | 118,2 | 111,7 | 105,8 |
| Spacing in cm = 50 | 285,7 | 270,3 | 256,4 | 241,0 | 227,3 | 212,8 | 202,0 | 190,5 | 181,8 | 170,9 | 161,3 | 152,7 | 143,9 | 135,1 | 127,4 | 120,5 | 113,0 | 106,4 | 100,5 | 95,2 |
| Spacing in cm = 55 | 259,7 | 245,7 | 233,1 | 219,1 | 206,6 | 193,4 | 183,7 | 173,2 | 165,3 | 155,4 | 146,6 | 138,8 | 130,8 | 122,9 | 115,8 | 109,5 | 102,7 | 96,7 | 91,4 | 86,6 |
| Spacing in cm = 60 | 238,1 | 225,2 | 213,7 | 200,8 | 189,4 | 177,3 | 168,4 | 158,7 | 151,5 | 142,5 | 134,4 | 127,2 | 119,9 | 112,6 | 106,2 | 100,4 | 94,2 | 88,7 | 83,8 | 79,4 |
| Spacing in cm = 65 | 219,8 | 207,9 | 197,2 | 185,4 | 174,8 | 163,7 | 155,4 | 146,5 | 139,9 | 131,5 | 124,1 | 117,4 | 110,7 | 104,0 | 98,0 | 92,7 | 86,9 | 81,8 | 77,3 | 73,3 |
| Spacing in cm = 70 | 204,1 | 193,1 | 183,2 | 172,1 | 162,3 | 152,0 | 144,3 | 136,1 | 129,9 | 122,1 | 115,2 | 109,1 | 102,8 | 96,5 | 91,0 | 86,1 | 80,7 | 76,0 | 71,8 | 68,0 |
| Spacing in cm = 75 | 190,5 | 180,2 | 170,9 | 160,6 | 151,5 | 141,8 | 134,7 | 127,0 | 121,2 | 114,0 | 107,5 | 101,8 | 95,9 | 90,1 | 84,9 | 80,3 | 75,3 | 70,9 | 67,0 | 63,5 |
| Spacing in cm = 80 | 178,6 | 168,9 | 160,3 | 150,6 | 142,0 | 133,0 | 126,3 | 119,0 | 113,6 | 106,8 | 100,8 | 95,4 | 89,9 | 84,5 | 79,6 | 75,3 | 70,6 | 66,5 | 62,8 | 59,5 |
| Thousands of seeds per hectare | | | | | | | | | | | | | | | | | | | | |
| The quantities indicated are given by way of illustration only. They equate to 64.4 revolutions of the wheel shaft per 100 metres of travel. | | | | | | | | | | | | | | | | | | | | |

| Metering output table - Disc 33 Holes - | | | | | | | | | | | | | | | | | | | | |
|---|------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| No. holes: 33 | 20-SPEED-GEARBOX | | | | | | | | | | | | | | | | | | | |
| Gearbox position | A1 | A2 | A3 | A4 | B1 | B2 | B3 | B4 | C1 | C2 | C3 | C4 | D1 | D2 | D3 | D4 | E1 | E2 | E3 | E4 |
| Seed spacing (mm) | 65 | 70 | 74 | 78 | 83 | 88 | 93 | 98 | 104 | 110 | 117 | 123 | 131 | 139 | 147 | 156 | 166 | 176 | 187 | 197 |
| No. Seeds / m | 15,4 | 14,3 | 13,5 | 12,8 | 12,0 | 11,4 | 10,8 | 10,2 | 9,6 | 9,1 | 8,5 | 8,1 | 7,6 | 7,2 | 6,8 | 6,4 | 6,0 | 5,7 | 5,3 | 5,1 |
| Spacing in cm = 40 | 384,6 | 357,1 | 337,8 | 320,5 | 301,2 | 284,1 | 268,8 | 255,1 | 240,4 | 227,3 | 213,7 | 203,3 | 190,8 | 179,9 | 170,1 | 160,3 | 150,6 | 142,0 | 133,7 | 126,9 |
| Spacing in cm = 45 | 341,9 | 317,5 | 300,3 | 284,9 | 267,7 | 252,5 | 238,9 | 226,8 | 213,7 | 202,0 | 189,9 | 180,7 | 169,6 | 159,9 | 151,2 | 142,5 | 133,9 | 126,3 | 118,8 | 112,8 |
| Spacing in cm = 50 | 307,7 | 285,7 | 270,3 | 256,4 | 241,0 | 227,3 | 215,1 | 204,1 | 192,3 | 181,8 | 170,9 | 162,6 | 152,7 | 143,9 | 136,1 | 128,2 | 120,5 | 113,6 | 107,0 | 101,5 |
| Spacing in cm = 55 | 279,7 | 259,7 | 245,7 | 233,1 | 219,1 | 206,6 | 195,5 | 185,5 | 174,8 | 165,3 | 155,4 | 147,8 | 138,8 | 130,8 | 123,7 | 116,6 | 109,5 | 103,3 | 97,2 | 92,3 |
| Spacing in cm = 60 | 256,4 | 238,1 | 225,2 | 213,7 | 200,8 | 189,4 | 179,2 | 170,1 | 160,3 | 151,5 | 142,5 | 135,5 | 127,2 | 119,9 | 113,4 | 106,8 | 100,4 | 94,7 | 89,1 | 84,6 |
| Spacing in cm = 65 | 236,7 | 219,8 | 207,9 | 197,2 | 185,4 | 174,8 | 165,4 | 157,0 | 147,9 | 139,9 | 131,5 | 125,1 | 117,4 | 110,7 | 104,7 | 98,6 | 92,7 | 87,4 | 82,3 | 78,1 |
| Spacing in cm = 70 | 219,8 | 204,1 | 193,1 | 183,2 | 172,1 | 162,3 | 153,6 | 145,8 | 137,4 | 129,9 | 122,1 | 116,1 | 109,1 | 102,8 | 97,2 | 91,6 | 86,1 | 81,2 | 76,4 | 72,5 |
| Spacing in cm = 75 | 205,1 | 190,5 | 180,2 | 170,9 | 160,6 | 151,5 | 143,4 | 136,1 | 128,2 | 121,2 | 114,0 | 108,4 | 101,8 | 95,9 | 90,7 | 85,5 | 80,3 | 75,8 | 71,3 | 67,7 |
| Spacing in cm = 80 | 192,3 | 178,6 | 168,9 | 160,3 | 150,6 | 142,0 | 134,4 | 127,6 | 120,2 | 113,6 | 106,8 | 101,6 | 95,4 | 89,9 | 85,0 | 80,1 | 75,3 | 71,0 | 66,8 | 63,5 |
| Thousands of seeds per hectare | | | | | | | | | | | | | | | | | | | | |
| The quantities indicated are given by way of illustration only. They equate to 64.4 revolutions of the wheel shaft per 100 metres of travel. | | | | | | | | | | | | | | | | | | | | |

| Metering output table - Disc 48 Holes - | | | | | | | | | | | | | | | | | | | | |
|---|------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| No. holes: 48 | 20-SPEED-GEARBOX | | | | | | | | | | | | | | | | | | | |
| Gearbox position | A1 | A2 | A3 | A4 | B1 | B2 | B3 | B4 | C1 | C2 | C3 | C4 | D1 | D2 | D3 | D4 | E1 | E2 | E3 | E4 |
| Seed spacing (mm) | 45 | 48 | 51 | 53 | 57 | 61 | 64 | 68 | 71 | 76 | 80 | 85 | 90 | 96 | 101 | 107 | 114 | 121 | 128 | 135 |
| No. Seeds / m | 22,2 | 20,8 | 19,6 | 18,9 | 17,5 | 16,4 | 15,6 | 14,7 | 14,1 | 13,2 | 12,5 | 11,8 | 11,1 | 10,4 | 9,9 | 9,3 | 8,8 | 8,3 | 7,8 | 7,4 |
| Spacing in cm = 40 | 555,6 | 520,8 | 490,2 | 471,7 | 438,6 | 409,8 | 390,6 | 367,6 | 352,1 | 328,9 | 312,5 | 294,1 | 277,8 | 260,4 | 247,5 | 233,6 | 219,3 | 206,6 | 195,3 | 185,2 |
| Spacing in cm = 45 | 493,8 | 463,0 | 435,7 | 419,3 | 389,9 | 364,3 | 347,2 | 326,8 | 313,0 | 292,4 | 277,8 | 261,4 | 246,9 | 231,5 | 220,0 | 207,7 | 194,9 | 183,7 | 173,6 | 164,6 |
| Spacing in cm = 50 | 444,4 | 416,7 | 392,2 | 377,4 | 350,9 | 327,9 | 312,5 | 294,1 | 281,7 | 263,2 | 250,0 | 235,3 | 222,2 | 208,3 | 198,0 | 186,9 | 175,4 | 165,3 | 156,3 | 148,1 |
| Spacing in cm = 55 | 404,0 | 378,8 | 356,5 | 343,1 | 319,0 | 298,1 | 284,1 | 267,4 | 256,1 | 239,2 | 227,3 | 213,9 | 202,0 | 189,4 | 180,0 | 169,9 | 159,5 | 150,3 | 142,0 | 134,7 |
| Spacing in cm = 60 | 370,4 | 347,2 | 326,8 | 314,5 | 292,4 | 273,2 | 260,4 | 245,1 | 234,7 | 219,3 | 208,3 | 196,1 | 185,2 | 173,6 | 165,0 | 155,8 | 146,2 | 137,7 | 130,2 | 123,5 |
| Spacing in cm = 65 | 341,9 | 320,5 | 301,7 | 290,3 | 269,9 | 252,2 | 240,4 | 226,2 | 216,7 | 202,4 | 192,3 | 181,0 | 170,9 | 160,3 | 152,3 | 143,8 | 135,0 | 127,1 | 120,2 | 114,0 |
| Spacing in cm = 70 | 317,5 | 297,6 | 280,1 | 269,5 | 250,6 | 234,2 | 223,2 | 210,1 | 201,2 | 188,0 | 178,6 | 168,1 | 158,7 | 148,8 | 141,4 | 133,5 | 125,3 | 118,1 | 111,6 | 105,8 |
| Spacing in cm = 75 | 296,3 | 277,8 | 261,4 | 251,6 | 233,9 | 218,6 | 208,3 | 196,1 | 187,8 | 175,4 | 166,7 | 156,9 | 148,1 | 138,9 | 132,0 | 124,6 | 117,0 | 110,2 | 104,2 | 98,8 |
| Spacing in cm = 80 | 277,8 | 260,4 | 245,1 | 235,8 | 219,3 | 204,9 | 195,3 | 183,8 | 176,1 | 164,5 | 156,3 | 147,1 | 138,9 | 130,2 | 123,8 | 116,8 | 109,6 | 103,3 | 97,7 | 92,6 |
| Thousands of seeds per hectare | | | | | | | | | | | | | | | | | | | | |
| The quantities indicated are given by way of illustration only. They equate to 64.4 revolutions of the wheel shaft per 100 metres of travel. | | | | | | | | | | | | | | | | | | | | |



| Metering output table - Disc 54 Holes - | | | | | | | | | | | | | | | | | | | | |
|---|------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| No. holes: 54 | 20-SPEED-GEARBOX | | | | | | | | | | | | | | | | | | | |
| Gearbox position | A1 | A2 | A3 | A4 | B1 | B2 | B3 | B4 | C1 | C2 | C3 | C4 | D1 | D2 | D3 | D4 | E1 | E2 | E3 | E4 |
| Seed spacing (mm) | 40 | 43 | 45 | 48 | 51 | 54 | 57 | 60 | 63 | 67 | 71 | 75 | 80 | 85 | 90 | 95 | 101 | 108 | 114 | 120 |
| No. Seeds / m | 25,0 | 23,3 | 22,2 | 20,8 | 19,6 | 18,5 | 17,5 | 16,7 | 15,9 | 14,9 | 14,1 | 13,3 | 12,5 | 11,8 | 11,1 | 10,5 | 9,9 | 9,3 | 8,8 | 8,3 |
| Spacing in cm = 40 | 625,0 | 581,4 | 555,6 | 520,8 | 490,2 | 463,0 | 438,6 | 416,7 | 396,8 | 373,1 | 352,1 | 333,3 | 312,5 | 294,1 | 277,8 | 263,2 | 247,5 | 231,5 | 219,3 | 208,3 |
| Spacing in cm = 45 | 555,6 | 516,8 | 493,8 | 463,0 | 435,7 | 411,5 | 389,9 | 370,4 | 352,7 | 331,7 | 313,0 | 296,3 | 277,8 | 261,4 | 246,9 | 233,9 | 220,0 | 205,8 | 194,9 | 185,2 |
| Spacing in cm = 50 | 500,0 | 465,1 | 444,4 | 416,7 | 392,2 | 370,4 | 350,9 | 333,3 | 317,5 | 298,5 | 281,7 | 266,7 | 250,0 | 235,3 | 222,2 | 210,5 | 198,0 | 185,2 | 175,4 | 166,7 |
| Spacing in cm = 55 | 454,5 | 422,8 | 404,0 | 378,8 | 356,5 | 336,7 | 319,0 | 303,0 | 288,6 | 271,4 | 256,1 | 242,4 | 227,3 | 213,9 | 202,0 | 191,4 | 180,0 | 168,4 | 159,5 | 151,5 |
| Spacing in cm = 60 | 416,7 | 387,6 | 370,4 | 347,2 | 326,8 | 308,6 | 292,4 | 277,8 | 264,6 | 248,8 | 234,7 | 222,2 | 208,3 | 196,1 | 185,2 | 175,4 | 165,0 | 154,3 | 146,2 | 138,9 |
| Spacing in cm = 65 | 384,6 | 357,8 | 341,9 | 320,5 | 301,7 | 284,9 | 269,9 | 256,4 | 244,2 | 229,6 | 216,7 | 205,1 | 192,3 | 181,0 | 170,9 | 161,9 | 152,3 | 142,5 | 135,0 | 128,2 |
| Spacing in cm = 70 | 357,1 | 332,2 | 317,5 | 297,6 | 280,1 | 264,6 | 250,6 | 238,1 | 226,8 | 213,2 | 201,2 | 190,5 | 178,6 | 168,1 | 158,7 | 150,4 | 141,4 | 132,3 | 125,3 | 119,0 |
| Spacing in cm = 75 | 333,3 | 310,1 | 296,3 | 277,8 | 261,4 | 246,9 | 233,9 | 222,2 | 211,6 | 199,0 | 187,8 | 177,8 | 166,7 | 156,9 | 148,1 | 140,4 | 132,0 | 123,5 | 117,0 | 111,1 |
| Spacing in cm = 80 | 312,5 | 290,7 | 277,8 | 260,4 | 245,1 | 231,5 | 219,3 | 208,3 | 198,4 | 186,6 | 176,1 | 166,7 | 156,3 | 147,1 | 138,9 | 131,6 | 123,8 | 115,7 | 109,6 | 104,2 |
| Thousands of seeds per hectare | | | | | | | | | | | | | | | | | | | | |
| The quantities indicated are given by way of illustration only. They equate to 64.4 revolutions of the wheel shaft per 100 metres of travel. | | | | | | | | | | | | | | | | | | | | |

| Metering output table - Disc 70 Holes - | | | | | | | | | | | | | | | | | | | | |
|---|------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| No. holes: 70 | 20-SPEED-GEARBOX | | | | | | | | | | | | | | | | | | | |
| Gearbox position | A1 | A2 | A3 | A4 | B1 | B2 | B3 | B4 | C1 | C2 | C3 | C4 | D1 | D2 | D3 | D4 | E1 | E2 | E3 | E4 |
| Seed spacing (mm) | 31 | 33 | 35 | 37 | 39 | 42 | 44 | 46 | 49 | 52 | 55 | 58 | 62 | 66 | 69 | 73 | 78 | 83 | 88 | 93 |
| No. Seeds / m | 32,3 | 30,3 | 28,6 | 27,0 | 25,6 | 23,8 | 22,7 | 21,7 | 20,4 | 19,2 | 18,2 | 17,2 | 16,1 | 15,2 | 14,5 | 13,7 | 12,8 | 12,0 | 11,4 | 10,8 |
| Spacing in cm = 40 | 806,5 | 757,6 | 714,3 | 675,7 | 641,0 | 595,2 | 568,2 | 543,5 | 510,2 | 480,8 | 454,5 | 431,0 | 403,2 | 378,8 | 362,3 | 342,5 | 320,5 | 301,2 | 284,1 | 268,8 |
| Spacing in cm = 45 | 716,8 | 673,4 | 634,9 | 600,6 | 569,8 | 529,1 | 505,1 | 483,1 | 453,5 | 427,4 | 404,0 | 383,1 | 358,4 | 336,7 | 322,1 | 304,4 | 284,9 | 267,7 | 252,5 | 238,9 |
| Spacing in cm = 50 | 645,2 | 606,1 | 571,4 | 540,5 | 512,8 | 476,2 | 454,5 | 434,8 | 408,2 | 384,6 | 363,6 | 344,8 | 322,6 | 303,0 | 289,9 | 274,0 | 256,4 | 241,0 | 227,3 | 215,1 |
| Spacing in cm = 55 | 586,5 | 551,0 | 519,5 | 491,4 | 466,2 | 432,9 | 413,2 | 395,3 | 371,1 | 349,7 | 330,6 | 313,5 | 293,3 | 275,5 | 263,5 | 249,1 | 233,1 | 219,1 | 206,6 | 195,5 |
| Spacing in cm = 60 | 537,6 | 505,1 | 476,2 | 450,5 | 427,4 | 396,8 | 378,8 | 362,3 | 340,1 | 320,5 | 303,0 | 287,4 | 268,8 | 252,5 | 241,5 | 228,3 | 213,7 | 200,8 | 189,4 | 179,2 |
| Spacing in cm = 65 | 496,3 | 466,2 | 439,6 | 415,8 | 394,5 | 366,3 | 349,7 | 334,4 | 314,0 | 295,9 | 279,7 | 265,3 | 248,1 | 233,1 | 223,0 | 210,7 | 197,2 | 185,4 | 174,8 | 165,4 |
| Spacing in cm = 70 | 460,8 | 432,9 | 408,2 | 386,1 | 366,3 | 340,1 | 324,7 | 310,6 | 291,5 | 274,7 | 259,7 | 246,3 | 230,4 | 216,5 | 207,0 | 195,7 | 183,2 | 172,1 | 162,3 | 153,6 |
| Spacing in cm = 75 | 430,1 | 404,0 | 381,0 | 360,4 | 341,9 | 317,5 | 303,0 | 289,9 | 272,1 | 256,4 | 242,4 | 229,9 | 215,1 | 202,0 | 193,2 | 182,6 | 170,9 | 160,6 | 151,5 | 143,4 |
| Spacing in cm = 80 | 403,2 | 378,8 | 357,1 | 337,8 | 320,5 | 297,6 | 284,1 | 271,7 | 255,1 | 240,4 | 227,3 | 215,5 | 201,6 | 189,4 | 181,2 | 171,2 | 160,3 | 150,6 | 142,0 | 134,4 |
| Thousands of seeds per hectare | | | | | | | | | | | | | | | | | | | | |
| The quantities indicated are given by way of illustration only. They equate to 64.4 revolutions of the wheel shaft per 100 metres of travel. | | | | | | | | | | | | | | | | | | | | |



| Metering output table - Disc 80 Holes - | | | | | | | | | | | | | | | | | | | | |
|---|------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| No. holes: 80 | 20-SPEED-GEARBOX | | | | | | | | | | | | | | | | | | | |
| Gearbox position | A1 | A2 | A3 | A4 | B1 | B2 | B3 | B4 | C1 | C2 | C3 | C4 | D1 | D2 | D3 | D4 | E1 | E2 | E3 | E4 |
| Seed spacing (mm) | 27 | 29 | 30 | 32 | 34 | 36 | 38 | 41 | 43 | 45 | 48 | 51 | 54 | 57 | 61 | 64 | 68 | 73 | 77 | 81 |
| No. Seeds / m | 37,0 | 34,5 | 33,3 | 31,3 | 29,4 | 27,8 | 26,3 | 24,4 | 23,3 | 22,2 | 20,8 | 19,6 | 18,5 | 17,5 | 16,4 | 15,6 | 14,7 | 13,7 | 13,0 | 12,3 |
| Spacing in cm = 40 | 925,9 | 862,1 | 833,3 | 781,3 | 735,3 | 694,4 | 657,9 | 609,8 | 581,4 | 555,6 | 520,8 | 490,2 | 463,0 | 438,6 | 409,8 | 390,6 | 367,6 | 342,5 | 324,7 | 308,6 |
| Spacing in cm = 45 | 823,0 | 766,3 | 740,7 | 694,4 | 653,6 | 617,3 | 584,8 | 542,0 | 516,8 | 493,8 | 463,0 | 435,7 | 411,5 | 389,9 | 364,3 | 347,2 | 326,8 | 304,4 | 288,6 | 274,3 |
| Spacing in cm = 50 | 740,7 | 689,7 | 666,7 | 625,0 | 588,2 | 555,6 | 526,3 | 487,8 | 465,1 | 444,4 | 416,7 | 392,2 | 370,4 | 350,9 | 327,9 | 312,5 | 294,1 | 274,0 | 259,7 | 246,9 |
| Spacing in cm = 55 | 673,4 | 627,0 | 606,1 | 568,2 | 534,8 | 505,1 | 478,5 | 443,5 | 422,8 | 404,0 | 378,8 | 356,5 | 336,7 | 319,0 | 298,1 | 284,1 | 267,4 | 249,1 | 236,1 | 224,5 |
| Spacing in cm = 60 | 617,3 | 574,7 | 555,6 | 520,8 | 490,2 | 463,0 | 438,6 | 406,5 | 387,6 | 370,4 | 347,2 | 326,8 | 308,6 | 292,4 | 273,2 | 260,4 | 245,1 | 228,3 | 216,5 | 205,8 |
| Spacing in cm = 65 | 569,8 | 530,5 | 512,8 | 480,8 | 452,5 | 427,4 | 404,9 | 375,2 | 357,8 | 341,9 | 320,5 | 301,7 | 284,9 | 269,9 | 252,2 | 240,4 | 226,2 | 210,7 | 199,8 | 189,9 |
| Spacing in cm = 70 | 529,1 | 492,6 | 476,2 | 446,4 | 420,2 | 396,8 | 375,9 | 348,4 | 332,2 | 317,5 | 297,6 | 280,1 | 264,6 | 250,6 | 234,2 | 223,2 | 210,1 | 195,7 | 185,5 | 176,4 |
| Spacing in cm = 75 | 493,8 | 459,8 | 444,4 | 416,7 | 392,2 | 370,4 | 350,9 | 325,2 | 310,1 | 296,3 | 277,8 | 261,4 | 246,9 | 233,9 | 218,6 | 208,3 | 196,1 | 182,6 | 173,2 | 164,6 |
| Spacing in cm = 80 | 463,0 | 431,0 | 416,7 | 390,6 | 367,6 | 347,2 | 328,9 | 304,9 | 290,7 | 277,8 | 260,4 | 245,1 | 231,5 | 219,3 | 204,9 | 195,3 | 183,8 | 171,2 | 162,3 | 154,3 |
| Thousands of seeds per hectare | | | | | | | | | | | | | | | | | | | | |
| The quantities indicated are given by way of illustration only. They equate to 64.4 revolutions of the wheel shaft per 100 metres of travel. | | | | | | | | | | | | | | | | | | | | |

| Metering output table - Disc 100 Holes - | | | | | | | | | | | | | | | | | | | | |
|---|------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| No. holes: 100 | 20-SPEED-GEARBOX | | | | | | | | | | | | | | | | | | | |
| Gearbox position | A1 | A2 | A3 | A4 | B1 | B2 | B3 | B4 | C1 | C2 | C3 | C4 | D1 | D2 | D3 | D4 | E1 | E2 | E3 | E4 |
| Seed spacing (mm) | 22 | 23 | 24 | 26 | 27 | 29 | 31 | 33 | 34 | 36 | 38 | 41 | 43 | 46 | 49 | 51 | 55 | 58 | 62 | 65 |
| No. Seeds / m | 45,5 | 43,5 | 41,7 | 38,5 | 37,0 | 34,5 | 32,3 | 30,3 | 29,4 | 27,8 | 26,3 | 24,4 | 23,3 | 21,7 | 20,4 | 19,6 | 18,2 | 17,2 | 16,1 | 15,4 |
| Spacing in cm = 40 | ##### | ##### | ##### | 961,5 | 925,9 | 862,1 | 806,5 | 757,6 | 735,3 | 694,4 | 657,9 | 609,8 | 581,4 | 543,5 | 510,2 | 490,2 | 454,5 | 431,0 | 403,2 | 384,6 |
| Spacing in cm = 45 | ##### | 966,2 | 925,9 | 854,7 | 823,0 | 766,3 | 716,8 | 673,4 | 653,6 | 617,3 | 584,8 | 542,0 | 516,8 | 483,1 | 453,5 | 435,7 | 404,0 | 383,1 | 358,4 | 341,9 |
| Spacing in cm = 50 | 909,1 | 869,6 | 833,3 | 769,2 | 740,7 | 689,7 | 645,2 | 606,1 | 588,2 | 555,6 | 526,3 | 487,8 | 465,1 | 434,8 | 408,2 | 392,2 | 363,6 | 344,8 | 322,6 | 307,7 |
| Spacing in cm = 55 | 826,4 | 790,5 | 757,6 | 699,3 | 673,4 | 627,0 | 586,5 | 551,0 | 534,8 | 505,1 | 478,5 | 443,5 | 422,8 | 395,3 | 371,1 | 356,5 | 330,6 | 313,5 | 293,3 | 279,7 |
| Spacing in cm = 60 | 757,6 | 724,6 | 694,4 | 641,0 | 617,3 | 574,7 | 537,6 | 505,1 | 490,2 | 463,0 | 438,6 | 406,5 | 387,6 | 362,3 | 340,1 | 326,8 | 303,0 | 287,4 | 268,8 | 256,4 |
| Spacing in cm = 65 | 699,3 | 668,9 | 641,0 | 591,7 | 569,8 | 530,5 | 496,3 | 466,2 | 452,5 | 427,4 | 404,9 | 375,2 | 357,8 | 334,4 | 314,0 | 301,7 | 279,7 | 265,3 | 248,1 | 236,7 |
| Spacing in cm = 70 | 649,4 | 621,1 | 595,2 | 549,5 | 529,1 | 492,6 | 460,8 | 432,9 | 420,2 | 396,8 | 375,9 | 348,4 | 332,2 | 310,6 | 291,5 | 280,1 | 259,7 | 246,3 | 230,4 | 219,8 |
| Spacing in cm = 75 | 606,1 | 579,7 | 555,6 | 512,8 | 493,8 | 459,8 | 430,1 | 404,0 | 392,2 | 370,4 | 350,9 | 325,2 | 310,1 | 289,9 | 272,1 | 261,4 | 242,4 | 229,9 | 215,1 | 205,1 |
| Spacing in cm = 80 | 568,2 | 543,5 | 520,8 | 480,8 | 463,0 | 431,0 | 403,2 | 378,8 | 367,6 | 347,2 | 328,9 | 304,9 | 290,7 | 271,7 | 255,1 | 245,1 | 227,3 | 215,5 | 201,6 | 192,3 |
| Thousands of seeds per hectare | | | | | | | | | | | | | | | | | | | | |
| The quantities indicated are given by way of illustration only. They equate to 64.4 revolutions of the wheel shaft per 100 metres of travel. | | | | | | | | | | | | | | | | | | | | |

How to read the calibration charts

Use the chart corresponding to the selected disk type (According to the number of holes).

The chart enables determining the position of the gearbox gearwheels according to the spacing between the seed drill rows and the number of plants required per hectare.

Example:

For Maize seeds: 27 hole disk.

Seed row spacing: 75 cm (2'5").

Required population: 83000 plants/hectare.

| Metering output table - Disc 27 Holes - | | | | | | | | | | | | | | | | | | | | |
|---|------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| No. holes: 27 | 20-SPEED-GEARBOX | | | | | | | | | | | | | | | | | | | |
| Gearbox position | A1 | A2 | A3 | A4 | B1 | B2 | B3 | B4 | C1 | C2 | C3 | C4 | D1 | D2 | D3 | D4 | E1 | E2 | E3 | E4 |
| Seed spacing (mm) | 80 | 85 | 90 | 95 | 101 | 108 | 114 | 120 | 127 | 135 | 143 | 150 | 160 | 175 | 180 | 190 | 203 | 215 | 228 | 241 |
| No. Seeds / m | 12,5 | 11,8 | 11,1 | 10,5 | 9,9 | 9,3 | 8,8 | 8,3 | 7,9 | 7,4 | 7,0 | 6,7 | 6,3 | 5,9 | 5,6 | 5,3 | 4,9 | 4,7 | 4,4 | 4,1 |
| Spacing in cm = 40 | 312,5 | 294,1 | 277,8 | 263,2 | 247,5 | 231,5 | 219,3 | 208,3 | 196,9 | 185,2 | 174,8 | 166,7 | 156,3 | 147,1 | 138,9 | 131,6 | 123,2 | 116,3 | 109,6 | 103,7 |
| Spacing in cm = 45 | 277,8 | 261,4 | 246,9 | 233,9 | 220,0 | 205,8 | 194,9 | 185,2 | 175,0 | 164,6 | 155,4 | 148,1 | 138,9 | 130,7 | 123,5 | 117,0 | 109,5 | 103,4 | 97,5 | 92,2 |
| Spacing in cm = 50 | 250,0 | 235,3 | 222,2 | 210,5 | 198,0 | 185,2 | 175,4 | 166,7 | 157,5 | 148,1 | 139,9 | 133,3 | 125,0 | 117,6 | 111,1 | 105,3 | 98,5 | 93,0 | 87,7 | 83,0 |
| Spacing in cm = 55 | 227,3 | 213,9 | 202,0 | 191,4 | 180,0 | 168,4 | 159,5 | 151,5 | 143,2 | 134,7 | 127,1 | 121,2 | 113,6 | 107,0 | 101,0 | 95,7 | 89,6 | 84,6 | 79,7 | 75,4 |
| Spacing in cm = 60 | 208,3 | 196,1 | 185,2 | 175,4 | 165,0 | 154,3 | 146,2 | 138,9 | 131,2 | 123,5 | 116,6 | 111,1 | 104,2 | 98,0 | 92,6 | 87,7 | 82,1 | 77,5 | 73,1 | 69,2 |
| Spacing in cm = 65 | 192,3 | 181,0 | 170,9 | 161,9 | 152,3 | 142,5 | 135,0 | 128,2 | 121,1 | 114,0 | 107,6 | 102,6 | 96,2 | 90,5 | 85,5 | 81,0 | 75,8 | 71,6 | 67,5 | 63,8 |
| Spacing in cm = 70 | 178,6 | 168,1 | 158,7 | 150,4 | 141,4 | 132,3 | 125,3 | 119,0 | 112,5 | 105,8 | 99,9 | 95,2 | 89,3 | 84,0 | 79,4 | 75,2 | 70,4 | 66,4 | 62,7 | 59,3 |
| Spacing in cm = 75 | 166,7 | 156,9 | 148,1 | 140,4 | 132,0 | 123,5 | 117,0 | 111,1 | 105,0 | 98,8 | 93,2 | 88,9 | 83,3 | 78,4 | 74,1 | 70,2 | 65,7 | 62,0 | 58,5 | 55,3 |
| Spacing in cm = 80 | 156,3 | 147,1 | 138,9 | 131,6 | 123,8 | 115,7 | 109,6 | 104,2 | 98,4 | 92,6 | 87,4 | 83,3 | 78,1 | 73,5 | 69,4 | 65,8 | 61,6 | 58,1 | 54,8 | 51,9 |
| Thousands of seeds per hectare | | | | | | | | | | | | | | | | | | | | |
| The quantities indicated are given by way of illustration only. They equate to 64.4 revolutions of the wheel shaft per 100 metres of travel. | | | | | | | | | | | | | | | | | | | | |

To obtain a number of plants (1) close to the required number with a spacing between rows (2) of 75 cm (2'5"), position gearbox gearwheels on ratio D1 (3).

The chart also indicates the spacing between seeds (4) and the theoretical number of seeds (5) over 1 m (3'3").

It is possible to determine the gearbox ration as from this data.

If in between 2 values in the adjustment chart, select the setting that gives the less plants per hectare.

When the chart does not correspond to the disk used (number of holes), use "1 hole disk" chart:

| Metering output table - Disc 1 Holes - | | | | | | | | | | | | | | | | | | | | |
|---|------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| No. holes: 1 | 20-SPEED-GEARBOX | | | | | | | | | | | | | | | | | | | |
| Gearbox position | A1 | A2 | A3 | A4 | B1 | B2 | B3 | B4 | C1 | C2 | C3 | C4 | D1 | D2 | D3 | D4 | E1 | E2 | E3 | E4 |
| Seed spacing (mm) | 2161 | 2296 | 2431 | 2566 | 2737 | 2908 | 3079 | 3250 | 3421 | 3635 | 3849 | 4063 | 4322 | 4592 | 4862 | 5132 | 5474 | 5816 | 6159 | 6501 |
| No. Seeds / m | 0,463 | 0,436 | 0,411 | 0,390 | 0,365 | 0,344 | 0,325 | 0,308 | 0,292 | 0,275 | 0,260 | 0,246 | 0,231 | 0,218 | 0,206 | 0,195 | 0,183 | 0,172 | 0,162 | 0,154 |
| Spacing in cm = 55 | 8,41 | 7,92 | 7,48 | 7,09 | 6,64 | 6,25 | 5,91 | 5,59 | 5,31 | 5,00 | 4,72 | 4,47 | 4,21 | 3,96 | 3,74 | 3,54 | 3,32 | 3,13 | 2,95 | 2,80 |
| Spacing in cm = 60 | 7,71 | 7,26 | 6,86 | 6,50 | 6,09 | 5,73 | 5,41 | 5,13 | 4,87 | 4,59 | 4,33 | 4,10 | 3,86 | 3,63 | 3,43 | 3,25 | 3,04 | 2,87 | 2,71 | 2,56 |
| Spacing in cm = 65 | 7,12 | 6,70 | 6,33 | 6,00 | 5,62 | 5,29 | 5,00 | 4,73 | 4,50 | 4,23 | 4,00 | 3,79 | 3,56 | 3,35 | 3,16 | 3,00 | 2,81 | 2,65 | 2,50 | 2,37 |
| Spacing in cm = 70 | 6,61 | 6,22 | 5,88 | 5,57 | 5,22 | 4,91 | 4,64 | 4,40 | 4,18 | 3,93 | 3,71 | 3,52 | 3,31 | 3,11 | 2,94 | 2,78 | 2,61 | 2,46 | 2,32 | 2,20 |
| Spacing in cm = 75 | 6,17 | 5,81 | 5,48 | 5,20 | 4,87 | 4,59 | 4,33 | 4,10 | 3,90 | 3,67 | 3,46 | 3,28 | 3,08 | 2,90 | 2,74 | 2,60 | 2,44 | 2,29 | 2,16 | 2,05 |
| Spacing in cm = 80 | 5,78 | 5,44 | 5,14 | 4,87 | 4,57 | 4,30 | 4,06 | 3,85 | 3,65 | 3,44 | 3,25 | 3,08 | 2,89 | 2,72 | 2,57 | 2,44 | 2,28 | 2,15 | 2,03 | 1,92 |
| Thousands of seeds per hectare | | | | | | | | | | | | | | | | | | | | |
| The quantities indicated are given by way of illustration only. They equate to 64.4 revolutions of the wheel shaft per 100 metres of travel. | | | | | | | | | | | | | | | | | | | | |

The 1 hole disk chart enables determining the following values:

- Number of plants per hectare.
- Spacing between seeds.
- Number of seeds per meter.

Example:

Seed row spacing: 75 cm (2'5").

24 hole disk.

Selected speed ratio: A1

Number of plants per hectare:

P = Number of plants per hectare.

N = Number of holes on the disk used.

N1 = Number of seeds with 1 hole disk.

$$P = (N \times N1) \times 1000$$

Example:

$$P = (24 \times 6.17) \times 1000 = 148080 \text{ seeds/ha}$$

Spacing between seeds:

E = Spacing between seeds.

E1 = Spacing between seeds with 1 hole disk.

N = Number of holes on the disk used.

$$E = E1 / N$$

Example:

$$E = 2161 / 24 = 90 \text{ mm (3.5")}$$

Number of seeds per meter:

N1 = Number of seeds per meter.

N2 = Number of seeds per meter with 1 hole disk.

N = Number of holes on the disk used.




$$N1 = N2 \times N$$

Example:

$$N1 = 0.463 \times 24 = 11.1 \text{ Seeds per meter.}$$

Adjustment of the gearbox



Combination chart

| | | | | | | | | | | | | | | | | | | | | |
|--|---|----|----|----|----|----|----|----|----|----|--|----|----|----|----|----|----|----|----|----|
| | A1 | A2 | A3 | A4 | B1 | B2 | B3 | B4 | C1 | C2 | C3 | C4 | D1 | D2 | D3 | D4 | E1 | E2 | E3 | E4 |
| |  | | | | | | | | | | | | | | | | | | | |
| |  | | | | | | | | | |  | | | | | | | | | |

Adjust gearbox gearwheel and chain position according to the ratio recommended in the calibration chart.

Example:

Ratio to adjust: D1.

| | A1 | A2 | A3 | A4 | B1 | B2 | B3 | B4 | C1 | C2 | C3 | C4 | D1 |
|--|----|----|----|----|----|----|----|----|----|----|----|----|----|
|   | | | | | | | | | | | | | |


- Position chain on upper level gearwheel **D**.
- Position chain on lower level gearwheel **1**.




Variation of 6 % between each ratio.

Adjustment:


- Remove lynch pin (1).
- Open gearbox (2).



- Lower lever (1) until chain tension is loosened.
- Push handle (2) to lock lever (1) in low position.
- Position lever (3) in notch (4) to enable moving the upper level gearwheels sideways.
- Position chain (5) on the recommended gearwheels.




- Position lever (3) in notch (4) to lock upper level gearwheels.



Check that chain and gearwheels are in line.

- Maintain lever (1) downwards and pull handle (2) to unlock the lever.
- Lift lever (1) to retension the chain.

- Close gearbox (1).
- Insert and lock lynch pin (2).



Checking the number of plants per hectare

2 methods are possible:

- Checking by counting over a set distance.
- Checking the spacing between seeds.

Checking by counting over a set distance

| Seed row spacing | Counting length |
|------------------|------------------|
| 30 cm (1.18") | 33.33 m (109'4") |
| 35 cm (1.38") | 28.57 m (93'9") |
| 40 cm (1.57") | 25.00 m (82') |
| 45 cm (1.77") | 22.22 m (72'11") |
| 50 cm (1.97") | 20.00 m (65'7") |
| 55 cm (2.16") | 18.18 m (59'8") |
| 60 cm (2.36") | 16.66 m (54'8") |
| 65 cm (2.56") | 15.38 m (50'5") |
| 70 cm (2.75") | 14.28 m (46'10") |
| 75 cm (2.95") | 13.30 m (43'8") |
| 80 cm (3.15") | 12.50 m (41') |

Example:

Seed row spacing: 75 cm (2'5").

The seed count must be made over a length of 13.30 m (43'8").

The count gives 83 seeds over a length of 13.30 m (43'8").

Multiply the number of seeds per 1000:

$$83 \times 1000 = 83000 \text{ seeds/ha.}$$



The KMS412 control box enables knowing instantaneously the average number of plants sown per hectare.



If the distance between the real population and the population target exceeds 4 %, the difference can be reduced by modifying the gearbox ratio.

Checking the spacing between seeds

- Uncover 11 seeds on the seeding line.
- Measure distance D between the first and eleventh seed.
- Divide the measured distance by 10 to obtain the spacing between two seeds.



Example:

For Maize seeds: 27 hole disk.

Seed row spacing: 75 cm (2'5").

Required population: 83000 plants/hectare.

Distance (D) measured between the first and eleventh seed: 1600 mm (5'3").

Seed spacing:

$$1600 / 10 = 160 \text{ mm (6.3")}$$

Compare the average distance measured with value (1) indicated in the chart. Modify settings if necessary.

Metering output table - Disc 27 Holes -

| No. holes: 27 | 20-SPEED-GEARBOX | | | | | | | | | | | | | | | | | | | |
|---|------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| | A1 | A2 | A3 | A4 | B1 | B2 | B3 | B4 | C1 | C2 | C3 | C4 | D1 | D2 | D3 | D4 | E1 | E2 | E3 | E4 |
| Seed spacing (mm) | 80 | 85 | 90 | 95 | 101 | 108 | 114 | 120 | 127 | 135 | 143 | 150 | 160 | 170 | 180 | 190 | 203 | 215 | 228 | 241 |
| No. Seeds / m | 12,5 | 11,8 | 11,1 | 10,5 | 9,9 | 9,3 | 8,8 | 8,3 | 7,9 | 7,4 | 7,0 | 6,7 | 6,3 | 5,9 | 5,6 | 5,3 | 4,9 | 4,7 | 4,4 | 4,1 |
| Spacing in cm = 40 | 312,5 | 294,1 | 277,8 | 263,2 | 247,5 | 231,5 | 219,3 | 208,3 | 196,9 | 185,2 | 174,8 | 166,7 | 156,3 | 147,1 | 138,9 | 131,6 | 123,2 | 116,3 | 109,6 | 103,7 |
| Spacing in cm = 45 | 277,8 | 261,4 | 246,9 | 233,9 | 220,0 | 205,8 | 194,9 | 185,2 | 175,0 | 164,6 | 155,4 | 148,1 | 138,9 | 130,7 | 123,5 | 117,0 | 109,5 | 103,4 | 97,5 | 92,2 |
| Spacing in cm = 50 | 250,0 | 235,3 | 222,2 | 210,5 | 198,0 | 185,2 | 175,4 | 166,7 | 157,5 | 148,1 | 139,9 | 133,3 | 125,0 | 117,6 | 111,1 | 105,3 | 98,5 | 93,0 | 87,7 | 83,0 |
| Spacing in cm = 55 | 227,3 | 213,9 | 202,0 | 191,4 | 180,0 | 168,4 | 159,5 | 151,5 | 143,2 | 134,7 | 127,1 | 121,2 | 113,6 | 107,0 | 101,0 | 95,7 | 89,6 | 84,6 | 79,7 | 75,4 |
| Spacing in cm = 60 | 208,3 | 196,1 | 185,2 | 175,4 | 165,0 | 154,3 | 146,2 | 138,9 | 131,2 | 123,5 | 116,6 | 111,1 | 104,2 | 98,0 | 92,6 | 87,7 | 82,1 | 77,5 | 73,1 | 69,2 |
| Spacing in cm = 65 | 192,3 | 181,0 | 170,9 | 161,9 | 152,3 | 142,5 | 135,0 | 128,2 | 121,1 | 114,0 | 107,6 | 102,6 | 96,2 | 90,5 | 85,5 | 81,0 | 75,8 | 71,6 | 67,5 | 63,8 |
| Spacing in cm = 70 | 178,6 | 168,1 | 158,7 | 150,4 | 141,4 | 132,3 | 125,3 | 119,0 | 112,5 | 105,8 | 99,9 | 95,2 | 89,3 | 84,0 | 79,4 | 75,2 | 70,4 | 66,4 | 62,7 | 59,3 |
| Spacing in cm = 75 | 166,7 | 156,9 | 148,1 | 140,4 | 132,0 | 123,5 | 117,0 | 111,1 | 105,0 | 98,8 | 93,2 | 88,9 | 83,3 | 78,4 | 74,1 | 70,2 | 65,7 | 62,0 | 58,5 | 55,3 |
| Spacing in cm = 80 | 156,3 | 147,1 | 138,9 | 131,6 | 123,8 | 115,7 | 109,6 | 104,2 | 98,4 | 92,6 | 87,4 | 83,3 | 78,1 | 73,5 | 69,4 | 65,8 | 61,6 | 58,1 | 54,8 | 51,9 |
| Thousands of seeds per hectare | | | | | | | | | | | | | | | | | | | | |
| The quantities indicated are given by way of illustration only. They equate to 64.4 revolutions of the wheel shaft per 100 metres of travel. | | | | | | | | | | | | | | | | | | | | |



The KMS412 control box enables knowing instantaneously the average distance between seeds.

■ Adjusting the selector



The selector adjustment must be made after having installed the disks best adapted to the seed variety to sow.

The selector enables preventing misses and doubles along the seeding line.

Pre-setting:


- Position selector (1) on the teeth bottom on the notched quadrant (2).



Plate (2) is graduated from 0 to 30.

- Pull knob (3) to place selector (1) on the recommended position.

| | Recommended adjustment range | Position of 1st running test |
|-----------|------------------------------|------------------------------|
| Maize | 15 to 25 | 21 |
| Sunflower | 10 to 16 | 14 |
| Beet | 18 to 25 | 21 |



Settings are only indicated for your information.


The seeding unit setting must be adjusted according to the sowing conditions (Work speed and soil nature).




It is indispensable to refine the adjustments when starting the machine and every time the seed variety or type changes.

Stationary checking:

- Fill hoppers with seeds.
- Lift the seed drill.
- Engage the tractor pto and increase speed gradually until reaching the recommended blower speed.
- Disengage the other seeding units by hand (Refer to "Manual seeding unit disengagement" chapter).
- Lift the observation flap (1).



- Turn the seed drill wheel through several revolutions by hand to monitor seed take-up by the disk. If doubles or misses are noticed during the seed take-up control, modify the selector position.




If you notice seed doubles on the disk, move selector (1) of one or several graduations in direction 0.



If you notice seed misses on the disk, move selector (1) of one or several graduations in direction 30.

- Repeat procedure until obtaining the right setting.
- Disengage tractor PTO.



After checking:

- Lower control hatch and engage all other seeding units.
- Carry out same setting for each seeding unit.




The marking enables identical setting of each seeding unit.


Checking during sowing:

The seed take-up control can be made while following the seed drill during a sowing operation.

- Lift the observation flap (1).



- If doubles or misses are noticed during the seed take-up control, modify the selector position.
- Push knob (1) to place selector (2) in the required position.



If you notice seed doubles on the disk, move selector (1) of one or several graduations in direction 0.


If you notice seed misses on the disk, move selector (1) of one or several graduations in direction 30.

- Repeat procedure until obtaining the right setting.

After checking:

- Lower control hatch.
- Carry out same setting for each seeding unit.


The marking enables identical setting of each seeding unit.




■ Adjusting the seed flow

When sowing fluid seeds (sunflower, rapeseed...) on slopes or stony grounds, there is a risk of overpopulation due to overflow. The reduction spacer may have to be adjusted.


- Loosen the butterfly nut (1).



- Lift output reduction spacer lever (1) to reduce the seed supply to the disks.



- Lower output reduction spacer lever (1) to increase the seed supply to the disks.
- Tighten the wing nut.




- Repeat procedure on each seeding unit.

3. Machine use




Before carrying out any maintenance on the machine, disengage the power take-off, switch off the tractor engine, remove ignition key and wait until all moving parts have come to a complete stop and apply park brake




Only work in straight lines. Lift the machine to turn.

■ Manual unit disengagement

To disengage a unit by hand, pull knob (1).




To engage a unit by hand, push and turn slightly knob (1) to facilitate the unit engagement.



Seeding unit safety

When an incident occurs on one of the sowing units, the safety bolt (2) shears causing the metering unit to stop.

- Disengage the unit.
- Use a punch to remove the remaining shear bolt part.
- Replace the components.



- ✓ Nuts (1) **Part no. 80200640.**
- Safety bolt (2) **Part no. N03273A0.**

- Torque: 10 daN m (74 lbf ft).

■ Seeding unit high and low position



Never lift a seeding unit using the hopper assembly in order not to damage its link with the distribution.




For safety reasons forbidding to handle loads exceeding 25 daN (56.20 lbf) by hand, the seeding unit must be adjusted with the machine coupled to the tractor and in raised position.




Setting the seeding unit in high position

✓ *The high position setting of the seeding units enables sowing on 1 row out of 2.*


- Disengage the unit using knob (1).




- Position spring (1) behind part (2).
- Lock (3) comes into contact with stop (4).



- Raise machine using tractor lift.
- Position a wedge (1) approximately 15 cm (5.90") thick underneath the seeding unit.




- Lower the machine using the tractor lift linkage.
- Lock (1) automatically positions itself underneath stop (2).




Setting the seeding unit in low position


- Position spring (1) inside hole (2).




- Raise machine using tractor lift.
- Position a wedge (1) approximately 15 cm (5.90") thick underneath the seeding unit.



- Using the tractor lift linkage, lower machine to release lock (1).



- Engage the seeding unit using knob (1).



■ Hoppers

Hopper filling




Lower the machine on the ground.

- Open the hopper cover (1).

Before filling:



- Check that there are no foreign bodies in the hoppers.
- Check that distribution disks are in the proper position.
- Check that distribution emptying hatches are closed.




Each hopper has a capacity of 52 L (14 US gal).

- Fill sowing unit hoppers in order to have approximately equal seed quantity in all hoppers.
- After filling, close hopper cover.
- Repeat procedure for each hopper.

Emptying the hoppers

When seed variety is changed, or at the end of the season, it is important to fully empty the hoppers.

- Position a container close to the emptying hatch.
- Position funnel (2) underneath emptying hatch (1).
- Pull emptying hatch handle (1).
- Repeat procedure for each hopper.



■ Checking

Seeding depth

It is recommended to check sowing depth every time you refill the different hoppers.

Sowing depth must be matched to the type of seed, the soil and conditions in the seed bed.

A insufficient or excessive depth can harm the emergence quality.

On plots with variable quality soil, the depth setting must be checked and adjusted so as to obtain the correct sowing depth across the whole area of the field.

Distribution

During filling, rotate drive wheel by hand to check the good seed distribution underneath each sowing unit.

Seed application rate


Check and compare the seed quantity used in relation to the adjustments and the area sown.

For each filling, compare residual seed quantity in each hopper. A variation of the residual seed volume in the hopper indicates there is a problem in the sowing unit setting or that the sowing unit is clogged. Search source of malfunction and remedy the problem prior to resuming sowing operation.

Suction adjustment

- Loosen nut (1).
- Position stop in the hole:
 - Minimum suction when stop is placed in the hole bottom position (Position (a)).

Maximum suction when the stop is placed in the hole top position (Position (b)).



Suction must be comprised between 50 and 65 mbar (or cm water column).




- A lower suction value can cause misses on the seeding line.
- A higher suction value can cause doubles on the seeding line and premature disk wear.

The measure must be made with disks fitted, seeds engaged on the disks.



*For precise measure of the suction value, a vacuumeter can be installed on the machine.
Kit no. 1677223.*



- Tighten nut (1).



Check that the flap is free to rotate and that no element interferes during its movement.

If the flap is not free to move upwards during seeding, there will be no suction at the distribution disk level.

■ Groundspeed



Adapt the forward speed to the working conditions.

For optimum precision and seeding evenness, it is recommended to travel at a speed comprised between 5 and 7 km/h (3.1 - 4.3 mph).




A variation in the ground speed of 2 km/h (1.2 mph) is equivalent to a loss of accuracy of around 10 %.




Groundspeed must be adapted to the encountered working conditions (Soil nature and presence or absence of plant residues).

OPTIONAL EQUIPMENT

■ Assembly combinations possible for front equipments





- 1 : 115 x 400 depth control wheels
- 2 : 65 x 400 depth control wheels
- 3 : Clod clearer with disk coulter for 65 x 400 gauge wheels



- 4 : Clod clearer with disk coulter for 115 x 400 gauge wheels
- 5 : Spring assisted clod clearer
- 6 : Star shaped trash remover
- 7 : Opener disc solo
- 8 : Star-shaped trash remover for furrow opening disk
- 9 : Furrow opening disk with star-shaped trash remover

■ Assembly combinations possible for rear equipments





1. Clod clearer

Kit no. 1676801

Clod clearer with disk coulters for gauge wheels (a).

Kit no. 1676802

Clod clearer with disk coulters for gauge wheels (b).

The clod clearer is used to clear clods and small stones to prepare for the passage of the lateral gauge wheels and create a furrow in humid soil after having pushed away the dry and clody part.

■ Adjustments

Height adjustment

- Loosen screws (1).
- Set the required height:
 - Clod clearer (2) must be set high enough to prevent seeding unit from engaging in the soil.

We recommend adjusting the clod clearer at approximately 20 mm (0.78") from the ground.




- The independent knife coulters (3) enables preparing the passage for the coulters and facilitates its engagement in the soil.

Respect a distance *L* of 2 to 6 cm (0.7" - 2") between the clod clearer (2) base and the independent coulters (3) base.

- Tighten screws (1).

Lateral adjustment


- Unscrew the 4 bolts (1).
- Centre clod clearer (2) with regards to the seeding line.
- Tighten the 4 bolts (1).



Adjust all seeding units to the same settings.

Machine use


In very wet, sticky or stony conditions, the clod clearer and coulter can be folded upwards or the equipment can be removed from the seed drill.



2. Spring assisted clod clearer

Kit no. 1676803

The clod clearer is used to clear clods and small stones to prepare for the passage of the lateral gauge wheels and create a furrow in humid soil after having pushed away the dry and clody part.



Adjustments

Height adjustment

- Loosen screws (1).
- Set the required height:
 - Clod clearer (2) must be set high enough to prevent seeding unit from engaging in the soil.




We recommend adjusting the clod clearer at approximately 20 mm (0.78") from the ground.

- The independent knife coulter (3) enables preparing the passage for the coulter and facilitates its engagement in the soil.




Respect a distance L of 2 to 6 cm (0.7" - 2") between the clod clearer (2) base and the independent coulter (3) base.

- Tighten screws (1).



Lateral adjustment


- Unscrew the 4 bolts (1).
- Centre clod clearer (2) with regards to the seeding line.
- Tighten the 4 bolts (1).



Adjust all seeding units to the same settings.

Machine use


In very wet, sticky or stony conditions, the clod clearer and coulter can be folded upwards or the equipment can be removed from the seed drill.



3. Star shaped trash remover

Kit no. 1676783

The star-shaped trash remover is used to push aside plant residues in order to prepare for the passage of the seeding unit.




■ Adjustments


Height adjustment

- Remove lynch pin (1).
- Adjust working height using pin (2).

The working height can be adjusted to 10 different positions.

 The adjustment range is of 82.5 mm (3.25").

- Insert and lock lynch pin (1).




Working width adjustment

The working width can be adjusted to 3 different positions.




The working width must be adjusted according to the type of residues to push aside.

- Remove nut (1).



- Place star-shaped disks (2) in the required position:
 - By moving the star-shaped disks (2) frontwards, organic residues are more easily separated.
 - By moving the star-shaped disks (2) rearwards, the clearing width is increased prior to the passage of the gauge wheels.



- Reinstall nut (1).




The pointed part (1) of the teeth must always be pointing frontwards in the lower part of the star-shaped disks.

Repeat procedure on the other disk.



Adjust all seeding units to the same settings.



4. Furrow opening disk

Kit no. 1676775

Opener disc solo.

The circular knife coulter facilitates penetration of the furrow opening disks in plant residues.


The star-shaped trash remover is used to push aside plant residues in order to prepare for the passage of the seeding unit.

■ Adjustment



Furrow opening disk

Height adjustment

- Unscrew the 2 nuts (1) (1 on each side).
- Loosen the 2 screws (2) (1 on each side).
- Position disk holder (3) in one of the holes to increase or reduce the working depth.


 The adjustment range is of 25 mm (0.98").

- Tighten the 2 screws (2) (1 on each side).
- Tighten the 2 nuts (1) (1 on each side).



■ **Machine use**

Only one spring (1) can be positioned in the centre of the parallelogram. The second spring (2) can be fitted on the right side of the parallelogram.




This equipment does not allow the seeding unit to be locked in the raised position.

5. Covering scraper

Kit no. 1676761

The covering scrapers transfers soil in the sowing line for easier furrow closing.




A 82 mm (3.2") spacer is delivered with this equipment.

■ **Adjustment**

Lateral adjustment

- Unscrew the 4 bolts (1).
- Centre scrapers (2) with regards to the furrow.
- Tighten the 4 bolts (1).



Check setting over the first few metres sown.


■ **Machine use**

The work fulfilled by the covering scrapers can vary according to the sowing conditions and depth.

Check that the ground pressure applied with the springs, does not cause too much soil to be transferred in the furrow or that the scraper action does not damage the sowing operation.




If necessary, remove springs (1) to reduce the scraper ground pressure.



6. Composite intermediate axial press wheel

Kit no. 1676762

The purpose of the intermediate centerline roller is to tamp down the seed at the bottom of the furrow in order to encourage germination by optimising its contact with its moist environment.



■ **Adjustments**

Lateral adjustment

- Unscrew the 4 bolts (1).
- Centre wheel (2) with regards to the furrow.




Incorrect wheel positioning could cause its incorrect functioning and alter the sowing precision.

- Tighten the 4 bolts (1).




Check setting over the first few metres sown.



Deflector adjustment

The deflector prevents stones from getting jammed.


- Loosen screws (1).
- Position deflector (2) as close as possible to the wheel, without touching it. Wheel (3) must be free to rotate by hand. Rotate wheel by hand and check that the wheel is free to rotate at least once.
- Torque bolts to (1).



Machine use


The wheel must be free to rotate and the return spring must allow a downward vertical effort of 3.5 to 6 daN.

The wheel must instantaneously resume its lower position and must not be blocked during its down travel.



In very wet, sticky or stony conditions, the wheel can be folded upwards to prevent damage on the wheel and ensure seeding precision.


- Push screw (1).
- Raise wheel (2).
- Pull screw (1).



7. Stainless steel intermediate axial press wheel

Kit no. 1676766

The purpose of the intermediate centerline roller is to tamp down the seed at the bottom of the furrow in order to encourage germination by optimising its contact with its moist environment.



■ Adjustments

Lateral adjustment

- Unscrew the 4 bolts (1).
- Centre wheel (2) with regards to the furrow.




Incorrect wheel positioning could cause its incorrect functioning and alter the sowing precision.

- Tighten the 4 bolts (1).



Check setting over the first few metres sown.



Adjusting the scraper's position

The scraper's position must be adjusted according to the sowing conditions:


- Position (a): Slightly wet conditions.

Loosen nut (1) to reduce distance between scraper (2) and the wheel.

- Position (b): Dry conditions.

Tighten nut (1) to increase distance between scraper (2) and the wheel.

Repeat procedure on each seeding unit.




Adjusting the intermediate axial wheel scrapers

The scraper removes soil build-up around the wheel.

Adjusting the plates:

- Loosen nut (1).
- Position plate (2) closest to the wheel, but without touching it. Rotate wheel once to check that it is not in contact.



In slightly wet conditions, reduce spacing between plate and wheel as much as possible to reduce wear.

- Tighten screws (1).


Repeat procedure on each seeding unit.

Machine use

In very wet, sticky or stony conditions, the wheel can be folded upwards to prevent damage on the wheel and ensure seeding precision.

- Remove R-clips (1).
- Mover levers (2) rearwards to raise the wheel.
- Insert split pins (1).


Repeat procedure on each seeding unit.



When the use of the wheel is no longer required or unadequate, it can be removed without removing the other equipments.

- Remove R-clips (1).
- Remove screws (2), nuts (4) and washers (3).
- Remove the 2 handles (5).
- Remove lynch pin (6).
- Remove screw (7) and pin (8).
- Remove wheel (9).


Repeat procedure on each seeding unit.



■ Maintenance

Greasing (Every 50 hours)

- The tamping wheel pivot pin.




Replacing the scraper plates

- Remove bolt (1) and nut (2).
- Remove plate (3).
- Turn plate over or replace it if necessary.

✓ *Scraper plate Part no. K3600550.*

- Install plate (3).
- Reinstall bolt (1) and nut (2).




8. Furrow closing disks

Kit no. 1676790

The closing disks transfers soil in the sowing line for easier furrow closing.

We recommend using the closing disks in the presence of debris or where the edges of the furrow are hard with little fine tilth.




A 45 mm (1.8") spacer is delivered with this equipment.

■ Adjustments

Lateral adjustment


- Unscrew the 4 bolts (1).
- Centre disks (2) in relation to the furrow.
- Tighten the 4 bolts (1).



Check setting over the first few metres sown.

Height adjustment

- Remove lynch pin (1).
- Remove pin (2).
- Insert pin (2) in one of bracket (3) holes to set the required working depth.
- Lock pin using lynch pin (1).
- Adjust all sowing units to the same setting.



Adjust all seeding units to the same settings.

9. Standard V-shaped roller

Kit no. 1677235:

Standard Rubber V roller 1" (a).

Kit no. 1677234:

Standard Rubber V roller 2" (b).


Kit no. 1677237:

Standard smooth steel V roller (c).

Kit no. 1677236:

Standard notched steel V roller (d).

The V-shaped roller enables closing and tamping the seeding line.




■ Adjustments

Adjusting the tamping pressure

Lever (1) enables adjusting the tamping pressure.


- Position lever (1) in one of the adjusting catches 5:
 - To reduce the tamping pressure in F, move adjustment lever (1) frontwards.
 - Mover adjustment lever (1) rearwards to increase tamping pressure in F.






Adjust all seeding units to the same settings.

Adjusting the spacing between the press wheels

- Remove nut (1).
- Remove the struts (2).
- Remove wheel (3).



- Place one or several spacers (1) on the inside to increase spacing between the press wheels.
- Place one or several spacers (1) on the outside to reduce spacing between the press wheels.



For standard 25 and 50 mm (1" - 2") rubber V rollers, spacer (1) must remain on the inside to prevent interferences with the press wheels.

- Reinstall nut (1).


Repeat procedure on the other press wheel.

Adjustment of the tamping wheel cleaners

The cleaners remove soil build up around the tamping wheels.

Lateral adjustment

- Loosen nut (1).
- Center cleaner (2) with regards to wheel (3).
- Tighten nut (1).
- Repeat procedure on the other cleaner.



Adjusting the scraper's position

The scraper's position must be adjusted according to the sowing conditions:


- Position (a): Slightly wet conditions.

Loosen nut (1) to reduce distance between scraper (2) and the wheel.

- Position (b): Dry conditions.

Tighten nut (1) to increase distance between scraper (2) and the wheel.

Repeat procedure on each seeding unit.




Adjusting the plates

- Loosen nut (1).
- Adjust plate (2) to bring it closer to the tamping wheel but without touching it. Rotate wheel once to check that it is not in contact.



In slightly wet conditions, reduce spacing between plate and wheel as much as possible to reduce wear.


- Tighten screws (1).
- Repeat procedure on each seeding unit.



■ Maintenance


Greasing (Every 50 hours)

- The tamping wheel pivot pin.



Replacing the scraper plates

- Remove nut (1).
- Remove screw (2) and washer (3).
- Turn plate over or replace it if necessary.



Scraper plate **Part no. K3600550.**

- Reinstall screw (2), nut (1) and washer (3).

10. HD V roller

Kit no. 1677241:

HD Rubber V roller 1" (a).

Kit no. 1677240:

HD Rubber V roller 2" (b).


Kit no. 1677239:

HD smooth steel V roller (c).

Kit no. 1677238:

HD notched steel V roller (d).

The V-shaped roller enables closing and tamping the seeding line.




■ Adjustments

Adjusting the tamping pressure

Lever (1) enables adjusting the tamping pressure.

- Position lever (1) in one of the adjusting catches 5:
 - To reduce the tamping pressure in F, move adjustment lever (1) frontwards.
 - Mover adjustment lever (1) rearwards to increase tamping pressure in F.




Adjust all seeding units to the same settings.

Adjusting the roller opening angle

Lever (2) allows adjusting the roller opening angle.

- Loosen knob (1).



- Move adjustment lever (2) frontwards to increase the roller opening angle.




In current conditions, the roller opening facilitates furrow closing and seed covering.

- Move adjustment lever (2) rearwards to reduce the roller opening angle.



In stony conditions, closing the rollers prevents stones from getting jammed.

- Tighten knob (1).




Adjust all seeding units to the same settings.

Adjusting the press wheel offset


To prevent stones from getting jammed between the press wheels, the right wheel must be slightly offset towards the front.

- Remove right press wheel (1).
- Position right press wheel (1) in hole (2).



Adjusting the spacing between the press wheels


- Remove nut (1).
- Remove the struts (2).
- Remove wheel (3).



- Place one or several spacers (1) on the inside to increase spacing between the press wheels.
- Place one or several spacers (1) on the outside to reduce spacing between the press wheels.

- Reinstall nut (1).

Repeat procedure on the other press wheel.




Adjustment of the tamping wheel cleaners

The cleaners remove soil build up around the tamping wheels.

Lateral adjustment

- Loosen nut (1).
- Center cleaner (2) with regards to wheel (3).
- Tighten nut (1).
- Repeat procedure on the other cleaner.



Adjusting the scraper's position

The scraper's position must be adjusted according to the sowing conditions:


- Position (a): Slightly wet conditions.

Loosen nut (1) to reduce distance between scraper (2) and the wheel.

- Position (b): Dry conditions.

Tighten nut (1) to increase distance between scraper (2) and the wheel.

Repeat procedure on each seeding unit.




Adjusting the plates

- Loosen nut (1).
- Adjust plate (2) to bring it closer to the tamping wheel but without touching it. Rotate wheel once to check that it is not in contact.



In slightly wet conditions, reduce spacing between plate and wheel as much as possible to reduce wear.


- Tighten screws (1).
- Repeat procedure on each seeding unit.



■ Maintenance


Greasing (Every 50 hours)

- The tamping wheel pivot pin.




Replacing the scraper plates

- Remove nut (1).
- Remove screw (2) and washer (3).
- Turn plate over or replace it if necessary.

 **Scraper plate Part no. K3600550.**

- Reinstall screw (2), nut (1) and washer (3).



11. "OTIFLEX" 370 x 165 roller

The OTIFLEX roller must be used in combination with a soil centering system.

Kit no. 1676757


370 x 165 OTIFLEX roller and covering scrapers.

Kit no. 1676859

370 x 165 OTIFLEX roller and furrow closing disks.

The OTIFLEX roller enables packing soil mounds formed by the soil centering system (Furrow closing disks and/or covering plates).


The rubber banding is self-cleaning.



■ Adjustments

Lateral adjustment

- Unscrew the 4 bolts (1).
- Centre roller (2) in relation to the seeding line.
- Tighten the 4 bolts (1).




Check setting over the first few metres sown.

Adjusting the tamping pressure


Lever (1) enables adjusting the tamping pressure.

- Position lever (1) in one of the adjusting catches 5:
 - To reduce the tamping pressure in F, move adjustment lever (1) frontwards.
 - Move adjustment lever (1) rearwards to increase tamping pressure in F.



■ Grease (Every 50 hours)

- The tamping wheel pivot pin.



12. "OTIFLEX" 500 x 175 roller

The OTIFLEX roller must be used in combination with a soil centering system.

Kit no. 1676758


500 x 175 OTIFLEX roller and covering scrapers.

Kit no. 1676863

500 x 175 OTIFLEX roller and furrow closing disks.

The OTIFLEX roller enables packing soil mounds formed by the soil centering system (Furrow closing disks and/or covering plates).


The rubber banding is self-cleaning.



■ Adjustments

Lateral adjustment

- Unscrew the 4 bolts (1).
- Centre roller (2) in relation to the seeding line.
- Tighten the 4 bolts (1).




Check setting over the first few metres sown.

Adjusting the tamping pressure


Lever (1) enables adjusting the tamping pressure.

- Position lever (1) in one of the adjusting catches 5:
 - To reduce the tamping pressure in F, move adjustment lever (1) frontwards.
 - Mover adjustment lever (1) rearwards to increase tamping pressure in F.



■ Grease (Every 50 hours)

- The tamping wheel pivot pin.



13. Microgranulator

Several microgranulators can be fitted on the machine:

For the following models:

M2M08RT000A003

First equipment microgranulator

Kit no. 1677163

Insecticide microgranulator 8 rows, 100 L (26 US gal) hoppers with front blower and fitting on air duct.

Kit no. 1677164

Slug pellet microgranulator 8 rows, 100 L (26 US gal) hoppers with front blower and fitting on air duct.

Kit no. 1677165

Herbicide microgranulator 8 rows, 190 L (50 US gal) hoppers with front blower and fitting on air duct.

Second equipment microgranulator

Kit no. 1677139

Insecticide microgranulator 8 rows, with 100 L (26 US gal) hoppers and fitting on air duct.

Kit no. 1677140

Slug pellet microgranulator 8 rows, with 100 L (26 US gal) hoppers and fitting on air duct.

Kit no. 1677292

Herbicide microgranulator 8 rows, with 190 (50 US gal) hoppers and fitting on air duct.

For the following models:

- M2M08RT000AG03

First equipment microgranulator

Kit no. 1677145

Insecticide microgranulator 8 rows with 100 L (21 US gal) hopper and fitting in high position.

Kit no. 1677146

Anti-slug pellet microgranulator 8 rows with 100 L (21 US gal) hopper and fitting in high position.

Kit no. 1677147

Herbicide microgranulator 8 rows with 190 L (40 US gal) hopper and fitting in high position.

Second equipment microgranulator

Kit no. 1677145

Insecticide microgranulator 8 rows with 100 L (21 US gal) hopper and fitting in high position.


Kit no. 1677146

Anti-slug pellet microgranulator 8 rows with 100 L (21 US gal) hopper and fitting in high position.

Kit no. 1677147

Herbicide microgranulator 8 rows with 190 L (40 US gal) hopper and fitting in high position.

■ **Description and glossary**



- | | |
|---|---|
| 1 : Cover | 2 : Sieve |
| 3 : Hopper | 4 : Distribution |
| 5 : Emptying lever | 6 : Outlet opening lever |
| 7 : Driven shaft | 8 : Drive shaft |
| 9 : Gearwheel storage | 10 : Herbicide spreading |
| 11 : Application of slug pellets behind the roller | 12 : Application of slug pellets in front of the roller |
| 13 : Application of slug pellets on the furrow bottom | 14 : Application of insecticide on the furrow bottom |

■ Technical specifications

| MAXIMA | | | | | |
|-----------------------------|---------------------|--|---|---|---|
| Insecticide microgranulator | | | | | |
| | Outputs | 9 | | | |
| Hopper | Capacity (L) | 100 | | | |
| | Material | polyethylene | | | |
| | Length (cm) | 69 | | | |
| | Height (cm) | 64 | | | |
| | Width (cm) | 58 | | | |
| Opening | Length (cm) | 43.0 | | | |
| | Width (cm) | 32.0 | | | |
| Sieve | Length (cm) | 44.6 | | | |
| | Width (cm) | 34.0 | | | |
| | Height (cm) | 6.5 | | | |
| | Area sown "ha trip" | 1568 | | | |
| | Material | Steel | | | |
| | Meshes | Diameter 2.5 mm ; Spacing 3.5 | | | |
| Cover | Type | Pivoting | | | |
| Agitator | Type | Without | | | |
| Emptying the hopper | Type | Sliding hatch | | | |
| Metering unit | Type | Fertiliser metering unit | | | |
| Drive | Type | Chain and gearwheels | | | |
| Adjustment | Valve and gears | Spacing 75 cm : 2,3 L/Ha | | | |
| | PTO and belt | Spacing 75 cm : 31,8 L/Ha | | | |
| | Type | Valve and gears | | | |
| Blower | Drive | PTO and belt | | | |
| | min ⁻¹ | 6300 | | | |
| Outputs | Quantity | In the furrow | 7 | 8 | 9 |
| | | Between coulter and rollers | | | |
| | | Behind rollers | | | |
| | Dimensions (mm) | Diameter 25 / Diameter 21 | | | |
| | Length (cm) | 31,5 | | | |
| | Cyclone and tube | 7 | 8 | 9 | |
| | Rigid tube | | | | |
| | Burster | | | | |
| Line width | 1 to 2 cm | | | | |
| Tubes | Material | PVC | | | |
| | Dimensions | Inner diameter 25 mm ; Length 1 to 9 m | | | |



| MAXIMA | | | | | |
|-----------------------------|-----------------|-----------------------------|--|------|---|
| Slug pellet microgranulator | | | | | |
| | | Outputs | 9 | | |
| Hopper | | Metering units | 9 | | |
| | | Capacity (L) | 100 | | |
| | | Material | polyethylene | | |
| | | Length (cm) | 69 | | |
| | | Height (cm) | 64 | | |
| | | Width (cm) | 58 | | |
| | Opening | | Length (cm) | 43.0 | |
| | | Width (cm) | 32.0 | | |
| Sieve | | Length (cm) | 44.6 | | |
| | | Width (cm) | 34.0 | | |
| | | Height (cm) | 6,5 | | |
| | | Area sown "ha trip" | 1568 | | |
| | | Material | Steel | | |
| | | Meshes | Diameter 2.5 mm ; Spacing 3.5 mm | | |
| Cover | | Type | Pivoting | | |
| Agitator | | Type | Without | | |
| Emptying the hopper | | Type | Sliding hatch | | |
| Metering unit | | Type | Fertiliser metering unit | | |
| Drive | | Type | Chain and gearwheels | | |
| Adjustment | | Valve and gears | Spacing 75 cm : 2,3 L/Ha | | |
| | | PTO and belt | Spacing 75 cm : 31,8 L/Ha | | |
| | | Type | Valve and gears | | |
| Blower | | Drive | PTO and belt | | |
| | | Min ⁻¹ | 6300 | | |
| Outputs | Quantity | In the furrow | | | |
| | | Between coulter and rollers | | | |
| | | Behind rollers | 7 | 8 | 9 |
| | | Dimensions (mm) | Diameter 25 / Diameter 21 | | |
| | | Length (cm) | 24,5 | | |
| | | Cyclone and tube | | | |
| | | Rigid tube | 7 | 8 | 9 |
| | | Burster | | | |
| | Line width (cm) | 2 to 6 | | | |
| Tubes | | Material | PVC | | |
| | | Dimensions | Inner diameter 25 mm ; Length 1 to 9 m | | |

MAXIMA

Herbicide microgranulator

| | | | | |
|---------------------|---------------------|--|---|---|
| | Outputs | 9 | | |
| Hopper | Capacity (L) | 190 | | |
| | Material | polyethylene | | |
| | Length (cm) | 69 | | |
| | Height (cm) | 84 | | |
| | Width (cm) | 58 | | |
| Opening | Length (cm) | 43.0 | | |
| | Width (cm) | 32.0 | | |
| Sieve | Length (cm) | 44.6 | | |
| | Width (cm) | 34.0 | | |
| | Height (cm) | 6.5 | | |
| | Area sown "ha trip" | 1568 | | |
| | Material | Steel | | |
| | Meshes | Diameter 2.5 mm ; Spacing 3.5 mm | | |
| Cover | Type | Pivoting | | |
| Agitator | Type | Without | | |
| Emptying the hopper | Type | Sliding hatch | | |
| Metering unit | Type | Fertiliser metering unit | | |
| Drive | Type | Chain and gearwheels | | |
| Adjustment | Valve and gears | Spacing 75 cm : 2,3 L/Ha | | |
| | PTO and belt | Spacing 75 cm : 31,8 L/Ha | | |
| | Type | Valve and gears | | |
| Blower | Drive | PTO and belt | | |
| | Min ⁻¹ | 6300 | | |
| Outputs | Quantity | In the furrow | | |
| | | Between coulter and rollers | | |
| | | Behind rollers | 7 | 8 |
| | Dimensions (mm) | Diameter 25 / Diameter 21 | | |
| | Length (cm) | 108 | | |
| | Cyclone and tube | | | |
| | Rigid tube | | | |
| | Burster | 7 | 8 | 9 |
| Line width (cm) | 100 to 150 | | | |
| Tubes | Material | PVC | | |
| | Dimensions | Inner diameter 25 mm ; Length 1 to 9 m | | |



■ Adjusting the seed rate

Adjustment charts for insecticide and slug pellet microgranulator

| TABLEAU DE REGLAGE MICRO INSECTICIDE ANTILIMACE EN LITRES/Ha | | MICROGRANULATOR CALIBRATION CHART INSECTICIDE-SLUG PELLETS LITRES/Ha | | | | | | | | | | | | EINSTELLTABELLE MICROGRANULATSTREUER INSEKTIZID-SCHNECKENKORN LITER/Ha | | | | | | | | | | | | TABLA DE AJUSTE DEL MICROGRANULADOR INSECTICIDA-ANTIBABOSA EN LITROS/Ha | | | | | | | | | | | | TABELLE DI REGOLAZIONE DEL MICROGRANULATORE INSETTICIDA-ANTILUMACHE IN LITRI/ETTARI | | | | | | | | | | | |
|---|------------------|---|------|---------------|------|------------|------|-------------|------|------------|------------------|---------|------|---|------|------------|------|-------------|------|------------|------------------|---------|------|---------------|------|--|----|-------------|----|----|----|----|----|----|----|----|----|--|----|----|----|--|--|--|--|--|--|--|--|
| | | A:12 | | | | | | B:36 | | | | | | | | A:12 | | | | | | B:24 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| L. 100M | Ecartement CM | Spacing | | Reihenabstand | | Separacion | | Scostamento | | L. 100M | Ecartement CM | Spacing | | Reihenabstand | | Separacion | | Scostamento | | L. 100M | Ecartement CM | Spacing | | Reihenabstand | | Separacion | | Scostamento | | | | | | | | | | | | | | | | | | | | | |
| | | 25 | 30 | 35 | 40 | 45 | 50 | 55 | 60 | | | 65 | 70 | 75 | 80 | 25 | 30 | 35 | 40 | | | 45 | 50 | 55 | 60 | 65 | 70 | 75 | 80 | 25 | 30 | 35 | 40 | 45 | 50 | 55 | 60 | 65 | 70 | 75 | 80 | | | | | | | | |
| 0 | 0.0172 | 6.9 | 5.7 | 4.9 | 4.3 | 3.8 | 3.4 | 3.1 | 2.9 | 2.6 | 2.5 | 2.3 | 2.2 | 0.0248 | 9.9 | 8.3 | 7.1 | 6.2 | 5.5 | 5 | 4.5 | 4.1 | 3.8 | 3.5 | 3.3 | 3.1 | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 0.0176 | 7 | 5.9 | 5 | 4.4 | 3.9 | 3.5 | 3.2 | 2.9 | 2.7 | 2.5 | 2.3 | 2.2 | 0.0254 | 10.2 | 8.5 | 7.3 | 6.4 | 5.6 | 5.1 | 4.6 | 4.2 | 3.9 | 3.6 | 3.4 | 3.2 | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | 0.0184 | 7.4 | 6.1 | 5.3 | 4.6 | 4.1 | 3.7 | 3.3 | 3.1 | 2.8 | 2.6 | 2.5 | 2.3 | 0.0264 | 10.6 | 8.8 | 7.5 | 6.6 | 5.9 | 5.3 | 4.8 | 4.4 | 4.1 | 3.8 | 3.5 | 3.3 | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | 0.0192 | 7.7 | 6.4 | 5.5 | 4.8 | 4.3 | 3.8 | 3.5 | 3.2 | 3 | 2.7 | 2.6 | 2.4 | 0.0276 | 11 | 9.2 | 7.9 | 6.9 | 6.1 | 5.5 | 5 | 4.6 | 4.2 | 3.9 | 3.7 | 3.5 | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | 0.0208 | 8.3 | 6.9 | 5.9 | 5.2 | 4.6 | 4.2 | 3.8 | 3.5 | 3.2 | 3 | 2.8 | 2.6 | 0.0304 | 12.2 | 10.1 | 8.7 | 7.6 | 6.8 | 6.1 | 5.5 | 5.1 | 4.7 | 4.3 | 4.1 | 3.8 | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | 0.0226 | 9 | 7.5 | 6.5 | 5.7 | 5 | 4.5 | 4.1 | 3.8 | 3.5 | 3.2 | 3 | 2.8 | 0.0326 | 13 | 10.9 | 9.3 | 8.2 | 7.2 | 6.5 | 5.9 | 5.4 | 5 | 4.7 | 4.3 | 4.1 | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | 0.0242 | 9.7 | 8.1 | 6.9 | 6.1 | 5.4 | 4.8 | 4.4 | 4 | 3.7 | 3.5 | 3.2 | 3 | 0.0342 | 13.7 | 11.4 | 9.8 | 8.6 | 7.6 | 6.8 | 6.2 | 5.7 | 5.3 | 4.9 | 4.6 | 4.3 | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | 0.0264 | 10.6 | 8.8 | 7.5 | 6.6 | 5.9 | 5.3 | 4.8 | 4.4 | 4.1 | 3.8 | 3.5 | 3.3 | 0.0364 | 14.6 | 12.1 | 10.4 | 9.1 | 8.1 | 7.3 | 6.6 | 6.1 | 5.6 | 5.2 | 4.9 | 4.6 | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | 0.0278 | 11.1 | 9.3 | 7.9 | 7 | 6.2 | 5.6 | 5.1 | 4.6 | 4.3 | 4 | 3.7 | 3.5 | 0.0386 | 15.4 | 12.9 | 11 | 9.7 | 8.6 | 7.7 | 7 | 6.4 | 5.9 | 5.5 | 5.1 | 4.8 | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | 0.0292 | 11.7 | 9.7 | 8.3 | 7.3 | 6.5 | 5.8 | 5.3 | 4.9 | 4.5 | 4.2 | 3.9 | 3.7 | 0.0405 | 16.2 | 13.5 | 11.6 | 10.1 | 9 | 8.1 | 7.4 | 6.8 | 6.2 | 5.8 | 5.4 | 5.1 | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | 0.031 | 12.4 | 10.3 | 8.9 | 7.8 | 6.9 | 6.2 | 5.6 | 5.2 | 4.8 | 4.4 | 4.1 | 3.9 | 0.0426 | 17 | 14.2 | 12.2 | 10.7 | 9.5 | 8.5 | 7.7 | 7.1 | 6.6 | 6.1 | 5.7 | 5.3 | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | 0.0314 | 12.6 | 10.5 | 9 | 7.9 | 7 | 6.3 | 5.7 | 5.2 | 4.8 | 4.5 | 4.2 | 3.9 | 0.043 | 17.2 | 14.3 | 12.3 | 10.8 | 9.6 | 8.6 | 7.8 | 7.2 | 6.6 | 6.1 | 5.7 | 5.4 | | | | | | | | | | | | | | | | | | | | | | | |
| | | A:16 | | | | | | B:20 | | | | | | | | A:20 | | | | | | B:16 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| L. 100M | Ecartement CM | Spacing | | Reihenabstand | | Separacion | | Scostamento | | L. 100M | Ecartement CM | Spacing | | Reihenabstand | | Separacion | | Scostamento | | L. 100M | Ecartement CM | Spacing | | Reihenabstand | | Separacion | | Scostamento | | | | | | | | | | | | | | | | | | | | | |
| | | 25 | 30 | 35 | 40 | 45 | 50 | 55 | 60 | 65 | 70 | 75 | 80 | | | 25 | 30 | 35 | 40 | 45 | 50 | 55 | 60 | 65 | 70 | 75 | 80 | | | 25 | 30 | 35 | 40 | 45 | 50 | 55 | 60 | 65 | 70 | 75 | 80 | | | | | | | | |
| 0 | 0.0398 | 15.9 | 13.3 | 11.4 | 10 | 8.8 | 8 | 7.2 | 6.6 | 6.1 | 5.7 | 5.3 | 5 | 0.0608 | 24.3 | 20.3 | 17.4 | 15.2 | 13.5 | 12.2 | 11.1 | 10.1 | 9.4 | 8.7 | 8.1 | 7.6 | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 0.041 | 16.4 | 13.7 | 11.7 | 10.3 | 9.1 | 8.2 | 7.5 | 6.8 | 6.3 | 5.9 | 5.5 | 5.1 | 0.063 | 25.2 | 21 | 18 | 15.8 | 14 | 12.6 | 11.5 | 10.5 | 9.7 | 9 | 8.4 | 7.9 | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | 0.042 | 16.8 | 14 | 12 | 10.5 | 9.3 | 8.4 | 7.6 | 7 | 6.5 | 6 | 5.6 | 5.3 | 0.0656 | 26.2 | 21.9 | 18.7 | 16.4 | 14.6 | 13.1 | 11.9 | 10.9 | 10.1 | 9.4 | 8.7 | 8.2 | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | 0.0448 | 17.9 | 14.9 | 12.8 | 11.2 | 10 | 9 | 8.1 | 7.5 | 6.9 | 6.4 | 6 | 5.6 | 0.0702 | 28.1 | 23.4 | 20.1 | 17.6 | 15.6 | 14 | 12.8 | 11.7 | 10.8 | 10 | 9.4 | 8.8 | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | 0.0482 | 19.3 | 16.1 | 13.8 | 12.1 | 10.7 | 9.6 | 8.8 | 8 | 7.4 | 6.9 | 6.4 | 6 | 0.0752 | 30.1 | 25.1 | 21.5 | 18.8 | 16.7 | 15 | 13.7 | 12.5 | 11.6 | 10.7 | 10 | 9.4 | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | 0.052 | 20.8 | 17.3 | 14.9 | 13 | 11.6 | 10.4 | 9.5 | 8.7 | 8 | 7.4 | 6.9 | 6.5 | 0.0804 | 32.2 | 26.8 | 23 | 20.1 | 17.9 | 16.1 | 14.6 | 13.4 | 12.4 | 11.5 | 10.7 | 10.1 | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | 0.056 | 22.4 | 18.7 | 16 | 14 | 12.4 | 11.2 | 10.2 | 9.3 | 8.6 | 8 | 7.5 | 7 | 0.085 | 34 | 28.3 | 24.3 | 21.3 | 18.9 | 17 | 15.5 | 14.2 | 13.1 | 12.1 | 11.3 | 10.6 | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | 0.0596 | 23.8 | 19.9 | 17 | 14.9 | 13.2 | 11.9 | 10.8 | 9.9 | 9.2 | 8.5 | 7.9 | 7.5 | 0.09 | 36 | 30 | 25.7 | 22.5 | 20 | 18 | 16.4 | 15 | 13.8 | 12.9 | 12 | 11.3 | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | 0.063 | 25.2 | 21 | 18 | 15.8 | 14 | 12.6 | 11.5 | 10.5 | 9.7 | 9 | 8.4 | 7.9 | 0.095 | 38 | 31.7 | 27.1 | 23.8 | 21.1 | 19 | 17.3 | 15.8 | 14.6 | 13.6 | 12.7 | 11.9 | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | 0.0668 | 26.7 | 22.3 | 19.1 | 16.7 | 14.8 | 13.4 | 12.1 | 11.1 | 10.3 | 9.5 | 8.9 | 8.4 | 0.1006 | 40.2 | 33.5 | 28.7 | 25.2 | 22.4 | 20.1 | 18.3 | 16.8 | 15.5 | 14.4 | 13.4 | 12.6 | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | 0.069 | 27.6 | 23 | 19.7 | 17.3 | 15.3 | 13.8 | 12.5 | 11.5 | 10.6 | 9.9 | 9.2 | 8.6 | 0.104 | 41.6 | 34.7 | 29.7 | 26 | 23.1 | 20.8 | 18.9 | 17.3 | 16 | 14.9 | 13.9 | 13 | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | 0.0706 | 28.2 | 23.5 | 20.2 | 17.7 | 15.7 | 14.1 | 12.8 | 11.8 | 10.9 | 10.1 | 9.4 | 8.8 | 0.1056 | 42.2 | 35.2 | 30.2 | 26.4 | 23.5 | 21.1 | 19.2 | 17.6 | 16.2 | 15.1 | 14.1 | 13.2 | | | | | | | | | | | | | | | | | | | | | | | |
| | | A:24 | | | | | | B:12 | | | | | | | | A:36 | | | | | | B:12 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| L. 100M | Ecartement CM | Spacing | | Reihenabstand | | Separacion | | Scostamento | | L. 100M | Ecartement CM | Spacing | | Reihenabstand | | Separacion | | Scostamento | | L. 100M | Ecartement CM | Spacing | | Reihenabstand | | Separacion | | Scostamento | | | | | | | | | | | | | | | | | | | | | |
| | | 25 | 30 | 35 | 40 | 45 | 50 | 55 | 60 | 65 | 70 | 75 | 80 | | | 25 | 30 | 35 | 40 | 45 | 50 | 55 | 60 | 65 | 70 | 75 | 80 | | | 25 | 30 | 35 | 40 | 45 | 50 | 55 | 60 | 65 | 70 | 75 | 80 | | | | | | | | |
| 0 | 0.0944 | 37.8 | 31.5 | 27 | 23.6 | 21 | 18.9 | 17.2 | 15.7 | 14.5 | 13.5 | 12.6 | 11.8 | 0.1338 | 53.5 | 44.6 | 38.2 | 33.5 | 29.7 | 26.8 | 24.3 | 22.3 | 20.6 | 19.1 | 17.8 | 16.7 | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 0.096 | 38.4 | 32 | 27.4 | 24 | 21.3 | 19.2 | 17.5 | 16 | 14.8 | 13.7 | 12.8 | 12 | 0.144 | 57.6 | 48 | 41.1 | 36 | 32 | 28.8 | 26.2 | 24 | 22.2 | 20.6 | 19.2 | 18 | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | 0.1 | 40 | 33.3 | 28.6 | 25 | 22.2 | 20 | 18.2 | 16.7 | 15.4 | 14.3 | 13.3 | 12.5 | 0.1506 | 60.2 | 50.2 | 43 | 37.7 | 33.5 | 30.1 | 27.4 | 25.1 | 23.2 | 21.5 | 20.1 | 18.8 | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | 0.108 | 43.2 | 36 | 30.9 | 27 | 24 | 21.6 | 19.6 | 18 | 16.6 | 15.4 | 14.4 | 13.5 | 0.1624 | 65 | 54.1 | 46.4 | 40.6 | 36.1 | 32.5 | 29.5 | 27.1 | 25 | 23.2 | 21.7 | 20.3 | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | 0.1158 | 46.3 | 38.6 | 33.1 | 29 | 25.7 | 23.2 | 21.1 | 19.3 | 17.8 | 16.5 | 15.4 | 14.5 | 0.174 | 69.6 | 58 | 49.7 | 43.5 | 38.7 | 34.8 | 31.6 | 29 | 26.8 | 24.9 | 23.2 | 21.8 | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | 0.1236 | 49.4 | 41.2 | 35.3 | 30.9 | 27.5 | 24.7 | 22.5 | 20.6 | 19 | 17.7 | 16.5 | 15.5 | 0.1856 | 74.2 | 61.9 | 53 | 46.4 | 41.2 | 37.1 | 33.7 | 30.9 | 28.6 | 26.5 | 24.7 | 23.2 | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | 0.132 | 52.8 | 44 | 37.7 | 33 | 29.3 | 26.4 | 24 | 22 | 20.3 | 18.9 | 17.6 | 16.5 | 0.1976 | 79 | 65.9 | 56.5 | 49.4 | 43.9 | 39.5 | 35.9 | 32.9 | 30.4 | 28.2 | 26.3 | 24.7 | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | 0.1398 | 55.9 | 46.6 | 39.9 | 35 | 31.1 | 28 | 25.4 | 23.3 | 21.5 | 20 | 18.6 | 17.5 | 0.2092 | 83.7 | 69.7 | 59.8 | 52.3 | 46.5 | 41.8 | 38 | 34.9 | 32.2 | 29.9 | 27.9 | 26.2 | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | 0.1474 | 59 | 49.1 | 42.1 | 36.9 | 32.8 | 29.5 | 26.8 | 24.6 | 22.7 | 21.1 | 19.7 | 18.4 | 0.2208 | 88.3 | 73.6 | 63.1 | 55.2 | 49.1 | 44.2 | 40.1 | 36.8 | 34 | 31.5 | 29.4 | 27.6 | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | 0.154 | 61.6 | 51.3 | 44 | 38.5 | 34.2 | 30.8 | 28 | 25.7 | 23.7 | 22 | 20.5 | 19.3 | 0.2314 | 92.6 | 77.1 | 66.1 | 57.9 | 51.4 | 46.3 | 42.1 | 38.6 | 35.6 | 33.1 | 30.9 | 28.9 | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | 0.1574 | 63 | 52.5 | 45 | 39.4 | 35 | 31.5 | 28.6 | 26.2 | 24.2 | 22.5 | 21 | 19.7 | 0.236 | 94.4 | 78.7 | 67.4 | 59 | 52.4 | 47.2 | 42.9 | 39.3 | 36.3 | 33.7 | 31.5 | 29.5 | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | 0.159 | 63.6 | 53 | 45.4 | 39.8 | 35.3 | 31.8 | 28.9 | 26.5 | 24.5 | 22.7 | 21.2 | 19.9 | 0.2384 | 95.4 | 79.5 | 68.1 | 59.6 | 53 | 47.7 | 43.3 | 39.7 | 36.7 | 34.1 | 31.8 | 29.8 | | | | | | | | | | | | | | | | | | | | | | | |

Les quantités indiquées ne sont données qu'à titre indicatif. The given values should be used as a guide only. Die angegebenen Werte sind Richtwerte.
 Los cantidades se especifican solo a título indicativo. Le quantità indicate sono soltanto a titolo indicativo. FLA217DA



Settings are only indicated for your information.

Adjustment charts for herbicide microgranulator

| TABLEAU DE REGLAGE MICROGRANULATEUR HERBICIDE EN LITRES/Ha | | MICROGRANULATOR CALIBRATION CHART HERBICIDE LITRES/Ha | | | | | | | | | | EINSTELLTABELLE MICROGRANULATSTREUER HERBIZID LITER/Ha | | | | | | | | | | TABLA DE AJUSTE DEL MICROGRANULADOR HERBICIDA EN LITROS/Ha | | | | | | | | | | TABELLE DI REGOLAZIONE DEL MICROGRANULATORE ERBICIDA IN LITRI/ETTARI | | | | | | | | | |
|---|------------|--|------|---------|------|---------------|------|------------|------|-------------|------|---|------------|-------|---------|------|---------------|------|------------|------|-------------|---|------|------|------|------|--|--|--|--|--|---|--|--|--|--|--|--|--|--|--|
| | | A:12 | | | | | B:24 | | | | | | | A:16 | | | | | B:20 | | | | | | | | | | | | | | | | | | | | | | |
| | L. 100M | Ecartement | | Spacing | | Reihenabstand | | Separacion | | Scostamento | | L. 100M | Ecartement | | Spacing | | Reihenabstand | | Separacion | | Scostamento | | | | | | | | | | | | | | | | | | | | |
| | | 40 | 45 | 50 | 55 | 60 | 65 | 70 | 75 | 80 | 85 | | 90 | 100 | 40 | 45 | 50 | 55 | 60 | 65 | 70 | 75 | 80 | 85 | 90 | 100 | | | | | | | | | | | | | | | |
| 0 | 0.064 | 16 | 14.2 | 12.8 | 11.6 | 10.7 | 9.8 | 9.1 | 8.5 | 8 | 7.5 | 7.1 | 6.4 | 0.102 | 25.5 | 22.7 | 20.4 | 18.5 | 17 | 15.7 | 14.6 | 13.6 | 12.8 | 12 | 11.3 | 10.2 | | | | | | | | | | | | | | | |
| 1 | 0.066 | 16.5 | 14.7 | 13.2 | 12 | 11 | 10.2 | 9.4 | 8.8 | 8.3 | 7.8 | 7.3 | 6.6 | 0.104 | 26 | 23.1 | 20.8 | 18.9 | 17.3 | 16 | 14.9 | 13.9 | 13 | 12.2 | 11.6 | 10.4 | | | | | | | | | | | | | | | |
| 2 | 0.07 | 17.5 | 15.6 | 14 | 12.7 | 11.7 | 10.8 | 10 | 9.3 | 8.8 | 8.2 | 7.8 | 7 | 0.109 | 27.3 | 24.2 | 21.8 | 19.8 | 18.2 | 16.8 | 15.6 | 14.5 | 13.6 | 12.8 | 12.1 | 10.9 | | | | | | | | | | | | | | | |
| 3 | 0.075 | 18.8 | 16.7 | 15 | 13.6 | 12.5 | 11.5 | 10.7 | 10 | 9.4 | 8.8 | 8.3 | 7.5 | 0.117 | 29.3 | 26 | 23.4 | 21.3 | 19.5 | 18 | 16.7 | 15.6 | 14.6 | 13.8 | 13 | 11.7 | | | | | | | | | | | | | | | |
| 4 | 0.082 | 20.5 | 18.2 | 16.4 | 14.9 | 13.7 | 12.6 | 11.7 | 10.9 | 10.3 | 9.6 | 9.1 | 8.2 | 0.129 | 32.3 | 28.7 | 25.8 | 23.5 | 21.5 | 19.8 | 18.4 | 17.2 | 16.1 | 15.2 | 14.3 | 12.9 | | | | | | | | | | | | | | | |
| 5 | 0.091 | 22.8 | 20.2 | 18.2 | 16.5 | 15.2 | 14 | 13 | 12.1 | 11.4 | 10.7 | 10.1 | 9.1 | 0.144 | 36 | 32 | 28.8 | 26.2 | 24 | 22.2 | 20.6 | 19.2 | 18 | 16.9 | 16 | 14.4 | | | | | | | | | | | | | | | |
| 6 | 0.103 | 25.8 | 22.9 | 20.6 | 18.7 | 17.2 | 15.8 | 14.7 | 13.7 | 12.9 | 12.1 | 11.4 | 10.3 | 0.161 | 40.3 | 35.8 | 32.2 | 29.3 | 26.8 | 24.8 | 23 | 21.5 | 20.1 | 18.9 | 17.9 | 16.1 | | | | | | | | | | | | | | | |
| 7 | 0.114 | 28.5 | 25.3 | 22.8 | 20.7 | 19 | 17.5 | 16.3 | 15.2 | 14.3 | 13.4 | 12.7 | 11.4 | 0.177 | 44.3 | 39.3 | 35.4 | 32.2 | 29.5 | 27.2 | 25.3 | 23.6 | 22.1 | 20.8 | 19.7 | 17.7 | | | | | | | | | | | | | | | |
| 8 | 0.126 | 31.5 | 28 | 25.2 | 22.9 | 21 | 19.4 | 18 | 16.8 | 15.8 | 14.8 | 14 | 12.6 | 0.197 | 49.3 | 43.8 | 39.4 | 35.8 | 32.8 | 30.3 | 28.1 | 26.3 | 24.6 | 23.2 | 21.9 | 19.7 | | | | | | | | | | | | | | | |
| 9 | 0.139 | 34.8 | 30.9 | 27.8 | 25.3 | 23.2 | 21.4 | 19.9 | 18.5 | 17.4 | 16.4 | 15.4 | 13.9 | 0.214 | 53.5 | 47.6 | 42.8 | 38.9 | 35.7 | 32.9 | 30.6 | 28.5 | 26.8 | 25.2 | 23.8 | 21.4 | | | | | | | | | | | | | | | |
| 10 | 0.15 | 37.5 | 33.3 | 30 | 27.3 | 25 | 23.1 | 21.4 | 20 | 18.8 | 17.6 | 16.7 | 15 | 0.233 | 58.3 | 51.8 | 46.6 | 42.4 | 38.8 | 35.8 | 33.3 | 31.1 | 29.1 | 27.4 | 25.9 | 23.3 | | | | | | | | | | | | | | | |
| 11 | 0.16 | 40 | 35.6 | 32 | 29.1 | 26.7 | 24.6 | 22.9 | 21.3 | 20 | 18.8 | 17.8 | 16 | 0.249 | 62.3 | 55.3 | 49.8 | 45.3 | 41.5 | 38.3 | 35.6 | 33.2 | 31.1 | 29.3 | 27.7 | 24.9 | | | | | | | | | | | | | | | |
| | | A:20 | | | | | B:16 | | | | | | | A:24 | | | | | B:12 | | | | | | | | | | | | | | | | | | | | | | |
| | L. 100M | Ecartement | | Spacing | | Reihenabstand | | Separacion | | Scostamento | | L. 100M | Ecartement | | Spacing | | Reihenabstand | | Separacion | | Scostamento | | | | | | | | | | | | | | | | | | | | |
| | | 40 | 45 | 50 | 55 | 60 | 65 | 70 | 75 | 80 | 85 | | 90 | 100 | 40 | 45 | 50 | 55 | 60 | 65 | 70 | 75 | 80 | 85 | 90 | 100 | | | | | | | | | | | | | | | |
| 0 | 0.157 | 39.3 | 34.9 | 31.4 | 28.5 | 26.2 | 24.2 | 22.4 | 20.9 | 19.6 | 18.5 | 17.4 | 15.7 | 0.247 | 61.8 | 54.9 | 49.4 | 44.9 | 41.2 | 38 | 35.3 | 32.9 | 30.9 | 29.1 | 27.4 | 24.7 | | | | | | | | | | | | | | | |
| 1 | 0.16 | 40 | 35.6 | 32 | 29.1 | 26.7 | 26.4 | 22.9 | 21.3 | 20 | 18.8 | 17.8 | 16 | 0.252 | 63 | 56 | 50.4 | 45.8 | 42 | 38.8 | 36 | 33.6 | 31.5 | 29.6 | 28 | 25.2 | | | | | | | | | | | | | | | |
| 2 | 0.168 | 42 | 37.3 | 33.6 | 30.5 | 28 | 25.8 | 24 | 22.4 | 21 | 19.8 | 18.7 | 16.8 | 0.264 | 66 | 58.7 | 52.8 | 48 | 44 | 40.6 | 37.7 | 35.2 | 33 | 31.1 | 29.3 | 26.4 | | | | | | | | | | | | | | | |
| 3 | 0.181 | 45.3 | 40.2 | 36.2 | 32.9 | 30.2 | 27.8 | 25.9 | 24.1 | 22.6 | 21.3 | 20.1 | 18.1 | 0.281 | 70.3 | 62.4 | 56.2 | 51.1 | 46.8 | 43.2 | 40.1 | 37.5 | 35.1 | 33.1 | 31.2 | 28.1 | | | | | | | | | | | | | | | |
| 4 | 0.2 | 50 | 40.4 | 40 | 36.4 | 33.3 | 30.8 | 28.6 | 26.7 | 25 | 23.5 | 22.2 | 20 | 0.308 | 77 | 68.4 | 61.6 | 56 | 51.3 | 47.4 | 44 | 41.1 | 38.5 | 36.2 | 34.2 | 30.8 | | | | | | | | | | | | | | | |
| 5 | 0.223 | 55.8 | 49.6 | 44.6 | 40.5 | 37.2 | 34.3 | 31.9 | 29.7 | 27.9 | 26.2 | 24.8 | 22.3 | 0.347 | 86.8 | 77.1 | 69.4 | 63.1 | 57.8 | 53.4 | 49.6 | 46.3 | 43.4 | 40.8 | 38.6 | 34.7 | | | | | | | | | | | | | | | |
| 6 | 0.249 | 62.3 | 55.3 | 49.8 | 45.3 | 41.5 | 38.3 | 35.6 | 33.2 | 31.1 | 29.3 | 27.7 | 24.9 | 0.388 | 97 | 86.2 | 77.6 | 70.5 | 64.7 | 59.7 | 55.4 | 51.7 | 48.5 | 45.6 | 43.1 | 38.8 | | | | | | | | | | | | | | | |
| 7 | 0.275 | 68.8 | 61.1 | 55 | 50 | 45.8 | 42.3 | 39.3 | 36.7 | 34.4 | 32.4 | 30.6 | 27.5 | 0.431 | 108 | 95.8 | 86.2 | 78.4 | 71.8 | 66.3 | 61.6 | 57.5 | 53.9 | 50.7 | 47.9 | 43.1 | | | | | | | | | | | | | | | |
| 8 | 0.302 | 75.5 | 67.1 | 60.4 | 54.9 | 50.3 | 46.5 | 43.1 | 40.3 | 37.8 | 35.5 | 33.6 | 30.2 | 0.475 | 119 | 106 | 95 | 86.4 | 79.2 | 73.1 | 67.9 | 63.3 | 59.4 | 55.9 | 52.8 | 47.5 | | | | | | | | | | | | | | | |
| 9 | 0.332 | 83 | 73.8 | 66.4 | 60.4 | 55.3 | 51.1 | 47.4 | 44.3 | 41.5 | 39.1 | 36.9 | 33.2 | 0.515 | 129 | 114 | 103 | 93.6 | 85.8 | 79.2 | 73.6 | 68.7 | 64.4 | 60.6 | 57.2 | 51.5 | | | | | | | | | | | | | | | |
| 10 | 0.357 | 89.3 | 79.3 | 71.4 | 64.9 | 59.5 | 54.9 | 51 | 47.6 | 44.6 | 42 | 39.7 | 35.7 | 0.555 | 139 | 123 | 111 | 101 | 92.5 | 85.4 | 79.3 | 74 | 69.4 | 65.3 | 61.7 | 55.5 | | | | | | | | | | | | | | | |
| 11 | 0.382 | 95.5 | 84.9 | 76.4 | 69.5 | 63.7 | 58.8 | 54.6 | 50.9 | 47.8 | 44.9 | 42.4 | 38.2 | 0.597 | 149 | 133 | 119 | 109 | 99.5 | 91.8 | 85.3 | 79.6 | 74.6 | 70.2 | 66.3 | 59.7 | | | | | | | | | | | | | | | |

Les quantités indiquées ne sont données qu'à titre indicatif. The given values should be used as a guide only. Die angegebenen Werte sind Richtwerte.
 Los cantidades se especifican solo a título indicativo. Le quantità indicate sono soltanto a titolo indicativo. FNB0585B



Settings are only indicated for your information.

How to read the calibration charts

Select the required volume per hectare in the column corresponding to the spacing between rows.



The values indicated in the calibration charts are given in litre per hectare.

Calculating the application rate per hectare:

- For insecticides:

Divide the product quantity to apply per hectare by the density of the non packed product.

Example:

Required application rate: 10 kg (22 lb) / ha.

Density of the non packed product: 1.5

Volume / ha = $10 / 1.5 = 6.66$ l (1.76 US gal) / ha

- For anti-slug pellets:

Divide the product quantity to apply per hectare by the correction factor of the product used.



- Correction factor for HELARION: 0.40
- Correction factor for MESUROL: 0.43


Example:

Required application rate: 5 kg (11 lb) / ha.

Correction factor for HELARION: 0.40

Volume / ha = $5 / 0.4 = 12.5$ l (3.30 US gal) / ha

Determine the drive gearwheel/driven gearwheel matching set according to the spacing between the seed drill rows and the required volume per hectare.

 Refer to the decal fitted on the machine.

Example:

Seed row spacing: 80 cm (2'7").

Required volume per hectare: 12.5 l (3.30 US gal) / ha.

| | | A : 20 / B : 16 | | | | | | | | | | | |
|----|---------|-----------------|------|------|------|------|------|------|------|------|------|------|------|
| | | <-----> cm | | | | | | | | | | | |
| | L. 100M | 25 | 30 | 35 | 40 | 45 | 50 | 55 | 60 | 65 | 70 | 75 | 80 |
| 0 | 0,0608 | 24,3 | 20,3 | 17,4 | 15,2 | 13,5 | 12,2 | 11,1 | 10,1 | 9,4 | 8,7 | 8,1 | 7,6 |
| 1 | 0,063 | 25,2 | 21,0 | 18,0 | 15,8 | 14,0 | 12,6 | 11,5 | 10,5 | 9,7 | 9,0 | 8,4 | 7,9 |
| 2 | 0,0656 | 26,2 | 21,9 | 18,7 | 16,4 | 14,6 | 13,1 | 11,9 | 10,9 | 10,1 | 9,4 | 8,7 | 8,2 |
| 3 | 0,0702 | 28,1 | 23,4 | 20,1 | 17,6 | 15,6 | 14,0 | 12,8 | 11,7 | 10,8 | 10,0 | 9,4 | 8,8 |
| 4 | 0,0752 | 30,1 | 25,1 | 21,5 | 18,8 | 16,7 | 15,0 | 13,7 | 12,5 | 11,6 | 10,7 | 10,0 | 9,4 |
| 5 | 0,0804 | 32,2 | 26,8 | 23,0 | 20,1 | 17,9 | 16,1 | 14,6 | 13,4 | 12,4 | 11,5 | 10,7 | 10,1 |
| 6 | 0,085 | 34,0 | 28,3 | 24,3 | 21,3 | 18,9 | 17,0 | 15,5 | 14,2 | 13,1 | 12,1 | 11,3 | 10,6 |
| 7 | 0,09 | 36,0 | 30,0 | 25,7 | 22,5 | 20,0 | 18,0 | 16,4 | 15,0 | 13,8 | 12,9 | 12,0 | 11,3 |
| 8 | 0,095 | 38,0 | 31,7 | 27,1 | 23,8 | 21,1 | 19,0 | 17,3 | 15,8 | 14,6 | 13,6 | 12,7 | 11,9 |
| 9 | 0,1006 | 40,2 | 33,5 | 28,7 | 25,2 | 22,4 | 20,1 | 18,3 | 16,8 | 15,5 | 14,4 | 13,4 | 12,6 |
| 10 | 0,104 | 41,6 | 34,7 | 29,7 | 26,0 | 23,1 | 20,8 | 18,9 | 17,3 | 16,0 | 14,9 | 13,9 | 13,0 |
| 11 | 0,1056 | 42,2 | 35,2 | 30,2 | 26,4 | 23,5 | 21,1 | 19,2 | 17,6 | 16,2 | 15,1 | 14,1 | 13,2 |

The volume per hectare closest to the required volume per hectare for a spacing between rows of 80 cm (2'7") is located in the chart for a **20** teeth drive gearwheel and **16** teeth driven gearwheel matching set.



The line where the required volume per hectare is located enables determining the outlet opening adjustment value.

Example:

| A : 20 / B : 16 | | | | | | | | | | | | | |
|-----------------|---------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|-------------|
| | L. 100M | <-----> cm | | | | | | | | | | | |
| | | 25 | 30 | 35 | 40 | 45 | 50 | 55 | 60 | 65 | 70 | 75 | 80 |
| 0 | 0,0608 | 24,3 | 20,3 | 17,4 | 15,2 | 13,5 | 12,2 | 11,1 | 10,1 | 9,4 | 8,7 | 8,1 | 7,6 |
| 1 | 0,063 | 25,2 | 21,0 | 18,0 | 15,8 | 14,0 | 12,6 | 11,5 | 10,5 | 9,7 | 9,0 | 8,4 | 7,9 |
| 2 | 0,0656 | 26,2 | 21,9 | 18,7 | 16,4 | 14,6 | 13,1 | 11,9 | 10,9 | 10,1 | 9,4 | 8,7 | 8,2 |
| 3 | 0,0702 | 28,1 | 23,4 | 20,1 | 17,6 | 15,6 | 14,0 | 12,8 | 11,7 | 10,8 | 10,0 | 9,4 | 8,8 |
| 4 | 0,0752 | 30,1 | 25,1 | 21,5 | 18,8 | 16,7 | 15,0 | 13,7 | 12,5 | 11,6 | 10,7 | 10,0 | 9,4 |
| 5 | 0,0804 | 32,2 | 26,8 | 23,0 | 20,1 | 17,9 | 16,1 | 14,6 | 13,4 | 12,4 | 11,5 | 10,7 | 10,1 |
| 6 | 0,085 | 34,0 | 28,3 | 24,3 | 21,3 | 18,9 | 17,0 | 15,5 | 14,2 | 13,1 | 12,1 | 11,3 | 10,6 |
| 7 | 0,09 | 36,0 | 30,0 | 25,7 | 22,5 | 20,0 | 18,0 | 16,4 | 15,0 | 13,8 | 12,9 | 12,0 | 11,3 |
| 8 | 0,095 | 38,0 | 31,7 | 27,1 | 23,8 | 21,1 | 19,0 | 17,3 | 15,8 | 14,6 | 13,6 | 12,7 | 11,9 |
| 9 | 0,1006 | 40,2 | 33,5 | 28,7 | 25,2 | 22,4 | 20,1 | 18,3 | 16,8 | 15,5 | 14,4 | 13,4 | 12,6 |
| 10 | 0,104 | 41,6 | 34,7 | 29,7 | 26,0 | 23,1 | 20,8 | 18,9 | 17,3 | 16,0 | 14,9 | 13,9 | 13,0 |
| 11 | 0,1056 | 42,2 | 35,2 | 30,2 | 26,4 | 23,5 | 21,1 | 19,2 | 17,6 | 16,2 | 15,1 | 14,1 | 13,2 |


For a volume to apply of 12.5 l (3.30 US gal) / ha, adjust index on **9**.

Adjusting the outlet opening

- Loosen knob (1).
- Position adjustment lever tip (2) on the required value.
- Tighten knob (1)



Refer to the adjustment chart to determine the outlet opening adjustment index according to the required volume per hectare and the spacing between the seed drill rows.




The values indicated in the adjustment chart are only for your information.

Adjusting the distribution shaft rotational speed




Refer to the adjustment chart to determine the drive gearwheel/driven gearwheel matching set according to the required volume per hectare and the spacing between the seed drill rows.

- Remove lynch pins (1).
- Position sprockets recommended in the adjustment charts in the adequate position:
 - Drive gearwheel (a).
 - Driven gearwheel (b).



Position non-used gearwheels on holder (2).

- Insert lynch pins (1).



Man. calibration



The flow can vary according to the product, the ambient temperature and the humidity level.




Proceed with regular calibration tests to check the fertilizer is properly adjusted.

After having preset the microgranulator, it is necessary to carry out a calibration test to know the real product volume applied.


Preparing the machine:

- Divert a product transfer tube (1) towards a container.
- Position a container (2) underneath the metering unit.



Checking flow rate:

- Travel a distance of 100 m (328'1") for the drive shaft (1) to rotate 64 times which corresponds to 100 m (328'1") linear.



- Weigh and deduct the container weight in order to assess the quantity collected.
- Compare the collected product quantity for one row with the value indicated in the chart column (1). Modify settings if necessary.



Values are given in litre.

| | L. 100M | A: 20 / B: 16 ←---→ cm | | | | | | |
|----|---------|---------------------------|------|------|------|------|------|------|
| | | 25 | 30 | 35 | 40 | 45 | 50 | 55 |
| 0 | 0,0608 | 24,3 | 20,3 | 17,4 | 15,2 | 13,5 | 12,2 | 11,1 |
| 1 | 0,063 | 25,2 | 21,0 | 18,0 | 15,8 | 14,0 | 12,6 | 11,5 |
| 2 | 0,0656 | 26,2 | 21,9 | 18,7 | 16,4 | 14,6 | 13,1 | 11,9 |
| 3 | 0,0702 | 28,1 | 23,4 | 20,1 | 17,6 | 15,6 | 14,0 | 12,8 |
| 4 | 0,0752 | 30,1 | 25,1 | 21,5 | 18,8 | 16,7 | 15,0 | 13,7 |
| 5 | 0,0804 | 32,2 | 26,8 | 23,0 | 20,1 | 17,9 | 16,1 | 14,6 |
| 6 | 0,085 | 34,0 | 28,3 | 24,3 | 21,3 | 18,9 | 17,0 | 15,5 |
| 7 | 0,09 | 36,0 | 30,0 | 25,7 | 22,5 | 20,0 | 18,0 | 16,4 |
| 8 | 0,095 | 38,0 | 31,7 | 27,1 | 23,8 | 21,1 | 19,0 | 17,3 |
| 9 | 0,1006 | 40,2 | 33,5 | 28,7 | 25,2 | 22,4 | 20,1 | 18,3 |
| 10 | 0,104 | 41,6 | 34,7 | 29,7 | 26,0 | 23,1 | 20,8 | 18,9 |
| 11 | 0,1056 | 42,2 | 35,2 | 30,2 | 26,4 | 23,5 | 21,1 | 19,2 |


Machine use

Filling the hopper




Wear waterproof clothing adapted for handling phytosanitary products (gloves, goggles, boots, mask).

- Lower the machine on the ground.
- Release hook (1).
- Open and lock the lid.




Make sure that sieve (1) is well installed.

- Empty the bag of microgranulates over the sieve.
- Close the lid and lock it.



Emptying the hopper

- Position a container close to the emptying hatch.
- Push lever (1) upwards to open the emptying hatch.
- Remove all seeds.
- Close the hatch.
- Empty transfer tubes (by shaking them).



Supply shut-off for a few rows

The 2 spacers (2) and (3) allow shutting off the product supply of 1 to 3 rows.


- Remove bolts (1).
- Install the spacer or spacers.



Spacer (2) enables shutting-off the supply to one row.

Spacer (3) enables shutting-off the supply to 2 rows.

- Reinstall bolts (1).
 - Torque: 2.3 daN m (17 lbf ft).



■ Checking

During filling, rotate drive wheel by hand to check proper functioning of the microgranulator and product flow. If no product comes out of the application system, this indicates there is a problem in the setting or that the supply tube is clogged. Search source of malfunction and remedy the problem prior to resuming sowing operation.


■ Maintenance

Cleaning the machine



Do not clean the microgranulator with water.

- Remove plug (1).
- Clean the venturi using compressed air.
- Reinstall plug (1).
- Repeat procedure on all other venturis.



Check (Each time the machine is used)

Check wear of foils to prevent sealing loss and overdosage.

■ Trouble shooting guide

| ■ Problem | ■ Cause | ■ Remedy |
|----------------------------------|--|--|
| Incorrect distribution rotation. | Metering unit encrusted. | Clean metering unit. |
| Irregular drive. | Friction point in metering unit. | Check the condition of the drive (condition of gears, sprockets, chains and tensioners). |
| Uneven spreading. | Metering unit encrusted. | Clean metering unit. |
| | Friction point in metering unit. | Check the condition of the drive (condition of gears, sprockets, chains and tensioners). |
| No distribution. | Pipes blocked. | Clear or replace the tube. |
| | Too tight a bend in the seed delivery pipe. | Shorten the pipe to eliminate the bend. |
| | Blocked venturi. | Clean the venturi. |
| Sealing loss. | Worn foils. | Replace foils. |
| Clogging inside the hopper. | Product remained too long inside the hopper during wet weather | Never leave microgranulates inside the hopper or they will form compact blocks. |

14. Fertilizer unit

For the following models:

- M2M08RT000AG03

Kit no. 1677058

Fertilizer 8 rows with 1350 L (356 US gal) hopper and applicators with standard Suffolk coulters.


Kit no. 1677059

Fertilizer 8 rows with 1350 L (356 US gal) hopper and applicators with non-stop Suffolk coulters.

Kit no. 1677060

Fertilizer 8 rows with 1350 L (356 US gal) hopper and applicators with non-top disk coulters.

■ Location of safety decals




■ Description of safety decals

Risk of falling (1)

Do not ride on the machine when it is moving. There is a risk of falling.



■ Description and glossary



- 1 : Hopper
- 3 : Metering unit
- 5 : Upper foil
- 7 : Applicator with non stop disks
- 9 : Applicator with standard couler

- 2 : Agitator
- 4 : Spline opening lever
- 6 : Distribution
- 8 : Applicator with non stop Suffolk couler

■ Adjusting the seed rate

Calibration chart

| | Kg/100m | E (cm) | | | | | | | | |
|----|---------|--------|------|------|------|-----|-----|-----|-----|-----|
| | | 40 | 45 | 50 | 55 | 60 | 65 | 70 | 75 | 80 |
| 20 | 0.537 | 134 | 119 | 107 | 98 | 89 | 83 | 77 | 72 | 67 |
| 22 | 0.617 | 154 | 137 | 123 | 112 | 103 | 95 | 88 | 82 | 77 |
| 24 | 0.698 | 175 | 155 | 140 | 127 | 116 | 107 | 100 | 93 | 87 |
| 26 | 0.779 | 195 | 173 | 156 | 142 | 130 | 120 | 111 | 104 | 97 |
| 28 | 0.860 | 215 | 191 | 172 | 156 | 143 | 132 | 123 | 115 | 107 |
| 30 | 0.941 | 235 | 209 | 188 | 171 | 157 | 145 | 134 | 125 | 118 |
| 32 | 1.021 | 255 | 227 | 204 | 186 | 170 | 157 | 146 | 136 | 128 |
| 34 | 1.102 | 276 | 245 | 220 | 200 | 184 | 170 | 157 | 147 | 138 |
| 36 | 1.183 | 296 | 263 | 237 | 215 | 197 | 182 | 169 | 158 | 148 |
| 38 | 1.264 | 316 | 281 | 253 | 230 | 211 | 194 | 181 | 169 | 158 |
| 40 | 1.345 | 336 | 299 | 269 | 244 | 224 | 207 | 192 | 179 | 168 |
| 42 | 1.425 | 356 | 317 | 285 | 259 | 238 | 219 | 204 | 190 | 178 |
| 44 | 1.506 | 377 | 335 | 301 | 274 | 251 | 232 | 215 | 201 | 188 |
| 46 | 1.587 | 397 | 353 | 317 | 289 | 265 | 244 | 227 | 212 | 198 |
| 48 | 1.668 | 417 | 371 | 334 | 303 | 278 | 257 | 238 | 222 | 208 |
| 50 | 1.749 | 437 | 389 | 350 | 318 | 291 | 269 | 250 | 233 | 219 |
| 52 | 1.829 | 457 | 407 | 366 | 333 | 305 | 281 | 261 | 244 | 229 |
| 54 | 1.910 | 478 | 424 | 382 | 347 | 318 | 294 | 273 | 255 | 239 |
| 56 | 1.991 | 498 | 442 | 398 | 362 | 332 | 306 | 284 | 265 | 249 |
| 58 | 2.072 | 518 | 460 | 414 | 377 | 345 | 319 | 296 | 276 | 259 |
| 60 | 2.153 | 538 | 478 | 431 | 391 | 359 | 331 | 308 | 287 | 269 |
| 62 | 2.233 | 558 | 496 | 447 | 406 | 372 | 344 | 319 | 298 | 279 |
| 64 | 2.314 | 579 | 514 | 463 | 421 | 386 | 356 | 331 | 309 | 289 |
| 66 | 2.395 | 599 | 532 | 479 | 435 | 399 | 368 | 342 | 319 | 299 |
| 68 | 2.476 | 619 | 550 | 495 | 450 | 413 | 381 | 354 | 330 | 309 |
| 20 | 1.106 | 276 | 246 | 221 | 201 | 184 | 170 | 158 | 147 | 138 |
| 22 | 1.294 | 323 | 287 | 259 | 235 | 216 | 199 | 185 | 172 | 162 |
| 24 | 1.482 | 370 | 329 | 296 | 269 | 247 | 228 | 212 | 198 | 185 |
| 26 | 1.670 | 418 | 371 | 334 | 304 | 278 | 257 | 239 | 223 | 209 |
| 28 | 1.858 | 465 | 413 | 372 | 338 | 310 | 286 | 265 | 248 | 232 |
| 30 | 2.047 | 512 | 455 | 409 | 372 | 341 | 315 | 292 | 273 | 256 |
| 32 | 2.235 | 559 | 497 | 447 | 406 | 372 | 344 | 319 | 298 | 279 |
| 34 | 2.423 | 606 | 538 | 485 | 441 | 404 | 373 | 346 | 323 | 303 |
| 36 | 2.611 | 653 | 580 | 522 | 475 | 435 | 402 | 373 | 348 | 326 |
| 38 | 2.799 | 700 | 622 | 560 | 509 | 467 | 431 | 400 | 373 | 350 |
| 40 | 2.988 | 747 | 664 | 598 | 543 | 498 | 460 | 427 | 398 | 373 |
| 42 | 3.176 | 794 | 706 | 635 | 577 | 529 | 489 | 454 | 423 | 397 |
| 44 | 3.364 | 841 | 748 | 673 | 612 | 561 | 518 | 481 | 449 | 420 |
| 46 | 3.552 | 888 | 789 | 710 | 646 | 592 | 546 | 507 | 474 | 444 |
| 48 | 3.740 | 935 | 831 | 748 | 680 | 623 | 575 | 534 | 499 | 468 |
| 50 | 3.929 | 982 | 873 | 786 | 714 | 655 | 604 | 561 | 524 | 491 |
| 52 | 4.117 | 1029 | 915 | 823 | 748 | 686 | 633 | 588 | 549 | 515 |
| 54 | 4.305 | 1076 | 957 | 861 | 783 | 717 | 662 | 615 | 574 | 538 |
| 56 | 4.493 | 1123 | 998 | 899 | 817 | 749 | 691 | 642 | 599 | 562 |
| 58 | 4.681 | 1170 | 1040 | 936 | 851 | 780 | 720 | 669 | 624 | 585 |
| 60 | 4.870 | 1217 | 1082 | 974 | 885 | 812 | 749 | 696 | 649 | 609 |
| 62 | 5.058 | 1264 | 1124 | 1012 | 920 | 843 | 778 | 723 | 674 | 632 |
| 64 | 5.246 | 1311 | 1166 | 1049 | 954 | 874 | 807 | 749 | 699 | 656 |
| 66 | 5.434 | 1359 | 1208 | 1087 | 988 | 906 | 836 | 776 | 725 | 679 |
| 68 | 5.622 | 1406 | 1249 | 1124 | 1022 | 937 | 865 | 803 | 750 | 703 |

Σ Kg /Ha



The values indicated in the adjustment chart are only for your information.





Reading the chart

Select the required application rate in the column corresponding to the spacing between the seed drill rows.

Example:

Seed row spacing: 75 cm (2'5").

Required application rate: 190 kg (419 lb) / ha.

| |  |  Kg.... 100M |  E (cm) | | | | | | | | |
|----|--|---|--|-----|-----|-----|-----|-----|-----|-----|-----|
| | | | 40 | 45 | 50 | 55 | 60 | 65 | 70 | 75 | 80 |
| 20 | | 0.537 | 134 | 119 | 107 | 98 | 89 | 83 | 77 | 72 | 67 |
| 22 | | 0.617 | 154 | 137 | 123 | 112 | 103 | 95 | 88 | 82 | 77 |
| 24 | | 0.698 | 175 | 155 | 140 | 127 | 116 | 107 | 100 | 93 | 87 |
| 26 | | 0.779 | 195 | 173 | 156 | 142 | 130 | 120 | 111 | 104 | 97 |
| 28 | | 0.860 | 215 | 191 | 172 | 156 | 143 | 132 | 123 | 115 | 107 |
| 30 | | 0.941 | 235 | 209 | 188 | 171 | 157 | 145 | 134 | 125 | 118 |
| 32 | | 1.021 | 255 | 227 | 204 | 186 | 170 | 157 | 146 | 136 | 128 |
| 34 | | 1.102 | 276 | 245 | 220 | 200 | 184 | 170 | 157 | 147 | 138 |
| 36 | | 1.183 | 296 | 263 | 237 | 215 | 197 | 182 | 169 | 158 | 148 |
| 38 | | 1.264 | 316 | 281 | 253 | 230 | 211 | 194 | 181 | 169 | 158 |
| 40 | | 1.345 | 336 | 299 | 269 | 244 | 224 | 207 | 192 | 179 | 168 |
| 42 |  1 | 1.425 | 356 | 317 | 285 | 259 | 238 | 219 | 204 | 190 | 178 |
| 44 | | 1.506 | 377 | 335 | 301 | 274 | 251 | 232 | 215 | 201 | 188 |
| 46 | | 1.587 | 397 | 353 | 317 | 289 | 265 | 244 | 227 | 212 | 198 |
| 48 | | 1.668 | 417 | 371 | 334 | 303 | 278 | 257 | 238 | 222 | 208 |
| 50 | | 1.749 | 437 | 389 | 350 | 318 | 291 | 269 | 250 | 233 | 219 |
| 52 | | 1.829 | 457 | 407 | 366 | 333 | 305 | 281 | 261 | 244 | 229 |
| 54 | | 1.910 | 478 | 424 | 382 | 347 | 318 | 294 | 273 | 255 | 239 |
| 56 | | 1.991 | 498 | 442 | 398 | 362 | 332 | 306 | 284 | 265 | 249 |
| 58 | | 2.072 | 518 | 460 | 414 | 377 | 345 | 319 | 296 | 276 | 259 |
| 60 | | 2.153 | 538 | 478 | 431 | 391 | 359 | 331 | 308 | 287 | 269 |
| 62 | | 2.233 | 558 | 496 | 447 | 406 | 372 | 344 | 319 | 298 | 279 |
| 64 | | 2.314 | 579 | 514 | 463 | 421 | 386 | 356 | 331 | 309 | 289 |
| 66 | | 2.395 | 599 | 532 | 479 | 435 | 399 | 368 | 342 | 319 | 299 |
| 68 | | 2.476 | 619 | 550 | 495 | 450 | 413 | 381 | 354 | 330 | 309 |

The line on which the required application rate is located enables determining the index (1) and the distribution shaft speed (2).

Example:


For an application rate of 190 kg (419 lb) / ha, adjust index on 42 and use gearwheel enabling to obtain a distribution shaft speed ratio of 13 rotations for 100 m (328').

Adjusting the spline opening

The spline opening is adjusted by means of crank (1).



Refer to adjustment chart to determine the spline opening adjustment index according to the required application rate and the spacing between the seed drill rows.





Adjusting the distribution shaft rotational speed



Refer to the adjustment chart to determine the drive gearwheel direction of mount according to the required application rate and the spacing between the seed drill rows.

- Loosen wing nut (1).
- Pivot tensioner (4).
- Remove spacer (2).
- Move the double gearwheel (3) and chain to the required position:
 - Position (a): Distribution shaft speed of 13 revs for a travel of 100 m (328').
 - Position (b): Distribution shaft speed of 30 revs for a travel of 100 m (328').
- Reinstall wedge (2) according to double gearwheel (3) position.
- Pivot tensioner (4).
- Tighten the wing nut (1).



Man. calibration



The flow can vary according to the fertilizer type, the ambient temperature and the humidity level.




Proceed with regular calibration tests to check the fertilizer is properly adjusted.

After having preset the fertilizer, it is necessary to carry out a calibration test in order to assess the real fertilizer dose supplied.


Preparing the machine:

- Disconnect tube (1) from one of the metering units.
- Position a container (2) underneath the metering unit.
- Open hatch (3).



Checking flow rate:

- Travel a distance of 100 m (328'1") for the drive shaft (1) to rotate 64 times which corresponds to 100 m (328'1") linear.
- Weigh and deduct the container weight in order to assess the quantity collected.



- Compare the collected product quantity for one row with the value indicated in the chart column (1). Modify settings if necessary.

| | Kg/100m | E (cm) | | | | | | | | | |
|----|---------|--------|------|------|------|-----|-----|-----|-----|-----|--|
| | | 40 | 45 | 50 | 55 | 60 | 65 | 70 | 75 | 80 | |
| 20 | 0.537 | 134 | 119 | 107 | 98 | 89 | 83 | 77 | 72 | 67 | |
| 22 | 0.617 | 154 | 137 | 123 | 112 | 103 | 95 | 88 | 82 | 77 | |
| 24 | 0.698 | 175 | 155 | 140 | 127 | 116 | 107 | 100 | 93 | 87 | |
| 26 | 0.778 | 195 | 173 | 156 | 142 | 130 | 120 | 111 | 104 | 97 | |
| 28 | 0.860 | 215 | 191 | 172 | 156 | 143 | 132 | 123 | 115 | 107 | |
| 30 | 0.941 | 235 | 209 | 188 | 171 | 157 | 145 | 134 | 125 | 118 | |
| 32 | 1.021 | 255 | 227 | 204 | 186 | 170 | 157 | 146 | 136 | 128 | |
| 34 | 1.102 | 276 | 245 | 220 | 200 | 184 | 170 | 157 | 147 | 138 | |
| 36 | 1.183 | 296 | 263 | 237 | 215 | 197 | 182 | 169 | 158 | 148 | |
| 38 | 1.264 | 316 | 281 | 253 | 230 | 211 | 194 | 181 | 169 | 158 | |
| 40 | 1.345 | 336 | 299 | 269 | 244 | 224 | 207 | 192 | 179 | 168 | |
| 42 | 1.425 | 356 | 317 | 285 | 259 | 238 | 219 | 204 | 190 | 178 | |
| 44 | 1.506 | 377 | 335 | 301 | 274 | 251 | 232 | 215 | 201 | 188 | |
| 46 | 1.587 | 397 | 353 | 317 | 289 | 265 | 244 | 227 | 212 | 198 | |
| 48 | 1.668 | 417 | 371 | 334 | 303 | 278 | 257 | 238 | 222 | 208 | |
| 50 | 1.749 | 437 | 389 | 350 | 318 | 291 | 269 | 250 | 233 | 219 | |
| 52 | 1.829 | 457 | 407 | 366 | 333 | 305 | 281 | 261 | 244 | 229 | |
| 54 | 1.910 | 478 | 424 | 382 | 347 | 318 | 294 | 273 | 255 | 239 | |
| 56 | 1.991 | 498 | 442 | 398 | 362 | 332 | 306 | 284 | 265 | 249 | |
| 58 | 2.072 | 518 | 460 | 414 | 377 | 345 | 319 | 296 | 276 | 259 | |
| 60 | 2.153 | 538 | 478 | 431 | 391 | 359 | 333 | 308 | 287 | 269 | |
| 62 | 2.233 | 558 | 496 | 447 | 406 | 372 | 344 | 319 | 298 | 279 | |
| 64 | 2.314 | 579 | 514 | 463 | 421 | 386 | 356 | 331 | 309 | 289 | |
| 66 | 2.395 | 599 | 532 | 479 | 435 | 399 | 368 | 342 | 319 | 299 | |
| 68 | 2.476 | 619 | 550 | 495 | 450 | 413 | 381 | 354 | 330 | 309 | |
| 20 | 1.106 | 276 | 246 | 221 | 201 | 184 | 170 | 158 | 147 | 138 | |
| 22 | 1.284 | 323 | 287 | 259 | 235 | 216 | 199 | 185 | 172 | 162 | |
| 24 | 1.462 | 370 | 329 | 296 | 269 | 247 | 228 | 212 | 198 | 185 | |
| 26 | 1.670 | 418 | 371 | 334 | 304 | 278 | 257 | 239 | 223 | 209 | |
| 28 | 1.858 | 465 | 413 | 372 | 338 | 310 | 286 | 265 | 248 | 232 | |
| 30 | 2.047 | 512 | 455 | 409 | 372 | 341 | 315 | 292 | 273 | 256 | |
| 32 | 2.235 | 559 | 491 | 447 | 406 | 372 | 344 | 319 | 298 | 279 | |
| 34 | 2.423 | 606 | 538 | 485 | 441 | 404 | 373 | 346 | 323 | 303 | |
| 36 | 2.611 | 653 | 580 | 522 | 475 | 435 | 402 | 373 | 348 | 326 | |
| 38 | 2.799 | 700 | 627 | 560 | 509 | 461 | 431 | 400 | 373 | 350 | |
| 40 | 2.988 | 747 | 664 | 598 | 543 | 498 | 460 | 427 | 398 | 373 | |
| 42 | 3.176 | 794 | 706 | 635 | 577 | 529 | 489 | 454 | 423 | 397 | |
| 44 | 3.364 | 841 | 748 | 673 | 612 | 561 | 518 | 481 | 449 | 420 | |
| 46 | 3.552 | 888 | 789 | 710 | 646 | 592 | 546 | 507 | 474 | 444 | |
| 48 | 3.740 | 935 | 831 | 748 | 680 | 623 | 575 | 534 | 499 | 468 | |
| 50 | 3.929 | 982 | 873 | 786 | 714 | 655 | 604 | 561 | 524 | 491 | |
| 52 | 4.117 | 1029 | 915 | 823 | 748 | 686 | 633 | 588 | 549 | 515 | |
| 54 | 4.305 | 1076 | 957 | 861 | 783 | 717 | 662 | 615 | 574 | 538 | |
| 56 | 4.493 | 1123 | 998 | 899 | 817 | 749 | 691 | 642 | 599 | 562 | |
| 58 | 4.681 | 1170 | 1040 | 936 | 851 | 780 | 720 | 669 | 624 | 585 | |
| 60 | 4.870 | 1217 | 1082 | 974 | 885 | 812 | 749 | 696 | 649 | 609 | |
| 62 | 5.058 | 1264 | 1124 | 1012 | 920 | 843 | 778 | 723 | 674 | 632 | |
| 64 | 5.246 | 1311 | 1166 | 1049 | 954 | 874 | 807 | 749 | 699 | 656 | |
| 66 | 5.434 | 1358 | 1208 | 1087 | 988 | 905 | 836 | 776 | 725 | 679 | |
| 68 | 5.622 | 1406 | 1249 | 1124 | 1022 | 937 | 865 | 803 | 750 | 703 | |


Σ Kg / Ha

■ Adjusting the applicators

Non stop disk applicators

Lateral adjustment

The applicator (D) is factory offset with regards to the seeding line by approximately 50 mm (1.97").




Adjusting the application depth



The seeding unit setting must be adjusted according to the sowing conditions (Soil preparation and nature).

- Raise the machine.
- Remove lynch pin (1) and pin (2).
- Insert pin (2) in one of bracket (3) holes to set the required working depth.
- Insert and lock lynch pin (1).


Adjust all applicators to the same setting.



Adjusting the plates

- Loosen nut (1).
- Set plate (2) as close as possible to the disks but without touching it. Rotate disk once to check that it is not in contact.
- Tighten nut (1).


Repeat procedure on each applicator.



Applicators with standard coulters

Lateral adjustment

The applicator (D) is factory offset with regards to the seeding line by approximately 50 mm (1.97").




Adjusting the application depth



The seeding unit setting must be adjusted according to the sowing conditions (Soil preparation and nature).

- Raise the machine.
- Loosen bolts (1).
- Adjust coulter height to obtain the required working depth.
- Tighten screws (1).


Adjust all applicators to the same setting.



Non stop coulter applicators

Lateral adjustment

The applicator (D) is factory offset with regards to the seeding line by approximately 50 mm (1.97”).




Adjusting the application depth



The seeding unit setting must be adjusted according to the sowing conditions (Soil preparation and nature).

- Raise the machine.
- Remove lynch pin (1) and pin (2).
- Insert pin (2) in one of bracket (3) holes to set the required working depth.
- Insert and lock lynch pin (1).


Adjust all applicators to the same setting.



■ Machine use

Disengaging the fertilizer

- Remove lynch pin (1).
- Use spacer (3) to stop spacer (2) from moving sideways.



Safety

When an incident occurs, the safety bolt (3) shears causing the metering unit to stop.

- Use a punch to remove the remaining shear bolt parts.



Hole (4) of larger diameter enables easier removal of the remaining shear bolt parts.

- Replace the components.




A full set of replacement components (5) is positioned on the machine.



Nut (1) **Part no. 80200640.**

Washer (2) **Part no. 80250611.**


Safety bolt (3) **Part no. N03481B0.**



Supply shut-off for a few rows

It is possible to shut-off the fertilizer supply to certain rows.

- Position (a): Distribution open.
- Position (b): Distribution shut-off.




Agitator adjustment

- Remove the sieve fitted in the hopper to access agitators.

When the distribution is not used, place agitator (1) in high position (a).

When the distribution is used, place agitator (1) in low position (b).




Filling the hopper

- Lower the machine on the ground.

If the machine is fitted with an access platform:

- Lower platform using lever (1).



- Raise protection cover (1).



Make sure that sieve (2) is well installed.



Before filling, check that there is no foreign matter in the hopper.

- After filling, lower and attach the protection cover.

If the machine is fitted with an access platform:

- Raise access platform.



The machine can be fitted with a loading screw for easier hopper filling.



- Loading screw for fertilizer equipped with 1350 L (356 US gal) hoppers **Kit no. 1677227.**

Emptying the hopper

- Place a container (1) underneath the hatch that does not supply a metering unit.
- Open hatch.



■ Checking

During filling, rotate drive wheel by hand to check proper functioning of the fertilizer and product flow. If no product comes out of the applicator, this indicates there is a problem in the setting or that the applicator is clogged. Search source of malfunction and remedy the problem prior to resuming sowing operation.

■ Maintenance

Cleaning the machine




Fertilisers used cause corrosion in the machine and rapid deterioration.


Remove the metering unit assembly to clean the machine completely.

Removing the metering units


- Disengage the fertilizer.
 - Remove lynch pin (1).
 - Slide spacer (2) to free distribution drive shaft.




- Loosen knurled knob (1) on each metering unit.




- Remove the unit.
- Clean the unit using compressed air.




- Reassemble the unit.



- Tighten knurled nuts *1 on each metering unit.




- Slide spacer (2).
- Reinstall lynch pin (1).



Lubrication (Every 50 hours)

- Eccentrics.



■ Trouble shooting guide

| ■ Problem | ■ Cause | ■ Remedy |
|----------------------------------|---|--|
| Incorrect distribution rotation. | Metering unit encrusted. | Clean metering unit. |
| Irregular drive. | Friction point in metering unit. | Check the condition of the drive (condition of gears, sprockets, chains and tensioners). |
| Uneven spreading. | Too tight a bend in the seed delivery pipe. | Shorten the pipe to eliminate the bend. |
| | Moisture problems. | Damp fertiliser will not flow, do not use fertiliser unless it is dry. |
| No distribution. | Applicators blocked. | Clean the applicators. |
| | Pipes blocked. | Clear or replace the tube. Do not work when the tube inside are too wet. |
| | The safety system shear bolt has sheared. | Replace the components. |
| | Distributions disengaged. | Check that the lynch pin is in position and locked |

15. Low flow kit for the fertilizer unit

Kit no. 1677228

This equipment allows reducing the flow for low application rate fertilisation.



Install calibration chart decal.

Part no. K3602200.

| | | | E (cm) | | | | | | | | |
|--|----|-------|--------|-----|-----|-----|-----|-----|-----|-----|-----|
| | | | 40 | 45 | 50 | 55 | 60 | 65 | 70 | 75 | 80 |
| | 20 | 0.347 | 87 | 77 | 69 | 63 | 58 | 53 | 50 | 46 | 43 |
| | 22 | 0.397 | 99 | 88 | 79 | 72 | 66 | 61 | 57 | 53 | 50 |
| | 24 | 0.448 | 112 | 99 | 90 | 81 | 75 | 69 | 64 | 60 | 56 |
| | 26 | 0.498 | 125 | 111 | 100 | 91 | 83 | 77 | 71 | 66 | 62 |
| | 28 | 0.549 | 137 | 122 | 110 | 100 | 91 | 84 | 78 | 73 | 69 |
| | 30 | 0.600 | 150 | 133 | 120 | 109 | 100 | 92 | 86 | 80 | 75 |
| | 32 | 0.650 | 163 | 144 | 130 | 118 | 108 | 100 | 93 | 87 | 81 |
| | 34 | 0.701 | 175 | 156 | 140 | 127 | 117 | 108 | 100 | 93 | 88 |
| | 36 | 0.751 | 188 | 167 | 150 | 137 | 125 | 116 | 107 | 100 | 94 |
| | 38 | 0.802 | 200 | 178 | 160 | 146 | 134 | 123 | 115 | 107 | 100 |
| | 40 | 0.853 | 213 | 189 | 171 | 155 | 142 | 131 | 122 | 114 | 107 |
| | 42 | 0.903 | 226 | 201 | 181 | 164 | 151 | 139 | 129 | 120 | 113 |
| | 44 | 0.954 | 238 | 212 | 191 | 173 | 159 | 147 | 136 | 127 | 119 |
| | 46 | 1.004 | 251 | 223 | 201 | 183 | 167 | 155 | 143 | 134 | 126 |
| | 48 | 1.055 | 264 | 234 | 211 | 192 | 176 | 162 | 151 | 141 | 132 |
| | 50 | 1.106 | 276 | 246 | 221 | 201 | 184 | 170 | 158 | 147 | 138 |
| | 52 | 1.156 | 289 | 257 | 231 | 210 | 193 | 178 | 165 | 154 | 145 |
| | 54 | 1.207 | 302 | 268 | 241 | 219 | 201 | 186 | 172 | 161 | 151 |
| | 56 | 1.257 | 314 | 279 | 251 | 229 | 210 | 193 | 180 | 168 | 157 |
| | 58 | 1.308 | 327 | 291 | 262 | 238 | 218 | 201 | 187 | 174 | 163 |
| | 60 | 1.359 | 340 | 302 | 272 | 247 | 226 | 209 | 194 | 181 | 170 |
| | 62 | 1.409 | 352 | 313 | 282 | 256 | 235 | 217 | 201 | 188 | 176 |
| | 64 | 1.460 | 365 | 324 | 292 | 265 | 243 | 225 | 209 | 195 | 182 |
| | 66 | 1.510 | 378 | 336 | 302 | 275 | 252 | 232 | 216 | 201 | 189 |
| | 68 | 1.561 | 390 | 347 | 312 | 284 | 260 | 240 | 223 | 208 | 195 |

K3602200


Σ Kg / Ha

16. Filling auger

Kit no. 1677227


Loading screw for fertilizer equipped with 1350 L (356 US gal) hoppers.

The machine can be fitted with a loading screw for easier hopper filling.




■ Hydraulic connections

Connect hydraulic hoses to the tractor double acting spool valve.




■ Machine use

Lever (1) linked to the hatch enables altering the screw flow.



Lever (1) enables directing the fertilizer flow to the right or left for an even hopper filling.



■ Maintenance


Cleaning the machine



Fertilisers used cause corrosion in the machine and rapid deterioration.

In case of a long interruption, or at the end of the season, the container must be fully emptied.

- Release hook (1).
- Open hatch (2).
- Empty remaining fertilizer and clean container thoroughly.
- Shut hatch (2).
- Lock hook (1).



17. Distribution disks

| Hole diameter (mm) | Number of holes | | | | | | | | | | | | |
|--------------------|-----------------|-----------|-----------------------|-----------|----------|-----------|----------|----------|-----------|-----------|-----------|----------|-----------|
| | 12 | 18 | 22 | 27 | 30 | 31 | 33 | 35 | 48 | 54 | 70 | 80 | 100 |
| 0.8 | | | | | | | | | | | | | N1501051* |
| 1.25 | | | | | | | | | K3601440* | | N1500431* | | N00849B0* |
| 1.5 | N1506320 | N04286B0* | | | | | | | | | | | |
| 1.75 | | | | | | | | | | | | | N1500701 |
| 2.1 | | | N00856B0* N1503810 | | | N00845B0* | | | | | | | |
| 2.5 | N04343B0 | N00846B0 | N04341B0 | N1503140 | | | | | N02951B0 | | N02851B0 | N1502170 | |
| 3 | | N04318B0 | | N1500670* | | | | | | N1500061* | | | |
| 3.5 | N1502090 | N00847B0 | N03840B0 | N03828B0 | | | N00855B0 | N1503380 | N00848B0 | | N04342B0 | N1501591 | N04293B0 |
| 4 | | | | | | | | | | | | | |
| 4.5 | | | N00851B0 | N00843B0 | | | N04107B0 | N1503390 | N04305B0 | N1500681 | N00850B0 | | |
| 5 | | | N02511B0 | N00905B0 | | | | N1503400 | | | | | |
| 5.5 | | | N00852B0 | N00844B0 | | | N04282B0 | N1503410 | N1503130 | N1500691 | | | |
| 7 | | | | | N1500340 | | | | | | | | |

* Without agitator blades and plan additional spacer **BNB0048** to install in the casing.



Other types of disks available. Contact your Kuhn dealer.

18. Belt and pulley units

Belt and pulley assemblies are available to adapt the blower speed to the tractor PTO speed.

Kit no. 1677287

Belt and pulley assembly for tractors with a pto speed of 470 min^{-1} .

Kit no. 1676731

Belt and pulley assembly for tractors with a pto speed of 870 min^{-1} .

Kit no. 1676738

Belt and pulley assembly for tractors with a pto speed of 1000 min^{-1} .




19. Rear PTO output stub

Kit no. 1676730

This equipment enables creating a drive source for driving another device.

Example: Driving a diaphragm pump for a fluid fertilizer placement system.



20. Hydraulic blower drive

Kit no. 1676545


This equipment enables driving the blower at a constant speed whatever the tractor engine speed.

When the seed drill is combined with a soil preparation tool driven by the tractor PTO, this equipment allows blower rotation when disengaging the PTO or when the torque limiter is released.

Kit no. 1676546

Hydraulic hose extension.

This equipment may be necessary when the machine is combined with a soil preparation tool.



■ Preparing the tractor

The tractor must be equipped with:

- 1 double acting valve or single acting valve with free return to supply the hydraulic valve bank.

■ Technical specifications




**The tractor must be fitted with load sensing.
In case of doubt, refer to the tractor operator's manual and contact the official distributor of the concerned tractor brand**

Recommendations

| | |
|--|--------------------|
| Required oil flow | 40 - 45 l/min |
| Maximum pressure authorized | 200 bar (2900 psi) |
| Maximum pressure authorized on the free return | 10 bar (145 psi) |

Hydraulic connections

- Connect the hydraulic hose (1) on the blower to a single acting or double acting valve.
- Connect the hydraulic hose (2) of the blower to a free return on the tractor. If the tractor is not fitted with a FLAT FACE coupler, use the one supplied with the equipment to connect hose (2) to the tractor free return.



Available as spare parts:




- "FLAT FACE" coupler with M30 thread (Part no. A4074042).
- "FLAT FACE" coupler with M22 thread (Part no. A4074041).

After connecting the hoses, check that there is no risk of catching them during operation.

Suction adjustment

Adjustment procedure:

- Fully turn thumbwheel (1) clockwise.
- Operate hydraulic valve that supplies the blower hydraulic drive motor.
- Turn thumbwheel (1) counterclockwise to increase the suction value.




Suction must be comprised between 50 and 65 (or cm water column).



- A lower suction value can cause misses on the seeding line.
- A higher suction value can cause doubles on the seeding line and premature disk wear.

The measure must be made with disks fitted, seeds engaged on the disks.





For a precise measure of the suction value, a vacuumeter must be fitted on the machine.
Kit no. 1677223.

21. Vacuumeter

Kit no. 1677223

The vacuumeter enables determining precisely the suction value at disk hole level.



 The vacuumeter calibration is factory checked.

22. HECTOR 3000 electronic control box

Kit no. 1676822

The HECTOR 3000 electronic control box is used to::

- Count the area sown (daily and total counter).
- Indicate forward speed.



23. Passage control box kit KMS208

Kit no. 1676659

The passage control box enables controlling seed passage.



24. Sowing control box kit KMS412

Kit no. 1676428B

The sowing control box enables controlling the seed population.



25. Electronic disengagement kit

Kit no. 1677299

The KMD112 disengagement control box allows electrical disengagement of one or several rows at any time.




The KMD112 disengagement control box can only function in combination with control boxes KMS208 or KMS412.

26. 65 x 400 depth control wheels

Kit no. 1676520


This equipment may be required for sowing crops that need little spacing between rows.



27. 45 mm (1.8 ") spacer and 5 mm (0.2") levelling pad

Kit no. 1677293


This equipment may be necessary to combine certain optional equipments.



28. 82 mm (3.2") spacer and 5 mm (0.2") levelling pad

Kit no. 1676792

This equipment may be necessary to combine certain optional equipments.



29. Mechanical hectare counter

Kit no. 1676821

The mechanical hectare counter shows the area sown.

■ Machine use

The chart indicates the number of rotations made by the hexagonal drive shaft to sow one hectare according to the number of rows used and the spacing between rows.


To determine the area sown:

- Find the value in the chart that corresponds to the number of rows used and the spacing between rows.

Example:

Number of rows: 12.

Seed row spacing: 45 cm (1'5").



| | Distance entre rangs (cm) | | | | | | | | | | | |
|---|-----------------------------|------|------|------|------|------|------|------|------|------|------|------|
| | Distances between rows (cm) | | | | | | | | | | | |
| | 25 | 33 | 38 | 40 | 45 | 50 | 55 | 60 | 70 | 75 | 80 | |
| Number of rows Numéro de files Reihenzahl | 3 | 8587 | 6505 | 5649 | 5367 | 4770 | 4293 | 3903 | 3578 | 3067 | 2862 | 2683 |
| | 4 | 6440 | 4879 | 4237 | 4025 | 3578 | 3220 | 2927 | 2683 | 2300 | 2147 | 2013 |
| | 5 | 5152 | 3903 | 3389 | 3220 | 2862 | 2576 | 2342 | 2147 | 1840 | 1717 | 1610 |
| | 6 | 4293 | 3253 | 2825 | 2683 | 2385 | 2147 | 1952 | 1789 | 1533 | 1431 | 1342 |
| | 7 | 3680 | 2788 | 2421 | 2300 | 2044 | 1840 | 1673 | 1533 | 1314 | 1227 | 1150 |
| | 8 | 3220 | 2439 | 2118 | 2013 | 1789 | 1610 | 1464 | 1342 | 1150 | 1073 | 1006 |
| | 9 | 2862 | 2168 | 1883 | 1789 | 1590 | 1431 | 1301 | 1193 | 1022 | 954 | 894 |
| | 10 | 2576 | 1952 | 1695 | 1610 | 1431 | 1288 | 1171 | 1073 | 920 | 859 | 805 |
| | 11 | 2342 | 1774 | 1541 | 1464 | 1301 | 1171 | 1064 | 976 | 836 | 781 | 732 |
| | 12 | 2147 | 1626 | 1412 | 1342 | 1193 | 1073 | 976 | 894 | 767 | 716 | 671 |
| | 13 | 1982 | 1501 | 1304 | 1238 | 1101 | 991 | 901 | 826 | 708 | 661 | 619 |
| | 14 | 1840 | 1394 | 1211 | 1150 | 1022 | 920 | 836 | 767 | 657 | 613 | 575 |
| | 15 | 1717 | 1301 | 1130 | 1073 | 954 | 859 | 781 | 716 | 613 | 572 | 537 |
| | 16 | 1610 | 1220 | 1059 | 1006 | 894 | 805 | 732 | 671 | 575 | 537 | 503 |
| | 17 | 1515 | 1148 | 997 | 947 | 842 | 758 | 689 | 631 | 541 | 505 | 474 |
| | 18 | 1431 | 1084 | 942 | 894 | 795 | 716 | 651 | 596 | 511 | 477 | 447 |

SURFACE SEMEE (Ha)=(VALEUR COMPTEUR) DIVISEE PAR (VALEUR TABLEAU)
 SOW SURFACE (Ha) = (COMPUTER VALOR) / (TABLE VALOR)
 GEDRILLTE FLÄCHE = (ZÄHLERANZEIGE) / (TABELLENWERT)
 SUPERFICIE SEMINATO (Ha) = (VALORE CONTATORE) / (VALORE TAVOLA)
 EXEMPLE:écartement 45cm sur semoir 12 rangs et valeur compteur=45000-->45000/1193=37,72Ha.

The value in the chart that corresponds to the number of rows used (1) and the spacing between rows (2) is **1193**.

- Divide the value indicated on the counter by the value indicated in the chart:


Example:

Value indicated on the hectare counter: 45000.

Number of hectares sown: $45000 / 1193 = 37.72$ ha.

To reset:


Turn the wheel (1) to reset the hectare counter to zero.



MAINTENANCE AND STORAGE



Before carrying out any maintenance or repairs on the machine, switch off the tractor engine, remove ignition key, wait until all moving parts have come to a standstill and apply park brake.



1. Frequency chart

| | Each time the machine is used | After the first 8 hours of use | Every 25 hours | Every 50 hours | At the end of each season |
|-------------------------------------|-------------------------------|--------------------------------|----------------|----------------|---------------------------|
| Lubrication | | | | | |
| Grease: | | | | ✓ | |
| - The gauge wheel pivot point | | | | ✓ | |
| - The marker pivot point | | | | ✓ | |
| - The roller guide pivot points | | | | ✓ | |
| - The telescopic frame | | | | | ✓ |
| Oil | | | | ✓ | |
| - The moving parts and pivot points | | | | ✓ | |
| - Chains | | | | ✓ | |
| Maintenance | | | | | |
| Check | ✓ | | | | |
| - Wearing parts | ✓ | | | | |
| - Seeding units | | | | ✓ | |



| | Each time the machine is used | After the first 8 hours of use | Every 25 hours | Every 50 hours | At the end of each season |
|---------------------------|-------------------------------|--------------------------------|----------------|----------------|---------------------------|
| - Tyre pressure | ✓ | | | | |
| - Fixing elements | | ✓ | | | |
| - Blower belt tension | ✓ | | | | |
| - Drive components | ✓ | | ✓ | | |
| - Sowing monitoring units | ✓ | | ✓ | | |

2. Cleaning the machine



Regularly clean hopper inside walls and furrow openers.

■ Hoppers

Empty and clean hopper inside and outside.

■ Blower and control boxes




Do not pressure-wash with water.

■ Distribution disc



Clean disks with a clean rag.



3. Lubrication

The pictorials show the points to be greased (Part no. 099054002).

Clean grease nipples before greasing.




Lubricate with SHELL multi-purpose grease grade NLGI 2.

Oil with SHELL SAE 90 gear oil.

■ PTO shaft


Primary PTO shaft

- Every 8 hours:
 - U-joints (1).
 - transmission tube (2).
 - guide rings (3).




■ Grease:


- The gauge wheel pivot point.




- The marker pivot point (1 on each side).




- The folding cylinder pivot points (1 on each side).




The foldable extension pivot point (1 on each side).



- The roller guide pivot points (1 on each side).



- The telescopic frame.



■ Oil:

- The moving parts and pivot points.
- Chains.




It is possible to spray silicone or other based aerosols to prevent dust from sticking on the chains.

4. Maintenance



Before carrying out any maintenance or repairs on the machine, switch off the tractor engine, remove ignition key, wait until all moving parts have come to a standstill and apply park brake.




■ Check

Wearing parts




It is important to check seed drill components sensitive to wear. Components must be replaced before wear affects the sowing quality.

- Opener disks:
The diameter of a new disk is of 380 mm (12.96") for a thickness of 4 mm (0.15").




- Door seals and distribution disks:
 - Check door seal (1) wear.
 - Check wear and flatness of distribution disks (2).
 - Check drive pin play (3) of each disk.



- Selector:

Wear modifies its action and risks creating doubles.
Change if necessary.

A gauge enables checking the selector wear.




Gauge part no.: **3N9818**.

- Position selector (1) on **11**.
- Position gauge (2) on drive square (3). Gauge (2) must be in contact with the fourth tooth (4) of the selector.

- Tyres:




Tire wear has a direct effect on the required sowing density.



Seeding units

Check all working parts for proper alignment to the sowing row (Coulters, clod-clearers, opener disks and rear rollers).

- Also check that all sections are equidistant.
- The correct positioning of the seed transfer ducts on the welded chassis and the proper condition inside and at the bottom part.



Tyre pressure




Tire pressure has a direct effect on the required sowing density.

A 1 bar (14 psi) low pressure can generate up to 3 % additional population.

- Tyres 26 x 12: 2.7 bar (39 psi).

Fixing elements

- Check wheelnut tightness:
 - Torque: 10 daN m (74 lbf ft).




Belt tension



Regularly check belt tension and in particular during the first hours of use.


- Exert a force of 7 daN on the belt.
- The deflection (H) must not exceed 20 mm (0.78").



For 4.40 m to 6 m (14'4" - 19'8") models:

Procedure to re-tension the belt:

- Remove 4 bolts (1).
- Remove guard (2).




- Loosen nuts (1).
- Loosen counter nut (2).
- Rotate nut (3) to tension the belt.




The belt tension must be moderate to prevent overheating.

- Tighten counter nut (2).
- Tighten nuts (1).




- Fit guard (2).
- Reinstall the 4 screws (1).




If the machine is fitted with a microgranulator, a blower is installed on the front of the vacuum turbine

To retension the blower belt:

- Remove 6 bolts (1).
- Remove guard (2).




- Loosen nuts (1).
- Loosen counter nut (2).
- Rotate screw (3) clockwise to tension the belt.



The belt tension must be moderate to prevent overheating.


- Tighten counter nut (2).
- Tighten nuts (1).

- Fit guard (2).
- Reinstall the 6 screws (1).



To retension fan blower:

- Remove 6 bolts (1).
- Remove guard (2).




- Loosen nuts (1).
- Loosen counternuts (2).
- Rotate screw (3) clockwise to tension the belt.




The belt tension must be moderate to prevent overheating.

- Tighten counternuts (2).
- Tighten nuts (1).



- Fit guard (2).
- Reinstall the 6 screws (1).



Drive components

Check the condition of the drive (condition of gears, sprockets, chains and tensioners).



Irregular drive can cause sowing variations.




Never fully tension the chains.

Sowing monitoring units

The sowing control cell (1) must be close to the distribution disk.




The cover must be correct without any possibility of the cell moving to the right.



5. Storage

■ At the end of each season



- Clean the machine with a spray gun.
- touch up any areas of damaged paintwork.
- Put the machine under cover in a dry place.
- Position wedges underneath wheel arms to take load off the tires.
- Store controls boxes in a dry place free of dust.
- Empty hoppers.
- Lubricate the whole machine.
- Check the operation of the doors and metering flaps.



■ **At the start of each season**


- Read through the operator's manual again.

- Check that all nuts and bolts are sufficiently tightened.



To keep an assembly mobile and self-aligning, nuts (1) and (2) fitted on each sowing unit must always be free to move on units (3), (4), (5) and (6).

- Make sure that all protection devices are in place and in good condition.
- Check that the lighting equipment is clean.
- Check tyre pressure.
- Check the condition of the hydraulic hoses.
- Check the condition and setting of the belts.



TROUBLE SHOOTING GUIDE

| ■ Problem | ■ Cause | ■ Remedy |
|--|---|---|
| Seeding units | | |
| There are misses on the seeding line. | Inappropriate disk being used. | Fit a disk to match seed size. |
| | Excessive ground speed. | Adapt the forward speed to the working conditions. |
| | Incorrect selector adjustment. | Adjust selector. |
| | Selector worn. | Adjust setting or change selector. |
| | Suction cover not closed properly. | Close it properly checking its sealing at the front and the rear of the metering housing. |
| | Spacer disk distorted, unsuitable or holes blocked. | Replace disc. |
| | | Fit a disk to match seed size. |
| | | Clean the disk and its holes with a dry rag. |
| | Fan belt improperly tensioned or displaced. | Tension belt. |
| | Failure of mechanical drive to disk. | Check the safety bolt and check that the disk rotates freely using the manual disengagement knob. |
| | Seed coating too delicate or uneven size. | Change seeds and do not mix varieties. |
| Fit disks without blades. | | |
| Worn door seal. | Replace seal. | |
| There are doubles on the seeding line. | Incorrect selector adjustment. | Adjust selector. |
| | Selector worn. | Adjust setting or change selector. |
| | Inappropriate disk being used. | Fit a disk to match seed size. |
| | Insufficient vacuum. | Reduce PTO speed. |
| | Seed level too high in the metering unit and overflowing into seed row. | Adjust seed supply. |

| ■ Problem | ■ Cause | ■ Remedy | |
|--------------------------|---|---|--|
| Unevenness while sowing. | Inappropriate disk being used. | Fit a disk to match seed size. | |
| | Incorrect selector adjustment. | Adjust selector. | |
| | Seed variety or batch promote poor placement. | Check improvement with another variety. (if possible send us a sample to the factory in order to check the problem with this type of seed on our test rig and to optimise settings). | |
| | Ground conditions. | Prepare ground correctly. Moisture content must be correct. | |
| | friction point in drive. | Check drive condition (gears, sprockets and chains). | |
| | Incorrect gearbox setting. | Use ratio adapted to the required population. | |
| | Excessive ground speed. | Adapt the forward speed to the working conditions. | |
| | Worn opening disks. | Replace opening disks. | |
| | Improper pressing and covering adjustment. | Reposition them so they do not interfere with seed positioning. | |
| | Incorrect seed drill horizontality adjustment. | Adjust the 3rd point such that the machine operates perfectly level. | |
| | Seed transfer duct encrusted and partialy blocked. | | Clean the inside and do not hesitate to replace it if necessary. |
| | | | Check for correct vacuum, re-tension the belt if necessary. |
| | Warped disk. | Replace disk. | |
| | Drive wheels are not always in contact with the ground. | Adjust spring adjustment in order to limit the ground pressure or add weights on the frame. | |
| Uneven sowing depth. | Ground too lumpy or too stony. | Prepare ground correctly. | |
| | Excessive ground speed. | Adapt the forward speed to the working conditions. | |
| | Incorrect seed drill horizontality adjustment. | Adjust the 3rd point such that the machine operates perfectly level. | |
| | Disks have difficulty in penetrating the ground. | Install ground pressure springs or fit a pre-cutting disk. | |



| ■ Problem | ■ Cause | ■ Remedy |
|--|---|--|
| Side markers | | |
| Too sharp raising and lowering of the markers. | Throttle valve not fitted or not adapted to the tractor oil flow. | Install adequate throttle valves. |
| Side markers do not react. | The side marker cylinder is not pressurized. | Pressurize the hydraulic circuit. Connect hoses to the other valve. |
| | The spool of the solenoid valve has seized up. | Remove the slide valve from the sequence valve and polish it. |



LIMITED WARRANTY

■ **The Limited Warranty is dependent on the strict observance of the following conditions:**

- The machine has been put in service by the dealer according to our instructions.
- The machine has been registered on line via extranet - www.kuhnsa.com or the warranty/product registration form has been completed and returned to the address indicated on the form as soon as the machine had been delivered to the retail purchaser.
- The warranty claim is completed on line via extranet - www.kuhnsa.com or submitted on a KUHN warranty claim form and returned to the Company within one month after the date of failure or the date of problem becoming apparent.
- The claim must be completed by the dealer and following information must be mentioned.
 - **Dealer's name and address**
 - **Name and address of retail purchaser**
 - **Exact type of machine**
 - **Machine serial number**
 - **Date of delivery to the retail purchaser**
 - **Date of failure**
 - **Number of hours of use or area (hectares, acres) worked**
 - **Power of tractor used**
 - **PTO speed (if applicable)**
 - **Detailed description and estimated cause of the failure**
 - **Quantity, reference number and name of the damaged parts**
 - **Invoice number and invoicing date for replacement parts.**
- The dealer has stored the damaged parts safely and labelled them clearly so that they can be recognised and returned to the Company if requested. They must be retained until a credit note has been issued to cover the parts. Carriage charges for the return of said parts are borne by the sender.
- The machine has been used and maintained according to the instructions in the operator's manual. The quality and quantity of lubricants used must always be in accordance with Company specifications.
- The safety measures mentioned in the Operator's manual and on the machine itself have been followed, and all the guards and protective elements, of whatever nature, have been inspected regularly and maintained in perfect working order.
- The judgment of the Company in all cases of claims under this Limited Warranty shall be final and conclusive and the retail purchaser agrees to accept its decisions.
- If damaged parts have been returned to the Company and Warranty is refused, the dealer is allowed a period of 1 month from the date of receiving our letter of decision to request the return of the damaged parts to the dealer site.

■ **Further conditions: limits of application and responsibility**

- This Limited Warranty can not be assigned or transferred to anyone without the prior written consent of the Company.
 - Authorized KUHN Dealers have no right or authority to assume any obligation or take any decision on the Company's behalf, whether expressly or tacitly.
 - Technical assistance given by the Company or its agents for repairing or operating equipment does not lead to any responsibility on the Company's behalf and cannot under any circumstances bring novation or derogation to the conditions of the present Limited Warranty.
 - The Company reserves the right to incorporate changes in its machines without prior notice and without obligation to apply these changes to machines previously manufactured.
 - Moreover, because of the constant progress in technology, no guarantee is given to the descriptions of equipment published in any document by the Company.
 - The present Limited Warranty excludes any other responsibility, whether legal or conventional, express or implied, and there are no warranties extending beyond those defined herein.
-

■ **The Limited Warranty is dependent on the strict observance of the following conditions:**

- The machine has been put in service by the dealer according to our instructions.
- The machine has been registered on line via extranet - www.kuhnsa.com or the warranty/product registration form has been completed and returned to the address indicated on the form as soon as the machine had been delivered to the retail purchaser.
- The warranty claim is completed on line via extranet - www.kuhnsa.com or submitted on a KUHN warranty claim form and returned to the Company within one month after the date of failure or the date of problem becoming apparent.
- The claim must be completed by the dealer and following information must be mentioned.
 - **Dealer's name and address**
 - **Name and address of retail purchaser**
 - **Exact type of machine**
 - **Machine serial number**
 - **Date of delivery to the retail purchaser**
 - **Date of failure**
 - **Number of hours of use or area (hectares, acres) worked**
 - **Power of tractor used**
 - **PTO speed (if applicable)**
 - **Detailed description and estimated cause of the failure**
 - **Quantity, reference number and name of the damaged parts**
 - **Invoice number and invoicing date for replacement parts.**
- The dealer has stored the damaged parts safely and labelled them clearly so that they can be recognised and returned to the Company if requested. They must be retained until a credit note has been issued to cover the parts. Carriage charges for the return of said parts are borne by the sender.
- The machine has been used and maintained according to the instructions in the operator's manual. The quality and quantity of lubricants used must always be in accordance with Company specifications.
- The safety measures mentioned in the Operator's manual and on the machine itself have been followed, and all the guards and protective elements, of whatever nature, have been inspected regularly and maintained in perfect working order.
- The judgment of the Company in all case of claims under this Limited Warranty shall be final and conclusive and the retail purchaser agrees to accept its decisions.
- If damaged parts have been returned to the Company and Warranty is refused, the dealer is allowed a period of 1 month from the date of receiving our letter of decision to request the return of the damaged parts to the dealer site.

■ **Further conditions: limits of application and responsibility**

- This Limited Warranty can not be assigned or transferred to anyone without the prior written consent of the Company.
- Authorized KUHN Dealers have no right or authority to assume any obligation or take any decision on the Company's behalf, whether expressly or tacitly.
- Technical assistance given by the Company or its agents for repairing or operating equipment does not lead to any responsibility on the Company's behalf and cannot under any circumstances bring novation or derogation to the conditions of the present Limited Warranty.
- The Company reserves the right to incorporate changes in its machines without prior notice and without obligation to apply these changes to machines previously manufactured.
- Moreover, because of the constant progress in technology, no guarantee is given to the descriptions of equipment published in any document by the Company.
- The present Limited Warranty excludes any other responsibility, whether legal or conventional, express or implied, and there are no warranties extending beyond those defined herein.



KUHN S.A. B.P. 50060 F - 67706 SAVERNE CEDEX (FRANCE)

Tél. : + 33 (0) 3 88 01 81 00 - Fax : + 33 (0) 3 88 01 81 03

www.kuhnsa.com - E-mail : info@kuhnsa.com

Société Anonyme au Capital de 19 488 000 Euros

KUHN-AUDUREAU S.A. B.P. 19 F - 85260 LA COPECHAGNIERE (FRANCE)

Tél. : + 33 (0) 2 51 41 47 00 - Fax : + 33 (0) 2 51 41 41 03

www.kuhnsa.com - E-mail : info@kuhnsa.com

Société Anonyme au Capital de 2 530 000 Euros

KUHN-BLANCHARD SAS - 24, route de Nantes - F - 44680 CHEMERE (FRANCE)

Tél. : + 33 (0) 2 40 21 30 24 - Fax : + 33 (0) 2 40 64 80 11

www.kuhnsa.com - E-mail : info@kuhnsa.com

Société par Action Simplifiée au Capital de 2 000 000 Euros

KUHN-HUARD S.A. B.P. 49 F - 44142 CHATEAUBRIANT CEDEX (FRANCE)

Tél. : + 33 (0) 2 40 55 77 00 - Fax : + 33 (0) 2 40 55 77 10

www.kuhnsa.com - E-mail : info@kuhnsa.com

Société Anonyme au Capital de 4 800 000 Euros

KUHN NORTH AMERICA INC P.O. Box 167 Brodhead - Wisconsin 53520 (USA)

Tél. : (608) 897 - 2131 - Fax : (608) 897 - 2561

www.kuhnsa.com - E-mail : info@kuhnsa.com

KUHN METASA PASSO FUNDO - RS - 99050-130 (BR)

Tél. : + 55 (54) 3316 6200 - Fax : + 55 (54) 3316 6250

www.kuhnsa.com - E-mail : info@kuhnsa.com