



RCT NL-N01K

NoteGuard T-Bar Security Cable with 4 Dial Combinations Lock.

- Designed to secure most:

NOTEBOOKS



PROJECTORS



LCD & PLASMA
SCREENS




- Easy to install
- Ideal theft deterrent



RESET COMBINATION

- The pre-set combination is 0-0-0-0.
- In order to set your own combination. hold the lock and using a small flat-head screwdriver or similar object, push in (B) and rotate the reset screw 90 degrees clockwise so that the screw's groove appears horizontal, then reset your own new combination.
- Then rotate the reset screw 90 degrees counter clockwise back to its original vertical position to save the new combination.
- Record the combination in either the space provided at the end of this guide or another secure, easy-to-find place.






TESTING THE COMBINATION

BEFORE ATTACHING THE LOCK TO YOUR NOTEBOOK COMPUTER.

- Turn the dials to disguise the combination.
- Return to the combination you set.
- Check that locking button depresses completely.



STEP 1

Loop the cable around a secure object.

STEP 2

Insert the lock into the computer slot then rotate (clockwise) the lock to 90 degrees. Release button (A) and mix number combination.

STEP 3

To open the lock, use your own combination and press button (A) then rotate (anti-clockwise) the lock to 90 degrees to open the lock.

PRODUCT BARCODE: 6009881185213



RCT

WWW.RCTZONE.CO.ZA