



Plug & Play




GT1060P Pen configuration:

NOTICE When using the product with Android™ device, pen/tablet settings cannot be customized.

For Windows®

Open the "Graphic Tablet" software to customize the settings.



SVer: 4.3.23.806 HVer: 2007 (G10)

1 Tablet connected

2 Screen Mapping **3** Defined Keys

Use Windows Ink **4**
 Left Hander **5**

6 [Grid area]

7 Website **8** Restore default **9** English

10 Custom Function keys [Z] + Ctrl + Alt + Shift [Reset]

Pressure fine tune **11** [Reset]
 Hard ——— 0 ——— Soft

This area is for testing purposes only,
 not painting software.


Test Paint Area **12** [Clear]

1 To show the connection status.	7 To access this user manual
2 To modify the screen mapping area and the active area of the tablet.	8 To restore default settings.
3 To customize the functions of the shortcut keys on the tablet.	9 To change the language.
4 Tick when using Microsoft Office.	10 To customize the function of the - button on the pen.
5 Tick for left-handed usage.	11 To fine-tune the pen pressure.
6 To show the pressure level.	12 The test paint area for testing the pen pressure.



GT1060P Button configuration:

1. Open Driver setting interface; select Defined keys.



- ① Select the key that you want to customize.
- ② Use the keyboard to enter the key.
- ③ Select the Combination key, if needed.
- ④ Confirm it.

