

# Prestik

## THE ORIGINAL RE-USABLE ADHESIVE

### TECHNICAL DATA SHEET

#### SMART ADVANTAGES

- STICKS TO ALMOST ANYTHING
- PERMANENTLY PLIABLE, REUSABLE
- STRIP FORM FOR EASE OF USE

#### DESCRIPTION

Bostik Prestik is the original off-white reusable putty-like adhesive, which is clean, safe and easy to use. It provides an ideal alternative to drawing pins and sticky tape. The innovative 4 strip design has over 101 uses in the home, office and school. It is solvent-free and non-toxic. Bostik Prestik will not dry out and can be removed and used over and over again.

#### APPLICATIONS

- Holds up posters, cards, certificates, notices, party decorations, maps, calendars, messages, learning aids, children paintings, etc.
- Holds in place telephones, mouse pads, pens, candles, figurines, vases, calculators, ornaments, etc.
- Keeps picture frames straight.
- Safely store pins, keys, screws and other small objects.
- Use in floral arrangements to keep flowers in place.
- Clean fluff from fabric.
- Remove dust and dirt from computers and hard to get to places.
- Use as a putty to block out breezes.
- Ideal as a modelling clay for children.

#### ADHESION

Bostik Prestik sticks extremely well to non porous surfaces such as metal, glass, plastics, vinyl coated and painted surfaces. Also sticks well to porous surfaces such as paper, boards, cloth, and wood.

#### LIMITATIONS

- Not suitable where a strong bond is needed and for holding up heavy objects.
- May damage fragile papers on removal.
- Not suitable on absorbent, silk-screen printed, hand-stenciled wall paper, or other delicate substrates as these are more susceptible to oil damage or may be damaged when the product is removed at a later stage.
- May leave an oily mark on some painted surfaces and papers.

#### SAFETY INSTRUCTIONS

Bostik Prestik is non-toxic. The product poses a choking hazard if ingested. In the event of ingestion, the mouth should be washed with water. Seek medical assistance if irritation or discomfort persists. Refer to our Safety Data Sheet for further toxicological information and comprehensive handling instructions.

#### SURFACE PREPARATION

Ensure that surfaces are clean, dry and free of any dust, grease and loose materials.



**HOW TO USE**

1. Pull off a piece of Bostik Prestik and activate it by pulling and stretching.
2. Roll into a ball, place between surfaces the two surfaces, and press firmly to adhere.
3. To prevent oil stains to posters, we recommend that strips of tape be applied to the back of the poster and the Bostik Prestik be attached to this area as opposed to directly onto the poster.

**CLEANING**

- Remove as much as possible mechanically by rolling off the surface. Dab any remaining residue with a larger piece of Prestik or rub with mineral turpentine.
- Use lighter fluid or Low Aromatic Cleaning Benzine (LACB) to remove off fabric. Check for colourfastness before using any solvents.

**STORAGE STABILITY**

The shelf life of the product is >5 years if stored at room temperature in its original packaging. If the material is kept beyond the recommended shelf life, it is not necessarily unusable. A check should be performed to observe whether the product is pliable and tacky.

**PRODUCT PACKAGING**

- 25g Wallets
- 50g Wallets
- 100g Wallets

PRODUCT CHARACTERISTICS	
Type	Synthetic polymer base
Appearance	Off-white pliable putty
Density (g/cm <sup>3</sup> )	1.6
Solids (%)	100

TYPICAL PERFORMANCE DATA	
Chemical resistance	Resistant to most diluted mineral and organic acids, alkalis and salts at normal temperatures
Cold Resistance	Retains elasticity down to -30°C
Heat Resistance	Softening occurs at elevated temperatures above 45°C
Water resistance	Waterproof

**DISCLAIMER**

The above information is only offered as a guide to the use of this product. Furthermore, users should satisfy themselves that it is suitable for their needs. Since we have no control over the conditions under which it is used, we cannot accept responsibility for the problems caused by the use and/or application of this product.

Head Office: +27(0)21 555 7400  
 Beverley Close, Montague Gardens, 7441  
 PO Box 37008, Chempet, 7442  
[www.bostik.co.za](http://www.bostik.co.za)

ASK A STICKY QUESTION...  
[www.stickyquestions.co.za](http://www.stickyquestions.co.za)  
 0800 222 400

